Service Handbook Model 745



HP Part No. A4964-90602 Edition E1199 Special Online Edition Printed in U.S.A. © Hewlett-Packard Co. 1999

Printing History

First Printing: April 1999 Latest Printing: November 1999

UNIX is a registered trademark of The Open Group.

#### NOTICE

The information contained in this document is subject to change without notice.

HEWLETT-PACKARD MAKES NO WARRANTY OF ANY KIND WITH REGARD TO THIS MATERIAL INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Hewlett-Packard shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance or use of this material.

Hewlett-Packard assumes no responsibility for the use or reliability of its software on equipment that is not furnished by Hewlett-Packard.

This document contains proprietary information that is protected by copyright. All rights reserved. No part of this document may be photocopied, reproduced or translated to another language without the prior written consent of Hewlett-Packard Company.

RESTRICTED RIGHTS LEGEND. Use, duplication, or disclosure by government is subject to restrictions as set forth in subdivision (c) (1) (ii) of the Rights in Technical Data and Computer Software Clause at DFARS 252.227.7013. Hewlett-Packard Co., 3000 Hanover St., Palo Alto, CA 94304.

10987654321

### **Safety and Regulatory Statements**

#### Safety

See the owner's guide that came with your system for safety information.

#### **Regulatory Statements**

#### **Emissions Regulations**

**Federal Communications Commission (FCC)** The Federal Communications Commission of the U.S. government regulates the radio frequency energy emanated by computing devices through published regulations. These regulations specify the limits of radio frequency emission to protect radio and television reception. All HP nodes and peripherals have been tested and comply with these limits. The FCC regulations also require that computing devices used in the U.S. display the agency's label and that the related documentation include the following statement:

NOTE:

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

**Canadian Department of Communications (CDC)** This digital apparatus does not exceed the Class A limits for radio noise emissions from digital apparatus as set out in the Radio Interference Requirements of the Canadian Department of Communications.

**Emissions Regulations Compliance** Any third-party I/O device installed in HP system(s) must be in accordance with the requirements set forth in the preceding Emissions Regulations statements.

#### **Safety and Regulatory Statements**

In the event that a third-party noncompliant I/O device is installed, the customer assumes all responsibility and liability arising therefrom.

**Electrostatic Discharge (ESD) Precautions** Electrostatic charges can damage the integrated circuits on printed circuit boards. To prevent such damage from occurring, observe the following precautions during board unpacking and installation:

- Stand on a static-free mat.
- Wear a static strap to ensure that any accumulated electrostatic charge is discharged from your body to ground.
- Connect all equipment together, including the static-free mat, static strap, routing nodes, and peripheral units.
- Keep uninstalled printed circuit boards in their protective antistatic bags.
- Handle printed circuit boards by their edges, once you have removed them from their protective antistatic bags.

#### 1 Product Information

The Model 745 Industrial Controller 1-3

Features 1-5

Typical External Devices 1-6

Physical Dimensions and Power Requirements 1-7

**Board Computer Configurations 1-8** 

Cables 1-9

Operating System Overview 1-10

Manuals for System Information 1-11 HP-UX 1-11 HP VUE 1-11 HP CDE 1-11

Online Sources of Information 1-12

Audio 1-13

Product Identification 1-14 Support 1-14 Hardware Support 1-14 Field Repair Philosophy 1-14

#### 2 Environmental/Installation/PM

Overview 2-2

**Environmental Specifications 2-3** 

**Regulatory Requirements 2-4** 

Installation 2-5

Preventive Maintenance 2-6

#### 3 Configuration

Boot Console User Interface Features 3-2
Main Menu 3-3
Configuration Menu 3-4
Information Menu 3-5
Service Menu 3-6
Accessing the Boot Console Interface 3-7
Booting Your Workstation 3-9
Searching for Bootable Media 3-11
Restoring the Factory Default Configuration 3-12
Displaying and Setting Paths 3-13
Displaying and Setting the Monitor Type 3-16
The Monitor Command 3-16

Displaying the Current Monitor Configuration 3-17 Setting the Monitor Type 3-18 Setting the Monitor Type at Power On 3-20 Using the Emergency Interactive Console Search 3-21

Displaying the Current Memory Configuration 3-23 Memory Information Example 3-23

Displaying the Status of the System I/O 3-25

Setting the Auto Boot and Auto Search and Auto Start Flags 3-26

Displaying and Setting the Security Mode 3-28

Displaying and Setting the Fastboot Mode 3-29

Displaying the LAN Station Address 3-30

**Displaying System Information 3-31** 

**Displaying PIM Information 3-32** 

Power Budgeting 3-33

#### 4 Troubleshooting

Dealing with a Boot Failure 4-2 Searching for Bootable Media 4-4 Stable Storage 4-4 Boot Command Notations 4-5 ISL Environment 4-6

Firmware Selftest Failures 4-7 Interpreting the Front Panel LEDs 4-7 Interpreting the Diagnostic Chassis Codes 4-9

Running ODE-Based Diagnostics 4-21

Running System Verification Tests 4-23

Dealing with HPMC (Uncorrectable Error) 4-25

HPMC Caused by a Data Cache Parity Error 4-28 HPMC Caused by a Multi-Bit Memory Parity Error 4-29 Interpreting the Table 4-29 Determining the Faulty Memory Card 4-30

#### 5 Field Replaceable Units

Introduction 5-2 Tools Required 5-2 Safety Precautions 5-2 New Parts 5-3 Exchange Parts 5-3 Local Hewlett-Packard Sales & Service Office 5-3 Replaceable Parts 5-4

Model 744 Board Computer Parts 5-7

Removing and Replacing the Model 744 Board Computer 5-9

Preliminary Requirements 5-9

Removal 5-10 Replacement 5-10

Removing and Replacing RAM Cards 5-12 Preliminary Requirements 5-12 Removal 5-12 Replacement 5-13

Removing and Replacing the PMC Adapters 5-14 Preliminary Requirements 5-14 Removal and Replacement 5-14

Removing and Replacing the Front Panel 5-21

Preliminary Requirements 5-21 Removal and Replacement 5-22

Firmware ICs 5-23

Description 5-23

Removing and Replacing the Real-Time Clock Battery 5-24

Preliminary Requirements 5-24 Removal 5-24 Replacement 5-24

Removing the Top Cover, Front Bezel, and Mid-Tray 5-25

Preliminary Requirements 5-25

Replacing Mass Storage Devices 5-29

Procedure 5-29 Selecting Device Address 5-29 Procedure 5-29 CD-ROM 5-30

Floppy Disk Drive 5-31 DDS Tape Drive 5-32 Hard Disk Drive Address Selection 5-33 **Device Locations 5-33** Removing a Device from the Mass Storage Carriers 5-34 Installing a Device in a Mass Storage Carrier 5-35 EISA or PCI Backplane Replacement 5-40 Preliminary Requirements 5-40 Procedure 5-40 Power Supply Replacement 5-42 Preliminary Requirements 5-42 Power Supply Removal 5-42 System Backplane Replacement 5-45 Preliminary Requirements 5-45 System Backplane Removal 5-46 Fuse Replacement 5-47 Preliminary Requirements 5-47

Rear Fan Replacement 5-48

Front Fans Replacement 5-50 Preliminary Requirements 5-50

#### 6 Diagrams

Functional Description of Model 745 Chassis 6-2

### 7 Reference Documentation

Service Documentation 7-2

System Installation and Getting Started Documentation 7-4

8 Service Notes

#### Figures

Model 745 Front View 1-3 Model 745 Rear View 1-4 Board Computer Front Panel 1-4 Serial Number Information 1-14 Model 744 LED Location 4-7 Physical Memory Slots 4-31 Example Memory Address Worksheet 4-35 Memory Address Worksheet 4-37 Model 745 Exploded View 5-4 Model 744 Board Computer (Exploded View) 5-7 Locating the LAN ID 5-9 Model 744 Captive Screws 5-10 RAM Card Fasteners 5-12 Removing the Labels and Springs 5-15 Removing the Sleeves 5-16 Removing the PMC Expansion Adapter 5-17 Removing a PMC card from the Expansion Adapter 5-18 Removing the PMC Bridge Adapter 5-19 Removing a PMC card from the Bridge Adapter 5-20 Port Jack Screws 5-22 744 ICs 5-23 Top Cover Removal 5-26 Front Bezel Removal 5-27 Mid-Tray Removal 5-28 CD-ROM Disk Drive 5-30 Floppy Disk Drive 5-31 DDS Tape Drive Address Selection 5-32 **Device Locations 5-33** Removing Retainer Bracket 5-34 Device Installation in the Disk Carrier 5-36 Installing the 3.5-inch adapter brackets 5-37 3.5-Inch Hard Disk Installation with Filler Panel 5-37 **Replacing Disk Carriers 5-38** Replacing Retainer Bracket 5-39 Backplane Assembly Removal 5-40 EISA or PCI Converter Board and Backplane Removal 5-41 Cherokee Power Supply Removal and Replacement 5-43

Astec Power Supply Replacement 5-44 System Backplane Removal 5-46 Fuse Removal 5-47 Rear Fan Removal (Step 1) 5-48 RearFan Removal (Step 2) 5-49 Rear Fan Removal (Step 3) 5-49 Front Fans Removal 5-50 Model 745 Functional Block Diagram 6-2 Model 744 Block Diagram 6-3 Model 745 Power Distribution Diagram 6-4

#### Tables

Cabling 1-9 **Environmental Information 2-3 Regulatory Information 2-4** System Paths 3-13 Mnemonic Style Notation 3-14 LED Indicators 4-8 Chassis Code Operating States 4-9 Chassis Codes 4-10 PIM Action Table 4-25 Processor Module Error (Data Cache Parity) 4-28 Multi-Bit Memory Parity Error 4-29 Logical Memory Slots 4-32 Memory Configuration Example 4-33 Memory Address Ranges 4-38 Model 745 Chassis Parts List 5-5 Mass Storage Parts List 5-6 **Replaceable Parts 5-8** Default SCSI Addressing 5-29 Related Service Documentation 7-2 **Diagnostic Documentation 7-3** System Installation and Getting Started Documentation 7-4

# **Product Information**

1

#### **Product Information**

This chapter introduces the Model 745 Industrial Controller. Its purpose is to familiarize you with the system features, controls, and indicators.

The major sections within this chapter are:

- Features
- Model 745 Physical Dimensions and Power Requirements
- Board Computer Configurations
- Cables

# The Model 745 Industrial Controller

The Model 745 Industrial Contoller provides for a wide variety of PCI or EISA cards. In combination with the Model 744 board computer as the system controller, the Model 745 is exceptionally flexible and responsive, being based on Hewlett-Packard's PA-RISC technology. Figure 1-1, Figure 1-2, and Figure 1-3 show a front view of the Model 745, a rear view, and the front panel of the board computer.





Model 745 Front View

#### Product Information The Model 745 Industrial Controller



Figure 1-2

Model 745 Rear View



Figure 1-3

**Board Computer Front Panel** 

## Features

The Model 745 has the following general features:

• Single-board computer processor:

132 MHz, or

165 MHZ

• Input/Output:

Onboard graphics, with optional

17-inch 1280x1024 monitor, or

19-inch 1280x1024 monitor

2 RS-232C ports

AUI (LAN) port

HP parallel port

Audio I/O ports

Speaker port

Single-Ended (SE) SCSI for internal and external devices

- PS/2 keyboard and mouse with mini-DIN connectors
- Slots for up to four user installed cards,

PCI or

EISA

• Optional PMC adapters available for 2 or 4 PMC sites added to board computer

Supports up to 4 HP PMC Graphics cards

Third party cards are available

• Mass storage bays for up to five devices, with up to two forward or rear facing removable media devices, including:

4GB single-ended SCSI hard drive

1.4MB floppy drive

Fast CD-ROM drive

#### Product Information Features

DDS-2 tape drive

- One 400 Watt power supply
- Operating system
  - HP-UX 10.20 (or later)
  - Supports SICL libraries
  - Supports Rocky Mountain Basic (RMB).
  - User interface

CDE or HP VUE graphical user interface.

Compatibility

Source and binary code compatible with HP 9000 product family.

### **Typical External Devices**

The Model 745 supports the following external devices:

LAN transceiver

HP A2670A ThinLAN ETHERNET Transceiver HP A2671A EtherTWIST Transceiver

• Speaker; 8 ohm impedance with <sup>1</sup>/<sub>8</sub>-inch sub-miniature stereo connector.

Only products with Hewlett-Packard approved parts, accessories, peripherals, operating systems, and application programs are supported by Hewlett-Packard. Any product with other than HP approved hardware or software connected or installed must have the non-HP approved hardware and software removed by the customer before on-site repair is conducted.

## **Physical Dimensions and Power Requirements**

Physical dimensions:

- Height: 177 mm (6.97 in.) 4 EIA Units
- Width: 425.45 mm (16.75 in.)
- Depth: 412.77 mm (16.25 in.)

Power requirements:

- Input voltage: 100-240 Vac
- Input frequency:50 to 60 Hz
- Input power: 700W maximum
- Input current: RMS 7 A 3.5 A maximum @ 100-240 Vac

The power supply for the Model 745 provides sufficient power to all devices and option slots, within specifications for those options. No power budgeting is required for options.

# **Board Computer Configurations**

The Model 745 Industrial Controller incorporates the Model 744 single-board compter (SBC) as its processor. The Model 744 is a high-performance Precision Architecture board computer based on the Hewlett-Packard PA-RISC 7300LC technology. It contains the following key features:

• Model type:

Model 744/132L

Primary internal cache - 128 KB: 64 KB instruction, 64KB data Model 744/165L

Primary internal cache - 128 KB: 64 KB instruction, 64KB data Secondary external cache - 512 KB

Clocks

Battery-backed real-time clock Interval timers (One 32 bit, Two 16 bit) Watchdog timer

Main Memory

Up to four RAM cards may be installed.

When mixing memory card capacities that include 128MB or 256MBcards, the 128MB and 256MB card(s) must be installed into the lowest memory slots before adding cards of other capacities.

*NOTE:* HP-UX requires a minimum of 32 MB RAM.

# Cables

Cables needed to connect to the ports of the Model 745 industrial controller are provided with the system.

The high-density I/O connectors for the board computer require conversions to standard cabling. These cables are 75 cm (30 in.) long.

See Table 1-1 for details of the cable included with the system.

Table 1-1	Cabling
Cable Number	Description
HP A4300A	HP Parallel: High Density 25-pin to standard 25-pin (female)
HP A4301A	RS-232C: High Density 9-pin to standard 9-pin (male)
HP A4302A	Audio: High Density 9-pin to three mini jacks
HP A4303A	LAN: High Density 15-pin to 15-pin AUI
HP A4305A	Video for EVC monitors: High Density 15-pin to EVC
	35-pin connector (female)
HP A4223A	Video: High Density 15-pin to standard 15-pin (female)
HP C2955A	SCSI: High Density 50-pin to High Density 50-pin, .5m (male)
HP K2291	SCSI: High Density 50-pin terminator
HP A4199A	Power cord (if no localization kit was ordered)

Standard interface cables are available and may be required to connect to the cable listed above.

# **Operating System Overview**

The Model 744 uses the standard HP-UX 10.20 or later operating system, a highly versatile system for multitasking, running your application programs, and performing a variety of development tasks. Refer to *HP-UX System Administration Tasks* for detailed installation and operation procedures for HP-UX.

When systems are configured at the factory, a specific HP-UX kernel configuration is chosen. If you reload HP-UX after receiving you system, you must reconfigure the kernel according to include the **vme2** driver.

# **Manuals for System Information**

### HP-UX

After you have completed the installation procedures in this book, you may consult the following sources for further information:

- For HP-UX administration information, see HP-UX System Administration Tasks.
- For a quick reference to commonly-used HP-UX commands, see the appendix in *Using HP-UX*.
- HP VUE or CDE is the default interface for HP-UX. At some point, you may want to interact with the Model 744 using CDE or HP VUE via the LAN, with an X Window System display. As a simpler window alternative, you can also use the X Window System by itself. All interfaces are included in HP-UX. For further information, refer to *Using the X Window System*, *Using HP-UX*, *CDE User's Guide*, or *HP VUE User's Guide*.

The following manuals are also useful:

- If you have not yet installed your HP-UX OS, see Installing HP-UX.
- For troubleshooting HP-UX, see the manual Solving HP-UX Problems.

#### HP VUE

For information on using and configuring the HP VUE interface with HP-UX, see *HP VUE User's Guide*. For information on installing HP VUE, refer to *HP VUE Installation Guide*.

#### HP CDE

For information on using and configuring the CDE interface with HP-UX, see *CDE User's Guide*. For information on installing CDE, refer to *CDE Installation Guide*.

# **Online Sources of Information**

HP-UX is designed so that you can access many sources of information without leaving your system. Most of these information sources are accessible through the shell command line on a character terminal.

Man pages: The HP-UX information found in *HP-UX Reference* is online and accessible by clicking on the Toolbox button at the right of your Front Panel, or by entering man command on a command line, where command is the name of the HP-UX command or routine you want to get information on. If you're not sure of the command name, you can enter man -k keyword, where keyword is a likely topic word to search on. This results in a display listing commands having the keyword in their description.

There are also a variety of files which contain version-specific information. These will be useful in administering and configuring cards and devices for your version of HP-UX. Among these files are the following:

- Release Notes: This is the online version of the Release Notes which come with your system. It contains all the latest information, undocumented changes, and bug fixes for your release of HP-UX. It also contains information on the current version of HP VUE. The Release Notes document resides in the /usr/share/doc directory, named by its release number; for example, 10.20RelNotes for HP-UX 10.20.
- HP-UX and HP VUE Help. For graphics displays, extensive help information on the operating system and the visual interface is included with HP VUE.
- Newconfig: The directory /usr/newconfig/etc contains information and new versions of HP-UX product configuration files, as well as shell scripts which may have been customized on your system. The contents of this directory will vary depending on which products you have loaded onto your system. In most cases, old versions of these files, in their regular locations in the file system, are not overwritten by the update process.

# Audio

HP-UX includes audio software comprising an audio editor, Audio Application Program Interface (AAPI), and some sample programs. Audio output is available through the audio port on the front panel of the Model 745. For highest quality audio, an external headphone set or speaker is recommended.

Audio is implemented using a CODEC (coder-decoder) combining CD-quality stereo audio-digital converters for microphone and line-input levels. The input sampling rate and format are programmable, as are the input gain and output attenuation.

A  $1/_{8}$ -inch mini-jack is used for the speaker output connection. The remaining audio signals are via a 9-pin D-sub connector. Output impedance is nominally 8 ohms, but higher impedance devices can also be driven.

For information on programming for audio, refer to *Using the Audio Developer's Kit* (B2355-90069) and the man page *audio*.

# **Product Identification**

On the bottom, a label lists the product serial number. Its information can be interpreted as shown in Figure 1-4 below for an example serial number 6421A00001:

Figure 1-4

#### **Serial Number Information**



### Support

Support services and policies mentioned in this section are subject to change. Please consult your local Hewlett-Packard Sales and Service Office for the current support policies.

### **Hardware Support**

#### Field Repair Philosophy

Field Repair Philosophy for these products is assembly, or board level. When a failure occurs, the problem is diagnosed to the assembly having the failed part, that assembly is then replaced.

Some assemblies may be exchanged for rebuilt ones. Other assemblies are only available as new ones. Refer to appropriate service handbook for information on replacement parts.

Additional Technical Information

Additional technical information on this product can be found in the *Model 745 Technical Reference*. Detailed information about architecture is provided.

#### Schematics

In support of the repair philosophy, this manual contains information to the assembly level. Schematics are not available for these products.

#### **Supported Configurations**

Only products with Hewlett-Packard approved parts, accessories, peripherals, operating systems and application programs are supported by Hewlett-Packard. Any product with other than HP approved hardware or software connected or installed must have the non-HP approved hardware and software removed by the customer before On-Site repair is accomplished.

**Repair Services** 

Hewlett-Packard supports three repair services:

Return to Hewlett-Packard Repair

**On-Site Repair** 

Customer Repair

For Return to Hewlett-Packard Repair, customers return the product to their local HP Sales and Service Office, where an HP Bench Repair Engineer troubleshoots, and repairs the hardware to the assembly level. The defective assembly is replaced with a new or rebuilt assembly and the product is returned to the customer. This service is available through a service contract or a time-and-materials basis.

On-Site Repair is performed at the customer's site. This service is available through a service contract or a time-and-materials basis.

Customers have the option of repairing their own HP products. Contact your nearest Hewlett-Packard Sales and Service Office for information concerning service training, special tools and test equipment, and spare parts. Product Information Product Identification

# Environmental/ Installation/PM

# Overview

This chapter lists the environmental specifications and regulatory requirements for the system. Installation and preventive maintenance information, if applicable, is also provided.

# **Environmental Specifications**

Table 2-1 lists the environmental specifications for this workstation.

Table 2-1Enviro	onmental Information
Operating temperature	0° - 55° C (without mass storage) 5° - 40° C (with mass storage)
Non-operating temperature	-30° - 70° C
Heat dissipation	2390 BTU, 600 Kcal/hr
Humidity (non-condensing); operating	95% maximum at 40deg; C (without mass storage) 90% maximum at 40deg; C (with mass storage)
Humidity (non-condensing); non-operating	5 - 95%
Maximum altitude, operating (to 47° C):	4.6 K meters (15 K ft.)(without mass storage) 3.05 K meters (10 K ft.)(with mass storage)
Maximum altitude, non-operating:	4.6 K meters (15 K ft.)

# **Regulatory Requirements**

Table 2-2 lists the regulatory requirements for this workstation.

Table 2-2	Regulatory Information
Safety Specification:	UL 1950, CSA 950M, IEC 950
Acoustics	NS ISO 7779
Electromagnetic Certification	FCC, VCCI, Taiwan,Australia, Canada, and European CE marks

# Installation

Refer to Model 745 Owner's Guide for system installation information.

# **Preventive Maintenance**

The system unit requires no preventive maintenance. Some removable media storage devices require operator preventive maintenance. Refer to *Model 745 Owner's Guide* for more information.
## Configuration

This chapter describes the interface to the Boot Console Handler (BCH), and discusses power budgeting.

## **Boot Console User Interface Features**

There are times when you want to interact directly with the hardware of your single board computer **before** it boots the operating system. Your 745 system provides a menu-driven **boot console interface** that allows you to perform special tasks, display information, and set certain system parameters, even if the operating system is unavailable.

Here are some of the things you can do:

- Boot your workstation
- Search for bootable media
- Reset your workstation
- · Display and set boot paths
- Display and set your monitor type
- Display memory configuration information
- Display the status of the EISA slots
- Set Auto Boot and Auto Search
- Set Fastboot
- Display LAN information
- Display system information
- Display PIM information

The **boot console** menus follow, showing the various tasks you can perform and the information available.

The shortened version of all commands is indicated by the uppercase letters.

Help is available for all menus and commands by using either **help**, **he**, or **?** and the menu or command you want help on.

### Main Menu

Main Menu	
Command	Description
BOot [PRI ALT  <path>]</path>	Boot from specified path
PAth [PRI ALT CON KEY][ <path>]</path>	Display or modify a path
SEArch [DIsplay IPL] [ <path>]</path>	Search for boot devices
COnfiguration [ <command/> ]	Access Configuration menu/commands
INformation [ <command/> ]	Access Information menu/commands
SERvice [ <command/> ]	Access Service menu/commands
DIsplay	Redisplay the current menu
HElp [ <menu> <command/>]</menu>	Display help for menu or command
RESET	Restart the system
Main Menu: Enter command >	

#### Configuration Boot Console User Interface Features

## **Configuration Menu**

Configuration Menu	
Command	Description
AUto [BOot SEArch] [ON OFF]	Display or set specified auto flag
BootID [ <proc>] [<boot id="">]</boot></proc>	Display or modify processor boot ID
BootINfo	Display boot-related information
BootTimer [0 - 200]	Seconds allowed for boot attempt
DEfault	Set the system to predefined values
FastBoot [ON OFF]	Display or set boot tests execution
MOnitor [LIST  <path> <type>]</type></path>	Change the current monitor type
PAth [PRI ALT CON KEY] [ <path>]</path>	Display or modify a path
SEArch [DIsplay IPL] [ <path>]</path>	Search for boot devices
SECure [ON OFF]	Set/show security mode
TIme [c:y:m:d:h:m:[s]	Read or set real time clock in GMT
BOot [PRI ALT  <path>]</path>	Boot from specified path
DIsplay	Redisplay the current menu
HElp [ <menu> <command/>]</menu>	Display help for menu or command
RESET	Restart the system
MAin	Return to Main Menu
Configuration Menu: Enter command	>

### Configuration Boot Console User Interface Features

### **Information Menu**

Information Menu -	
Command	Description
ALL	Display all system information
BootINfo	Display boot-related information
CAche	Display cache information
ChipRevisions	Display revisions of VLSI and firmware
COprocessor	Display coprocessor information
FwrVersion	Display firmware version
IO	Dispay I/O interface information
LanAddress	Display built-in system LAN address
MEmory	Display memory information
PRocessor	Display processor information
WArnings	Display selftest warning messages
BOot [PRI   ALT   <path>]</path>	Boot from specified path
DIsplay	Redisplay the current menu
HElp [ <menu> <command/></menu>	Display help for menu or command
RESET	Restart the system
MAin	Return to Main Menu
Information Menu: Enter c	ommand >

### Configuration Boot Console User Interface Features

### Service Menu

Service Menu	
Command	Description
ChassisCodes [ <proc>]</proc>	Display chassis codes
CLEARPIM	Clear (zero) the contents of PIM
<pre>EepromRead [<addr>] {<len>]</len></addr></pre>	Read EEPROM locations
MemRead <addr> [<len>] [a]</len></addr>	Read memory locations
PIM [ <proc> [HPMC TOC]]</proc>	Display PIM information
BOot [PRI ALT  <path>]</path>	Boot from specified path
DIsplay	Redisplay the current menu
HElp [ <menu> <command/>]</menu>	Display help for menu or command
RESET	Restart the system
MAin	Return to Main Menu
Service Menu: Enter command >	

### Accessing the Boot Console Interface

To access the boot console interface, follow these steps:

**NOTE:** This procedure should be done by a system administrator with **root** user privileges.

- 1 Close any files and applications on your workstation.
- 2 In a terminal window, enter the following command:

#### reboot -h

3 When the system has completely shut down, power off the system then power it back on.

If **Autoboot** is turned off, the boot sequence automatically stops at the boot console Main Menu.

If Autoboot is turned on, you will see the following messages:

Processor is starting Autoboot process. To discontinue, press any key within 10 seconds.

If Autoboot and Autosearch are both turned on, you will see the following messages:

Processor is booting from first available device.To discontinue, press any key within 10 seconds.

**NOTE:** If you are using a power-saving monitor, you will have less than 10 seconds from the time this message appears to press a key. Power saving monitors usually indicate the presence of a live video sync signal through the power LED on the monitor. When the LED is on, press **ESC**.

### Configuration Accessing the Boot Console Interface

4 Press a key. You will then see the following message:

Boot terminated

The Main Menu of the boot console appears.

Main Menu	
Command	Description
BOot [PRI ALT  <path>]</path>	Boot from specified path
PAth [PRI ALT CON KEY][ <path>]</path>	Display or modify a path
SEArch [DIsplay IPL] [ <path>]</path>	Search for boot devices
COnfiguration [ <command/> ]	Access Configuration menu/commands
INformation [ <command/> ]	Access Information menu/commands
SERvice [ <command/> ]	Access Service menu/commands
DIsplay	Redisplay the current menu
HElp [ <menu> <command/>]</menu>	Display help for menu or command
RESET	Restart the system
Main Menu: Enter command >	

## **Booting Your Workstation**

Usually, you start your workstation by turning it on and waiting for the operating system to boot automatically. However, you may not always want the usual sequence to occur.

For example, you may want to start your workstation from an operating system that is stored on a device that is different from your usual boot device. If your normal operating system kernel or the disk on which it resides becomes damaged or unusable, you may wish to boot from a different disk or perhaps another type of device, such as a DDS-format tape drive.

Here are some situations and examples:

• If you know which device you want to boot from, and you know that it contains a bootable operating system, follow the directions in "Accessing the Boot Console Interface" earlier in this chapter, and then type the following at the prompt:

Main Menu: Enter command > boot device

where *device* is the **hardware path** to the device, specified in Mnemonic Style Notation. When prompted whether or not to interact with the ISL enter **n** for no.

For example, if you wish to boot an operating system that is stored on a DDS-format tape in a drive that is located at "sescsi.1.0", follow the directions in "Accessing the Boot Console Interface" earlier in this chapter, and then type the following command at the prompt:

Main Menu: Enter command > boot sescei.1.0

Interact with ISL (Y,N,Q)> n

The operating system on the specified device is used to start your workstation.

• The Initial System Loader (ISL) is the program that actually controls the loading of the operating system. By interacting with ISL, you can choose to load an alternate version of the HP-UX operating system. If you wish to interact with the ISL before booting your workstation, follow the directions in "Accessing the Boot Console Interface" earlier in this chapter, and then type the following at the prompt:

Main Menu: Enter command > boot device

You are prompted:

Interact with ISL (Y,N,Q)>

# Configuration Booting Your Workstation

Answering quit  $(\mathbf{q})$  aborts the boot and returns you to the boot console handler.

Answering no (**n**) continues the boot sequence with the device specified from the main menu prompt.

Answering yes (y) causes the ISL to be loaded from the specified device. After a short time, the following prompt appears on your screen:

ISL>

For example, if the usual kernel (/**stand/vmunix**) on your root disk (**fwscsi.6.0**) has become corrupted, and you wish to boot your workstation from the backup kernel (/ **stand/vmunix.prev**), type the following at the ISL> prompt:

#### ISL> hpux /stand/vmunix.prev

To quit out of the ISL without booting, you must power cycle the board computer.

• If you do not know which media in your file systems have bootable operating systems, you can find them with the **search IPL** command. See the section "Searching for Bootable Media".

## Searching for Bootable Media

To list devices that contain bootable media, follow the directions in "Accessing the Boot Console Interface" earlier in this chapter, and then type the following at the prompt:

Main Menu: Enter command > search ipl

The search command searches all buses. The search may turn up more devices than there are lines on your display. If you are using a text terminal, you may control the progress of the search from your terminal's keyboard by using the following commands:

- To hold the display temporarily, press  $\overline{Ctrl}$   $\overline{S}$
- To continue the display, press  $\overline{\mathbf{Ctrl}}$   $\overline{\mathbf{Q}}$
- To halt the search, press any other key

These flow-control commands do not work with a bitmapped display, but such a display can show more than forty lines of text, so you are unlikely to need them.

To search for devices of *just one type* that actually contain bootable media, follow the directions in "Accessing the Boot Console Interface" earlier in this chapter, and then type the following at the prompt:

Main Menu: Enter command > search ipl device\_type

Where *device\_type* is one of the following:

sescsi is the built-in single-ended SCSI bus

lan is all connections to the built-in LAN

**pci***n* is an optional PCI card in slot *n* 

**pmc***n* is an optional PMC card in site *n* 

## **Restoring the Factory Default Configuration**

To restore the factory default values in the EEPROM, follow the directions in "Accessing the Boot Console Interface" earlier in this chapter, and then type the following at the prompt to access the Configuration Menu:

Main Menu: Enter command > co

When the Configuration Menu appears, type the following at the prompt:

Configuration Menu: Enter command > default

The process takes less than 30 seconds and messages similar to the following are displayed:

Initializing...

TEST 30CD

INIT 30CD

Configuration Menu: Enter command >

The factory default EEPROM settings are now restored.

The defaults are as follows:

OS_ID:	HP-UX
Fast Size:	0xF (all memory is tested)
Primary Path:	sescsi.6.0
Alternate Path:	sescsi.5.0
Console Path:	GRAPHICS(0) <i>or</i> PMC <i>n</i> where <i>n</i> is the lowest numbered device installed. If no graphics devices are installed this is set to SERIAL_1.
Keyboard Path:	PS2
Autoboot:	OFF
Autosearch	OFF
Autostart	ON

## **Displaying and Setting Paths**

A **path** is the hardware address of a device that is attached to the I/O system of your workstation. The **path** command sets the system paths shown in Table 3-1.

The **path** command sets and displays the hardware address of a specified device attached to the I/O bus of your workstation.

Path Type	Device
primary or pri	Your workstation's default boot device (usually the root disk)
alternate or alt	Your workstation's alternate boot device (usually a DDS- format tape device)
console or con	Your workstation's primary display device
<b>keyboard</b> or <b>key</b>	Your workstation's primary ASCII input device

#### Table 3-1 System Paths

To display the current settings for the system paths, type the following at the prompt:

Main Menu: Enter command > path

To obtain a full listing of currently supported boot device "mnemonic" paths, use the following command:

Main Menu: Enter command > pa prim?

To obtain a full listing of currently supported console "mnemonic" paths, use the following command:

Main Menu: Enter command > pa con?

# Configuration Displaying and Setting Paths

The paths are displayed in **Mnemonic Style Notation**, as shown in Table 3-2.

І/О Туре	Specification Format
Built-in SCSI	sescsi.scsi_address.logical_unit_number
Built-in LAN	lan.server_address.init_retries.io_retries <sup>1</sup>
PCI Slot	pcin
PMC Slot	pmcn
On-board Graphics	graphics(0)
PS/2 Keyboard	ps2
RS232(A)	serial_1.baudrate.wordlength.parity
RS232(B)	serial_2.baudrate.wordlength.parity
1. server_address is the	IP address of the host system
init_retries, default (0) =	= 3 retries, 255=nerver stop, 1-254=that exact number
<i>io_retries</i> , default (0) = ber	254 retries, 255=nerver stop, 1-254=that exact num-

 Table 3-2
 Mnemonic Style Notation

To display the current setting for a particular system path, follow the directions in "Accessing the Boot Console Interface" earlier in this chapter, and then type the following at the prompt:

Main Menu: Enter command > path path\_type

where *path\_type* is one of the path types listed in Table 3-1.

For example, to get the path to the primary boot device, follow the directions in "Accessing the Boot Console Interface" earlier in this chapter, and then type the following at the prompt:

Main Menu: Enter command > path primary

To set a system path to a new value, follow the directions in "Accessing the Boot Console Interface" earlier in this chapter, and then type the following at the prompt:

Main Menu: Enter command > path path\_type path

where *path\_type* is one of the path types listed in Table 3-1 and *path* is the specification of the path in Mnemonic Style Notation (as described in Table 3-2). For example, to set the primary boot path to a SCSI disk with an ID of 6.0, follow the directions in "Accessing the Boot Console Interface" earlier in this chapter, and then type the following at the prompt:

Main Menu: Enter command > path pri sescsi.6.0

## **Displaying and Setting the Monitor Type**

Your system ships from the factory preset to use a monitor with a specific resolution and frequency. If you replace your workstation's monitor with a different type of monitor, you must reconfigure your workstation to support the new monitor.

### The Monitor Command

The **monitor** command lets you change your workstation's graphics configuration. This command is available in the Configuration Menu of the boot console interface.

To display the current graphics and console information, enter the following command:

Configuration Menu: Enter command > monitor

The correct usage for setting the graphics configuration is:

Configuration Menu: Enter command > monitor graphics\_path type

where valid graphics\_path parameters are:

graphics(0) - The on-board 8-plane graphics adapter.

pmc1 - Graphics adapter installed in PMC site 1.

pmc2 - Graphics adapter installed in PMC site 2.

pmc3 - Graphics adapter installed in PMC site 3.

pmc4 - Graphics adapter installed in PMC site 4.

and type is the numerical monitor type as shown with the monitor list command.

You can also use the **monitor** command to disable the onboard graphics if you plan to use only PMC graphics cards to drive displays. To disable the onboard graphics, enter the following command:

Configuration Menu: Enter command > monitor disable builtin

**NOTE:** If you disable the onboard graphics, and later need to use the onboard graphics as the console device, see "Using the Emergency Interactive Console Search" on page 21.

### **Displaying the Current Monitor Configuration**

To display the current monitor configuration for your system from the Configuration Menu of the boot console interface, follow the directions in "Accessing the Boot Console Interface" earlier in this chapter. Once you are in the Boot Console Interface Main Menu, type:

Main Menu: Enter command > configuration

This places you in the Configuration Menu. From here type:

Configuration Menu: Enter command > monitor

The screen displays a list of the current graphics adapters and their monitor types configured for your workstation.

MONITOR INFORMATION

Path	Slot	Head	HPA	Resolution	Freq	Туре	Class
GRAPHICS(0)	0	1	f8000000	1280x1024	72Hz	12	

Configuration Menu: Enter command >

In this example, only the built-in graphic adapter graphics(0) is configured. The monitor type for graphics(0) is set to type 12, which is a 1280 by 1024 monitor that uses a frequency of 72 Hz.

# Configuration **Displaying and Setting the Monitor Type**

### Setting the Monitor Type

You can set the monitor type for a graphics adapter from the configuration menu by entering the following:

Configuration Menu: Enter command > monitor graphics(0) tt - or -Configuration Menu: Enter command > monitor pmcn tt Where n is the number of the PMC site and tt is the monitor type.

where *n* is the number of the 1 we site and *n* is the monitor type.

To display a list of supported monitors, enter the following command;

Configuration Menu: Enter command > monitor list

A list of valid monitor types similar to the following is displayed;

MONITOR INFORMATION

Path	Slot	Head	Туре	Size	Freq	Class
GRAPHICS(0)	0	1	1	1280x1024	75Hz	VESA
*GRAPHICS(0)	0	1	2	1280x1024	75Hz	VESA, Double buffered
GRAPHICS(0)	0	1	3	1280x1024	75Hz	VESA, Greyscale
*GRAPHICS(0)	0	1	4	1280x1024	75Hz	VESA, Double Buffered,Greyscale
GRAPHICS(0)	0	1	5	1024x768	75Hz	VESA
GRAPHICS(0)	0	1	6	800x600	75Hz	VESA
GRAPHICS(0)	0	1	7	640x480	75Hz	VESA
*GRAPHICS(0)	0	1	8	1600x1200	75Hz	VESA
*GRAPHICS(0)	0	1	9	1600x1200	75Hz	VESA, Greyscale
*GRAPHICS(0)	0	1	10	1200x1600	75Hz	VESA
*GRAPHICS(0)	0	1	11	1200x1600	75Hz	VESA, Greyscale
GRAPHICS(0)	0	1	12	1280x1024	72Hz	
*GRAPHICS(0)	0	1	13	1280x1024	72Hz	Double buffered
GRAPHICS(0)	0	1	14	640x480	60Hz	
GRAPHICS(0)	0	1	15	us	er def	ined

Configuration Menu: Enter command >

\* These monitor types are not supported on the Model 745 built-in graphics.

# Configuration **Displaying and Setting the Monitor Type**

To set the monitor type for graphics(0) to monitor type 2 you would enter the following;

Configuration Menu: Enter command > monitor graphics(0) 2 This will take effect on the next reboot.

MONITOR INFORMATION

Path	Slot	Head	HPA	Resolution	Freq	Туре	Class
GRAPHICS(0)	0	1	£8000000	1280x1024	72Hz	2	

The boot console displays a message that tells you that your new monitor selection will take effect the next time you reboot your system.

The boot console also displays the new monitor information.

Trying to change the monitor type to a number not listed for that graphics device fails and gives you the following warning message:

Value of monitor type n out of range (n - nn)

### Configuration Displaying and Setting the Monitor Type

### Setting the Monitor Type at Power On

If you replace your workstation's monitor with a different monitor type, and do not set the workstation's graphics parameters by using the monitor command before doing so, you need to perform the following steps at power on:

If your keyboard connects to the PS/2 connector on your system, wait <u>2 sec</u>onds after the Num Lock light flashes near the end of the boot sequence, then press <u>Tab</u> to initiate the automatic monitor selection process.

The system cycles through all of the available monitor types one at a time. When you can see a message similar to the following clearly and legibly, select that monitor type by pressing **Enter**.

MONITOR INFORMATION

Path Slot Head Size Type Freq Class ----\_\_\_\_\_ \_\_\_\_\_ \_ \_ \_ \_ \_\_\_\_\_ GRAPHICS(0) 0 1 n nnnnxnnnn nnHz Press [RETURN] to select this monitor type (type n of n types).

NOTE:

If you are using a power saving monitor, the power LED will light when the monitor senses a valid video synch signal.

The system queries you to confirm your selection. Press  $\overline{\mathbf{Y}}$  to save this monitor type.

If you press any key other than  $\overline{\mathbf{Y}}$ , the following message is displayed:

Monitor type not saved.

At this point, the new monitor type is active, but not saved. Because you didn't save the monitor type, the next time you reboot the system, the original monitor type will be used.

Next, the following message is displayed:

To select a new Graphics Monitor Type press the <TAB> key now, otherwise EXIT by entering any other key (or will time out in 15 seconds)...

To restart the monitor selection process, press TAB.

### Using the Emergency Interactive Console Search

If the system console is set to a device that is not installed in the system, you can use the emergency interactive console search to set the console to one of the terminal devices that is currently connected.

Use the following procedure to set the console with the emergency interactive console search:

- 1 Make sure that the monitor(s) and/or terminal(s) are powered on.
- 2 Hold the Model 744 board computer's reset/abort switch in its **Abort** position, then turn on power to the chassis.
- 3 A message similar to the following is displayed on each monitor connected to a graphics device recognized by the system:

Where n is a single-digit number or a keyboard key.

When the message is displayed clear and undistorted on the monitor for your console device, enter the number or key that corresponds to the display device that you are selecting.

#### NOTE:

The message is displayed for sixty seconds before proceeding to the next monitor resolution.

If you are using a power saving monitor, the power LED will light when the monitor senses a valid video synch signal.

If this message is not displayed on your monitor, review the procedures in Chapter 1 and Chapter 2 to make sure that you correctly installed the option board.

If no keyboards are found the following message is displayed:

WARNING: No keyboard(s) found. Turn off system power, check keyboard connection(s) and repeat interactive console search.

#### Configuration Displaying and Setting the Monitor Type

To advance all graphics adapter monitors to the next resolution, press the  $\langle Tab \rangle$  key **one** time and wait five seconds for all monitor types to change. Do not hold down the  $\langle Tab \rangle$  key or press it multiple times as this will cause the monitor types to advance for each press of the  $\langle Tab \rangle$  key.

4 When the following message is displayed, press the <Esc> key to confirm selection of the device as the console:

Press the <Esc> key to confirm selection of GRAPHICS(s) as the CONSOLE.

This selection will timeout in 10 seconds if not confirmed.

NOTE:

The message is displayed for only ten seconds before console search is resumed. Press <Esc> as soon as possible after the message is displayed.

The following message is displayed on the selected display:

GRAPHICS(s) MONITOR INFORMATION Slot Model Type Resolution Freq Class \_\_\_\_ \_\_\_\_\_ \_ \_ \_ \_ \_\_\_\_\_ \_\_\_\_ \_\_\_\_ INTERNAL EG 1280 12 75Hz 0 1280x1024 Selected CONSOLE path is: GRAPHICS(s) Selected KEYBOARD path is: PS2

## **Displaying the Current Memory Configuration**

The **memory** command shows the memory configuration table.

To display the current memory configuration for your system, from the Information Menu of the boot console interface, follow the directions in "Accessing the Boot Console Interface" earlier in this chapter. Once you are in the Boot Console Interface Main Menu, type:

Main Menu: Enter command > information

This places you in the Information Menu. From here type:

Information Menu: Enter command > memory

The screen displays status and configuration information for the memory modules installed in your workstation.

### **Memory Information Example**

If a memory card failure is detected during power-on selftest, the following message is displayed on the console (after completing all selftests) and the autoboot/autosearch process is automatically stopped:

WARNING: One or more memory banks were not configured due to a SIMM size mismatch or a SIMM failure. For more details, use the MEMORY command in the INFORMATION menu.

*NOTE:* The above condition occurs only after the testing and successful configuration of at least one memory card.

# Configuration **Displaying the Current Memory Configuration**

The following listing is a sample memory configuration table when memory modules are properly installed and configured:

ME	MORY	INFORM	ATION
ME	MODY		
ME	MORI	SIAIUS	TABLE
Sl	ot	Size	Status
0		64MB	Configured
1		32MB	Configured
2		64MB	Configured
TOTAL		160MB	

If the power-on selftest detects a defective or damaged memory card, using the **memory** command (from the Information Menu prompt) displays the following information:

```
WARNING: One or more memory banks were not configured due
     to errors in the following SIMM(s).
 Physical Slot Error Type
   -----
 3
          SIMM hardware error
        Memory Card Stack
      +----+
 Slot 3 | Failed
      +----+
      +----+
 Slot 2
            64MB OK
      +----+
      +----+
 Slot 1
            32MB OK
      +----+
      +----+
 Slot 0
            64MB OK
      +----+
_____
Side view of Model 9000/744/165L Single Board Computer PCB.
SUGGESTION: If possible, turn off the computer and check to
     see if the memory card(s) are seated properly.
   Memory
   HVERSION
                   SVERSION
   -----
   0x0740
                   0x0900
```

### Displaying the Status of the System I/O

The **IO** command is available from the information menu. It lets you identify all built-in I/O devices and optional I/O devices installed in the option slots.

To use the IO command from the Information Menu of the boot console interface, type:

Information Menu: Enter command > IO Information about the built-in and optional I/O devices is displayed as shown in the following example:

Doth	Dogimal	Tr mo		Logation	INTED	CUTED	IODC	IODC
	Decimai	туре	_	LOCALION		SVER	vers	
8 8 8/16 8/16/0 8/16/1 SERIAL_1 SERIAL_1 SERIAL_1 SERIAL_1 8/16/8 8/20 EISA GRAPHICS(1 8/28 SERIAL_2 BPR 62 63	8 8 8/16/0 8/16/1 8/16/4 8/16/5 8/16/6 8/16/7 8/16/8 8/20/5 8/20/5 8/24 8/28/2 8/28/2 8/28/2 63	Bus Converter Bus Converter Bus Adapter Parallel Audio RS232 SE SCSI LAN Keyboard Mouse Bus Adapter Bus Adapter Bus Adapter INTERNAL_EG_1280 Bus Adapter RS232 BPR Native Processor Proc Dep Memory	_	built-in built-in built-in built-in built-in built-in built-in built-in built-in built-in built-in built-in built-in built-in	5040 5050 04b0 04b0 04b0 04b0 04b0 04b0 04b0 04b0 0110 0110 04b0 0110 04a0 04a0 04a0 04a0 04a0 04a0 04b1 0110 04b1 0110 04b1 0120 04b1 04b1 04b1 04b1 04b1 04b1 04b1 04b1 04b1 04b1 04b1 04b1 04b1 04b1 04b1 04b0 04a0 0440 0400 0400 0400 0400 0400 0400 0400 0400 0400 0400 0400	0000 0000 8100 7400 7b00 8200 8200 8400 8400 8400 8400 9000 8500 9300 8c00 8c00 8c00 0481 0900	0x00 0x00 0x00 0x00 0x00 0x00 0x02 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00	0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x0
EISA Card	3							
Path	Type	EISA I	D					
20/5/1 20/5/2 20/5/3 20/5/3 20/5/4 20/5/5 20/5/6 20/5/7 20/5/8	100VG AnyLAN Unknown EISA Smart 16/4 Ri PSI card Unknown EISA Unknown EISA Unknown EISA	adapter cardHWP199 card or empty slot ngnode cardMUG0002 HWP187 card or empty slot card or empty slot card or empty slot card or empty slot	0					
PCI Cards Slot 	Path	в	us 	Class				

Information Menu: Enter command >

I/O MODULE INFORMATION

## Setting the Auto Boot and Auto Search and Auto Start Flags

The **auto boot, auto search,** and **auto start** flags are variables stored in your workstation's nonvolatile memory. (Nonvolatile memory retains its contents even after power is turned off.) If you reset these flags to a new value, the change takes effect the next time you reboot the workstation.

The **auto boot** variable boots the operating system whenever your workstation is turned on.

To examine the state of auto boot and auto search, type the following at the prompt:

Configuration Menu: Enter command > auto

If **auto boot** is set to **on**, your workstation automatically attempts to boot the operating system when turned on. If **auto boot** is set to **off**, your workstation enters the boot administration mode of the boot console user interface.

The state of **auto search** determines how your workstation seeks a boot device during autoboot. If **auto search** is set to **on**, your workstation will search for other boot devices if the primary boot device is not available. If **auto search** is **off**, your workstation will default to the boot administration mode if it can't see the primary boot device.

To change the state of **auto boot** or **auto search**, enter either of the following commands at the prompt:

Configuration Menu: Enter command > auto boot state

Configuration Menu: Enter command > auto search state

where state is on or off.

#### Setting the Auto Boot and Auto Search and Auto Start Flags

Autosearch searches for devices in the following order: Primary Boot Path Alternate Boot Path Built-in Single-Ended SCSI Devices Built-in LAN bootp servers

## **Displaying and Setting the Security Mode**

The **SECure** flag is a variable stored in non-volatile memory. (Non-volatile memory retains its contents even after power is turned off.) If you reset this flag to a new value, the change takes effect the next time you reboot the board computer.

When the **SECure** flag is set to **on**, **autoboot** and **autosearch** are enabled and cannot be stopped. The system boots from the default boot paths regardless of user intervention.

To display the current setting for the SECure flag, enter the following command:

Configuration Menu: Enter command > secure

To set the **SECure** flag on or off, enter one of the following:

Configuration Menu: Enter command > secure on Configuration Menu: Enter command > secure off

## **Displaying and Setting the Fastboot Mode**

When **fastboot** is enabled (set to **on**), your workstation does a quick check of the memory and skips I/O interface testing during its power-on self tests. This enables your workstation to complete its boot process more quickly. The default factory setting is for **fastboot** to be disabled (**off**).

The **fastboot** mode allows your workstation to boot quickly by performing a less extensive check of the system's memory.

When **fastboot** is disabled (set to **off**), more extensive memory testing and I/O interface testing is performed during the selftests, causing the boot process to take longer.

If you are experiencing difficulty in booting your workstation, set **fastboot** to **off** and reboot the system. The more extensive testing may reveal the error condition.

To display the status of **fastboot**, type the following at the prompt:

Configuration Menu: Enter command > fastboot

To disable **fastboot**, type the following at the prompt:

Configuration Menu: Enter command > fastboot off

To enable **fastboot**, type the following at the prompt:

Configuration Menu: Enter command > fastboot on

**CAUTION:** If a graphics adapter is installed in the system, it must be selected as the console device. If additional graphics adapters are installed, Fastboot mode cannot be used.

## **Displaying the LAN Station Address**

It is sometimes necessary to supply the LAN station address of your workstation to other users. For example, if your workstation is to become a member of a cluster, the cluster administrator needs to know your LAN station address in order to add your workstation to the cluster.

A **LAN station address** of your workstation is the label that uniquely identifies the LAN connection for your workstation at the **link level** (the hardware level).

To display your workstation's LAN station addresses, type the following at the prompt:

Information Menu: Enter command > lanaddress

The LAN station address is displayed as a twelve-digit number in hexadecimal notation, similar to the following:

LAN Station Addresses: 0060b0-789abc

The address is for the system's built-in LAN.

## **Displaying System Information**

The **all** command allows you to display the system's processor revision and speed, cache size, memory size, flag settings, and the boot and console paths. To display system information from the Information Menu, type the following at the prompt:

Information Menu: Enter command > all

This information is paged to allow you to view it as necessary.

# Configuration **Displaying PIM Information**

## **Displaying PIM Information**

The **pim** command allows you to display the most recent PIM information for the specified fault type. To display PIM information for a specific fault, type the following at the Service Menu prompt:

Service Menu: Enter command > **pim** processor\_number

You can use **pim** in the following ways:

pim - Gives all fault types

pim 0 - Gives HPMC information on the processor

pim 0 fault\_type -Provides fault type information on the processor. Where fault\_type is HPMC, LPMC, or TOC

## **Power Budgeting**

The power supply accomodates the needs of all devices and options available for the Model 745 (within specifications for the options and applicable interface specifications). No power budgeting is required.

Configuration
Power Budgeting

## Troubleshooting

This chapter provides information about isolating a failing/failed component in a Model 744 board computer through the use of diagnostic tests and troubleshooting techniques. A failed component is traced to the level of the Field Replaceable Unit (FRU) and the FRU is replaced to correct a problem.

## Troubleshooting **Dealing with a Boot Failure**

## **Dealing with a Boot Failure**

To start this workstation from an operating system stored on a device different from the usual boot device, to boot from a different disk, or to boot from another type of device (such as a DDS tape drive), see the following situations and examples that use the Boot Console Interface. To access the Boot Console Interface, see Chapter3 of this book.

• To boot from a known device containing a bootable operating system, type the following at the prompt:

Main Menu: Enter command > boot <device>

where *device* is the **hardware path** to the device, specified in Mnemonic Style Notation.

For example, to boot an operating system stored on a DDS-format tape in a drive located at "scsi.1.0," go to the Main Menu of the Boot Console Interface and then type the following command at the prompt:

Main Menu: Enter command >boot scsi.1.0

The operating system on the specified device is used to start the workstation.

• To interact with the Initial System Loader (ISL) before booting the workstation, type the following at the prompt:

Main Menu: Enter command >boot <device>

You are prompted:

Interact with IPL (Y, N, Q)?>
Answering yes  $(\mathbf{y})$  causes the ISL to be loaded from the specified device. After a short time, the following prompt appears on the screen:

ISL>

ISL is the program that actually controls the loading of the operating system. By interacting with ISL, you can choose to load an alternate version of the HP-UX operating system.

For example, in HP-UX, if the usual kernel (/**stand/vmunix**) on the root disk (**fwscsi.6.0**) has become corrupted, boot the workstation from the backup kernel (/**stand/vmunix.prev**) by typing the following at the ISL> prompt:

### ISL> hpux /stand/vmunix.prev

• To find the location of the bootable operating systems on the various media in the file system, use the search command.

# Troubleshooting **Dealing with a Boot Failure**

# Searching for Bootable Media

To list all devices that may contain bootable media, go to the Main Menu of the Boot Console Interface and then type the following at the prompt:

Main Menu: Enter command > search ipl

The search may turn up more devices than there are lines on the display. If using a text terminal, control the progress of the search from the terminal's keyboard by performing the following commands:

- To hold the display temporarily, press  $\overline{Ctrl}$   $\overline{S}$
- To continue the display, press  $\overline{\mathbf{Ctrl}} \ \overline{\mathbf{Q}}$
- To halt the search, press any key.

These flow-control commands do not work with a bitmapped display, but such a display can show more than forty lines of text, so they are unnecessary.

To search for devices of *just one type* that actually contain bootable media, go to the Main Menu of the Boot Console Interface and then type the following at the prompt:

Main Menu: Enter command > search ipl device\_type

where *device\_type* is one of the following:

gscn is an optional FW SCSI adapter in GSC slot 1 or 2

sescsi is the built-in single-ended SCSI bus

lan is the built-in network adapter

bpn is the VME backplane networking

bpr is the VME backplane boot ROM

ata(0) is the optional PCMCIA adapter (HP-RT only)

# **Stable Storage**

Stable Storage is non-volatile memory associated with each PA-RISC processor module. Stable storage is used by the processor (CPU) to store device path information, the state of the boot flags, HPMC error information, and operating system initialization data.

# **Boot Command Notations**

The **boot** command supports the following two notations:

- Mnemonic
- Path number

Type help path or help boot for more information on the boot path parameters.

Here are examples of mnemonic notation:

- **boot** with "no parameters" selects the primary boot path in stable storage.
- **boot** with the **alternate** or **alt** parameter selects the alternate boot path in stable storage.

Here is an example of path number notation:

**boot p1** attempts to boot from the second path indicated by the **search** command.

# Troubleshooting **Dealing with a Boot Failure**

# **ISL Environment**

ISL provides the means to load the operating system. ISL also provides an offline platform to execute diagnostic and utility programs contained in the LIF volume on the boot device when the operating system is not loaded.

The ISL program is the first program loaded into main memory from an external media (LAN, disk, or tape) and launched by the initial program loader (IPL) routine from the Boot Administration environment.

The ISL environment provides the following capabilities:

- Execute user-entered commands to modify boot device paths and boot options in stable storage.
- Run offline diagnostic programs, as described later in this chapter.
- Provide automatic booting of the operating system after power-on or reset.

# **Firmware Selftest Failures**

Two methods are used by the firmware to provide diagnostic information: the LEDs on the board computer's front panel and ASCII encoded chassis codes which are output through the RS-232 (A) port.

## **Interpreting the Front Panel LEDs**

The Model 744 provides two LEDs, located to the left and right of the reset switch, as shown in Figure 4-1. The red LED is labeled SYSFAIL and the green LED is labeled POWER.



Figure 4-1 Model 744 LED Location

Table 4-1 provides information on interpreting the system status from the LEDs.

SYSFAIL (Red)	POWER (Green)	Meaning	Possible Solution
Off	Off	No Power	Check for board seating in chassis.
On	2Hz Flash	Normal Power-on/ selftest	If the system never proceeds past this point, either the con- sole path is not set or there is a critical CPU failure.
			Refer to "Using the Emer- gency Interactive Console Search" in Chapter 3 to set the console path. If this fails, replace the system board.
On	Off	Memory Failure	Troubleshoot for failed RAM card or problem with the RAM connection.
On	1 Flash/ second	CPU (board) Failure	Replace the system board.
On	4 Flash/ second	No console identified	Check the console search path and keyboard connections. If no problem is found, replace the system board.
On	On	OS is booted with VME services failure	Check the Operating System VME services. Check that VME services is configured in the kernel.
Off	On	OS is booted with VME services OK	

### Table 4-1 LED Indicators

# Interpreting the Diagnostic Chassis Codes

The chassis codes convey the state of the system. Each chassis code consists of two fields, the general operating state of the system and a four-digit hexadecimal (hex) status code indicating the specific system hardware or software component as follows:

xxxx nnnn

Where *xxxx* is an ASCII string indicating the operating state, and *nnnn* is the hexadecimal status code.

For example, in the chassis code TEST 3000, TEST is the operating state, and 3000 is the hexadecimal status code.

Table 4-2 lists the five possible operating states that can be reported.

State	Description
FLT	A critical hardware fault which will result in a system halt.
INIT	A hardware or software component being initialized.
SHUT	The system is shutting down.
TEST	A hardware component is being tested.
WARN	A non-critical warning.

#### Table 4-2 Chassis Code Operating States

Under normal operating conditions the operating states of the displayed chassis codes are INIT and TEST.

In cases of a critical hardware component failure, the operating state displayed is FLT.

In cases when an optional component is not found or configuration information is incorrect, the displayed operating state is WARN. The WARN operating state is a noncritical condition, but the condition of the indicated component should be verified.

During the system shutdown process, the displayed state is SHUT.

The following table provides information on interpreting the diagnostic chassis codes to troubleshoot the system to the FRU (Field Replaceable Unit) level.

Chassis Code Range	FRU	Description	Possible Solution
1001-101F	Unknown	Unexpected Interrupt	Note what chassis codes pre- cede this fault condition, then remove or replace the component indicated by the preceding chassis codes. This condition is generally due to memory corruption.
1030		Start of early self-test phase	
1031		Early self-test phase skipped. (Fastboot enabled)	
103C	744 SBC <sup>a</sup>	Initializing CPU	
103E		Early self-tests com- pleted	
1040-1099	744 SBC <sup>a</sup>	CPU self-tests	Replace the single board computer.
10A0-10AE	744 SBC <sup>a</sup>	Floating-point co-pro- cessor self-tests	Replace the single board computer.
10AF	744 SBC <sup>a</sup>	Floating-point co-pro- cessor disabled	
10B0-10BF	744 SBC <sup>a</sup>	TLB init and self-test	Replace the single board computer.
10C0-10DF	744 SBC <sup>a</sup>	PDH status informa- tion	Replace the single board computer.
10EF		Self-test returned a warning	

Table 4-3 Chassis Codes

Chassis Code Range	FRU	Description	Possible Solution
10FF	744 SBC <sup>a</sup>	Self-test failure	Replace the single board computer.
2000-20FF	744 SBC <sup>a</sup>	CPU built-in level-1 cache self-tests and init	Replace the single board computer.
300030FF	744 SBC <sup>a</sup>	PDH self-test, init, and fault conditions	Replace the single board computer.
4000		Start of late self-tests	
4001		Late self-test phase skipped. (Fastboot enabled)	
400E		Late self-tests com- pleted	
4010-406F	744 SBC <sup>a</sup>	Cache late self-tests	Replace the single board computer.
4070-4071	744 SBC <sup>a</sup>	CPU super-scalar self- tests	Replace the single board computer.
5000	Unknown	Unknown bus error	

### Table 4-3 Chassis Codes

Chassis Code Range	FRU	Description	Possible Solution
503F		HPMC due to bus error	
504F		Processor memory access exceeded bounds of configured memory space	These conditions result in an HPMC. Refer to the section
505F	Unknown	Processor I/O access timed out	"Dealing with HPMC (Uncorrectable Error)" later
506F		DMA guest detected data parity error on GSC bus	in this chapter.
507F		Processor detected data parity error on GSC bus	
7000-7FFF	Memory Modules	Memory init, self-test, and fault codes	Refer to the section "Deter- mining the Faulty Memory Card" later in this chapter.
80F3	Various	Could not get IODC bytes for current mod- ule	
80F4	Various	Could not get ENTRY_INIT proce- dure for current mod- ule	Confirm that the paths are set correctly, cables are cor- rectly connected, and power is turned on to external
80F5	Various	ENTRY_INIT proce- dure for the current module returned a fail- ure status	devices.
80F6	Various	Could not get ENTRY_IO procedure for current module	

Table 4-3 Chassis Codes

Chassis Code Range	FRU	Description	Possible Solution
80F7	Various	ENTRY_IO procedure for the current module returned a failure status	
80F8	Various	Device class for cur- rent boot device is invalid	Confirm that the paths are set correctly, cables are cor- rectly connected, and power
80F9	Various	Could not get ENTRY_TEST proce- dure for current mod- ule	is turned on to external devices.
80FA	Various	ENTRY_TEST proce- dure for the current module returned a fail- ure status	1
8414		Testing RS232C port A	
8415	744 SBC <sup>a</sup>	Testing SCSI control- ler	
8416		Testing LAN controller	
8417		Testing PS/2 keyboard controller	
84FF		Core I/O adapter not found	Replace the single board computer.
8FFF		Late self-test failure	

### Table 4-3 Chassis Codes

Chassis Code Range	FRU	Description	Possible Solution
9000	Various	Device specified by console path not found	
9001	Various	Could not find a con- sole device	
A008	Various	Could not locate a boot device	Confirm that the paths are set correctly, cables are cor-
A00F	Various	Could not get path for current module	rectly connected, and power is turned on to external devices.
A088	Various	Unable to boot, no con- sole	
A0BD	Various	ENTRY_INIT returned <i>device not ready</i> status	
A50F	Various	Failed to init boot device specified by pri- mary path	
A70F	Various	Failed to init alternate boot device	
C200		Starting memory con- figuration	
C201	Memory	Starting destructive memory test	
C202	. Wentery	Starting non-destruc- tive memory test	
C2E0		Memory config and self-test complete	
C300	744 SBC <sup>a</sup>	CPU is executing early selftests	
C3FF	744 SBC <sup>a</sup>	CPU is executing late selftests	

 Table 4-3 Chassis Codes

Chassis Code Range	FRU	Description	Possible Solution
C400		Retrieving the Stable Store console path	
C440		Initializing the Stable Store console path	
C500		Retrieving the primary boot path	
C540		Initializing the pri- mary boot path	
C580		Loading IPL from the primary boot path	
C5F0		An error occurred read- ing IPL from primary boot device	
C5F1		LIF address is zero or not 2K byte aligned on primary boot device	File system may be corrupt on boot device. Try booting from alternate boot device. Replace or repair boot device.
C5F2		LIF file not present on media on primary boot device	
C5F3		LIF file is zero, not a multiple of 2K bytes, or is greater than 256KB on primary boot device	File system may be corrupt on boot device. Try booting
C5F4		LIF entry point not word aligned or >= size of LIF file on primary boot device	Replace or repair boot device.
C5F8		IPL checksum error on primary boot device	

Chassis Code Range	FRU	Description	Possible Solution
C5FF		Branching to IPL from the primary boot device	
C600		Retrieving default con- sole path	
C640		Initialize default con- sole path	
C641		Initializing current graphics device	
C64F		Retrying bad monitor type	
C650-C652		Initializing graphics device 0, 1, or 2	
C740		Initializing alternate boot path	
C780		Loading IPL from alternate boot device	

Chassis Code Range	FRU	Description	Possible Solution
C7F0		An error occurred read- ing IPL from alternate boot device	
C7F1		LIF address is zero or not 2K byte aligned on alternate boot device	
C7F2		LIF file not present on alternate boot device	File system may be corrupt
C7F3		LIF file is zero, not a multiple of 2K bytes, or is greater than 256KB on alternate boot device	on boot device. Try booting from alternate boot device. Replace or repair boot device.
C7F4		LIF entry point not word aligned or >= size of LIF file on alternate boot device	
C7F8		IPL checksum error on alternate boot device	
C7FF		Branching to IPL loaded from alternate boot device	
CB00		TOC handling initiated	
CB01		No OS_TOC vector	
CB02		Invalid OS_TOC vec- tor	
CB03		Invalid OS_TOC code	
CB04		Invalid OS_TOC code length	

### Table 4-3 Chassis Codes

 Table 4-3 Chassis Codes

Chassis Code Range	FRU	Description	Possible Solution
CB05		Invalid checksum for OS_TOC code	
CB0A		Previous TOC PIM logged	
CB0B		Branching to OS_TOC handler	
CB0C		Branch to OS_TOC failed	
CB9A		HPMC PIM overwrit- ten	
CBF0		HPMC handling initi- ated	
CBF1		OS did not replace PDC IVA	Pofer to the section Dealing
CBF2		Invalid length for OS_HPMC code	with HPMC (Uncorrectable Error) later in this chapter.
CBF3		Invalid address for OS_HPMC code	
CBF4		Invalid checksum for OS_HPMC code	
CBF5		IVA + 32 = 0	
CBFA		Previous HPMC PIM logged	

Table 4-3	Chassis	Codes
-----------	---------	-------

Chassis Code Range	FRU	Description	Possible Solution
CBFB		Branching to the OS HPMC handler	
CBFC		Failed branch to the OS HPMC handler	Refer to the section Dealing
CBFE		HPMC interrupted a TOC	with HPMC (Uncorrectable Error) later in this chapter.
CBFF		Nested HPMC occurred	
CD00		Beginning initializa- tion of the I/O sub- system	
CD10-CD17		Initializing GSC slots 1 through 8	
CD18		Initializing the VME ASIC	
CD1A-CD1D		Initializing graphics devices	
CD1E		Initializing EISA sub- system	
CD1F		Initializing core I/O ASIC	
CDE0		EISA subsystem ini- tialization complete	
CDEA		Initializing EISA sub- system	
CDEF		EISA subsystem not found	Reseat the EISA tray in the chassis. If this message still occurs, replace the EISA tray.

#### Table 4-3 Chassis Codes

Chassis Code Range	FRU	Description	Possible Solution
CDFF		System map initializa- tion complete	

a. SBC (Single Board Computer)

To get additional information about failures, from the boot console interface, use the **pim** and **Chassis Code** commands from the Service Menu.

# **Running ODE-Based Diagnostics**

The Offline Diagnostic Environment (ODE) consists of diagnostic modules for testing and verifying system operation. ODE provides all the necessary functions for the user to load specified tests and interact with those tests.

ODE is an ISL utility. To boot ODE:

- 1 Invoke the ISL environment from the system disk.
- 2 Type ode after the ISL> prompt to invoke ODE from the LIF directory on the system disk. The prompt changes to ODE>.

Not all of the test modules are available on all systems. To see what test modules are available to run on this system, type ls at the ODE> prompt. The available modules include the following:

- **lasidiag** tests and verifies the core-I/O functionality within the I/O ASIC chip. The diagnostics test the SCSI interface, LAN interface logic, parallel interface, audio, RS-232, PS/2 keyboard and mouse interface, real time clock, and the PC floppy interface and drive.
- **memtest** tests and verifies the memory arrays. If an error is detected, the diagnostic reports the memory card that needs replacement and its slot number. Memtest also provides a map of the memory configuration so that the user can identify the type of memory and its slot location.
- **update** updates the system's Processor Dependent Code (PDC) firmware on the EEPROM.

## Troubleshooting Running ODE-Based Diagnostics

• **mapper** - identifies the configuration of HPPA systems. It displays path, identification, and revision information of I/O components, configuration of memory controllers, processors, co-processors, cache, and TLB, as well as processor board component revisions and values of various HPPA system identifiers, revisions, and capabilities.

For further information on the various ODE commands and a complete listing of the command set, type **help** at the ODE> prompt or at the prompt of one of the test modules.

# **Running System Verification Tests**

HP-UX uses an online diagnostics product called the Support Tools Manager that allows system operation verification. HP-RT does not support online diagnostics.

Three interfaces are available with the Support Tools Manager: a command line interface (accessed through the **cstm** command), a menu-driven interface (accessed through the **mstm** command), and the graphical user interface (accessed through the **xstm** command).

For more information on these user interfaces see the online man pages by entering the following at an hpterm command line prompt:

\$ man cstm
\$ man mstm

### \$ man xstm

For information on the enhanced online diagnostics, see the *Precision Architecture RISC HP 9000 Series 700 Diagnostics Manual.* 

# Troubleshooting Running System Verification Tests

To access the Support Tools Manager, you must be logged in as "root" or "superuser", and perform the following steps:

1 In a terminal window, type the following at the # prompt to invoke the command line interface:

### # cstm

2 The following message appears:

Support Tool Manager Version A.01.00 Type 'help' for a list of available commands: CSTM>

3 To verify the system operation, type the following at the CSTM> prompt:

### CSTM> verify all

Messages similar to the following appear:

Verification has started on device (CPU). Verification has started on device (FPU). CSTM>Verification of (FPU) has completed. CSTM>Verification of (CPU) has completed.

- 4 Press Enter to return to the CTSM> after all test results are reported.
- 5 To exit the Support Tools Manager, enter the following:

### CTSM> exit

If any tests failed, run Self Test and ISL diagnostics to isolate the problem.

# Dealing with HPMC (Uncorrectable Error)

The power-on sequence follows this path:

Power-on -> Selftest -> Console Path -> Boot Admin Mode -> Boot Path -> ISL Mode -> Operating System Mode

When the hardware detects an unrecoverable (HPMC) error in the Operating System environment, an error message, referred to as a Kernel Tombstone is displayed on the monitor. The state of the system is written to main memory and the entire contents of main memory is dumped (written) to the swap area on the system disk.

HPMC error information is logged into Stable Storage; this information is referred to as PIM (Processor Internal Memory). The HPMC error information is available from the Boot Administration environment using the **PIM** command at the **service** menu.

To identify the failed FRU(s) after an HPMC, follow these steps:

- 1 Examine the first line of the data returned from the PIM command to display the latest error information from the last TOC, LPMC, or HPMC interruption detected.
- **2** Compare the values from the PIM command with those shown in Table 4-4 and take the appropriate action.

Check Type Word	Cache Check Word	Bus Check Word	System Responder Word	Action
0x80000000	0x40000000	N/A	N/A	Replace CPU board
0x20000000	N/A	0x00210003	0x00000000 0xEFFFFFF	Refer to Determin- ing the Faulty Memory Card, later in this chapter.
0x20000000	N/A	0x00310007	0xF0000000 0xF01FFFFF	Replace CPU board.
0x20000000	N/A	0x00310007	0xF0200000 0xF0207FFF	Replace EISA tray, if present, or replace CPU board.

Table 4-4 PIM Action Table

Check Type Word	Cache Check Word	Bus Check Word	System Responder Word	Action
0x20000000	N/A	0x00310007	0xF0280000 0xF029FFFF	Replace PCMCIA adapter. If problem persists replace CPU board.
0x20000000	N/A	0x00310007	0xF0300000 0xF031FFFF	Replace CPU board.
0x20000000	N/A	0x00310007	0xF0400000 0xF3FFFFFF	Check VME sys- tem configuration and/or replace CPU board.
0x20000000	N/A	0x00310007	0xF4000000 0xF5FFFFFF	Replace Graphics in GSC Slot 2, if present, otherwise check VME cards, and/or replace CPU board.
0x20000000	N/A	0x00310007	0xF6000000 0xF7FFFFFF	Check VME sys- tem configuration and/or replace CPU board.
0x20000000	N/A	0x00310007	0xF8000000 0xF9FFFFFF	Replace Graphics in GSC Slot 1, if present, otherwise check VME cards, and/or replace CPU board.
0x20000000	N/A	0x00310007	0xFA000000 0xFBFFFFFF	Check VME sys- tem configuration and/or replace CPU board.

 Table 4-4
 PIM Action Table

Check Type Word	Cache Check Word	Bus Check Word	System Responder Word	Action
0x20000000	N/A	0x00310007	0xFC000000 0xFFBFFFFF	Replace EISA tray, if present, otherwise check VME system configuration, and/ or replace CPU board.
0x20000000	N/A	0x00310007	0xFFC00000 0xFFD1FFFF	Replace CPU board
0x20000000	N/A	0x00310007	0xFFF80000 0xFFF83FFF	Replace optional GSC card in GSC Slot 1, if present, or replace CPU board.
0x20000000	N/A	0x00310007	0xFFF88000 0xFFF8BFFF	Replace optional GSC card in GSC Slot 2, if present, or replace CPU board.
0x20000000	N/A	0x00310007	0xFFF8C000F 0xFFFFFFFF	Replace CPU board

 Table 4-4
 PIM Action Table

# HPMC Caused by a Data Cache Parity Error

For example, an HPMC interruption is forced when a data cache parity error is detected during a load instruction to the memory address space or during a data cache flush operation.

Table 4-5 shows an example of the HPMC error information retrieved from Stable Storage by the PIM command from the Boot Administration environment.

Word	Value
Check Type	0x8000000
CPU State	0x9e000004
Cache Check	0x40000000
TLB Check	0x00000000
Bus Check	0x00000000
Assists Check	0x00000000
Assists State	0x00000000
System Responder Address	0x00000000
System Requester Address	0x00000000
System Controller Status	0x00000nnn

Table 4-5 Processor Module Error (Data Cache Parity)

The value in the CPU State word indicates that register values and addresses stored in Stable Storage at the time of the HPMC were saved.

The value of the Cache Check word identifies that logic in the processor module detected a (data) cache parity error. Ignore the value in the System Controller Status word.

# HPMC Caused by a Multi-Bit Memory Parity Error

An HPMC interruption is forced when a multi-bit memory parity error is detected during a "DMA read" operation or fetching an I/D cache line (32 bytes).

Table 4-6 shows an example of the HPMC error information retrieved from Stable Storage by the PIM command during the Boot Administration environment.

Word	Value
Check Type	0x20000000
CPU State	0x9e000004
Cache Check	0x00000000
TLB check	0x0000000
Bus Check	0x00210004
Assists Check	0x0000000
Assists State	0x0000000
System Responder Address	Oxnnnnnnn
System Requester Address	0x0000000
System Controller Status	0x00000nnn

Table 4-6 Multi-Bit Memory Parity Error

### **Interpreting the Table**

The values in the Bus Check and System Responder Address words indicate that a multibit memory parity error was detected by logic in the memory module. Ignore the value in the System Controller Status word.

The System Responder contains the hexadecimal address of the faulty memory location. Read the following section, Determining the Faulty Memory Card, to determine which memory card contains the faulty memory location.

# **Determining the Faulty Memory Card**

Memory is configured in a contiguous fashion starting at a base hexadecimal address of 0x00000000 to a maximum of 0x3FFFFFFF (1024MB).

Memory is installed on the Model 744 in a single stack of up to four memory cards of 16MB, 32MB, 64MB, 128MB or 256MB capacity. The card on the bottom of the stack, or closest to the system board, is considered to be in physical slot 0, the second board in the stack is physical slot 1, the third card is physical slot 2, and the fourth card in the stack is physical slot 3, as shown in Figure 4-2.

**NOTE:** When mixing memory cards of different capacities, 128MB and 256MB cards must always be in the lowest numbered physical slots.



Figure 4-2 Physical Memory Slots

During the boot process, when the system sizes the memory to create a memory map, the memory slots are divided into eight logical slots. For better understanding, they will be referred to from herein as logical slots 0 through 7.

The system maps two logical slots to each physical slot as shown in Table 4-7. Notice that the logical slots are not sequential.

Logical Slot 6	Physical
Logical Slot 7	5101.5
Logical Slot 5	Physical
Logical Slot 4	S10t 2
Logical Slot 3	Physical
Logical Slot 3 Logical Slot 1	Physical Slot 1
Logical Slot 3 Logical Slot 1 Logical Slot 2	Physical Slot 1 Physical

### Table 4-7 Logical Memory Slots

When sizing memory, the system first looks for 256MB memory cards. It starts mapping address ranges with the 256MB memory card in the lowest numbered slot first, then the 128MB cards in the next highest slots in order.

Each 256MB, 128 MB, 64MB or 16MB card is mapped to the bottom one of the two logical slots for its physical slot. As shown in Table 4-7, a 128 MB, 64MB or 16MB card is mapped to logical slot 0, 1, 4, or 7. For example, a 128 MB, 64MB or 16MB card in physical slot 3, is mapped to logical slot 7.

The 32MB cards are mapped as two segments of 16MB. One for each logical slot associated with the cards physical slot. For example, a 32MB card installed in physical slot 0 has 16MB mapped to logical slot 0 and 16MB mapped to logical slot 2.

As you can see from Table 4-7, the logical slot numbering does not progress in a numerical order from physical slot 0 to physical slot 3. Because of this, a 32MB card may not have both of its 16MB segments mapped contiguously.

After the 256MB cards are sized, the 128 and 64MB cards are sized in a similar manner. Then the sizing progresses to the 16MB segment of memory in the lowest numbered logical slot, then the 16MB segment in the next highest numbered logical slot, and so on, until all of the memory has been mapped.

For example; suppose you have four memory cards installed as shown in Table 4-8.

32 MB	Logical Slot 6 (16MB)	Physical
Card	Logical Slot 7 (16MB)	Slot 3
	Logical Slot 5	Physical
64 MB Card	Logical Slot 4 (64MB)	Slot 2
	Logical Slot 3	Physical
16 MB Card	Logical Slot 1 (16MB)	Slot 1
256 MB or	Logical Slot 2	Physical
128 MB Card	Logical Slot 0 (128MB or 256MB)	Slot U

### Table 4-8 Memory Configuration Example

The memory is mapped in the following order:

- 256 MB or 128MB Card in Physical Slot 0 (Logical Slot 0)
- 64MB Card in Physical Slot 2 (Logical Slot 4)
- 16MB Card in Physical Slot 1 (Logical Slot 1)
- 16MB of the 32MB Card in Physical Slot 3 (Logical Slot 6)
- 16MB of the 32MB Card in Physical Slot 3 (Logical Slot 7)

A worksheet is needed to determine the address ranges associated with each of the logical slots. In the example in Figure 4-3 below, the memory configuration example shown in Table 4-8 has been used.

In this example, we first determine the memory cards that are installed in each physical slot.

Next, we circle the corresponding memory card capacity in the second column. Note that we circled two 16's for each 32MB memory card.

We now look for the 128MB memory card that is associated with the lowest numbered logical slot. In our example, the 128MB card in physical slot 0, logical slot 0 is the first and only 128MB card.

Using Table 4-9, we write the hexadecimal address range for 0 to 128MB in the first column.

Next we look for the 64MB segment of memory in the lowest numbered slot. In our example, that is the 64MB segment in logical slot 4.

Then we look for the 16MB segment of memory in the lowest numbered slot. In our example, that is the 16MB segment in logical slot 1, which is the 16MB memory card in physical slot 1.

Using Table 4-9, we write the hexadecimal address range for 192MB to 208MB in the first column of our worksheet.

We continue this for each logical slot in numerical order, skipping the slots that do not have any memory.

Memory Address Range	Memory Card Capacity (MB)	Logical Slot	Physical Slot
0x0D000000 - 0x0DFFFFFF	32 (16)	6	3
0x0E000000 - 0x0EFFFFF	<u>(16)</u> 16 64 128	7	
	32 16	5	2
0x08000000 - 0x0BFFFFF	16 16 64 128	4	2
	32	3	1
0x0C000000 - 0x0CFFFFFF	16 (16) 64 128	1	
	32	2	0
0x00000000 - 0x07FFFFF	16 16 64 (28	0	

Figure 4-3 Example Memory Address Worksheet

Perform the following steps to fill out the worksheet:

- 1 Determine the memory capacity of each memory card in the **physical** slots and circle the corresponding number in the second column of Figure 4-4. For 32MB cards, circle a 16 for each of the two logical slots associated with the physical slot.
- 2 Use Table 4-9 to look up the memory address ranges of each segment of memory associated with the **logical** slots. Remember to use the following rules:
  - a Find the 128MB card with the lowest numbered logical slot first.
  - **b** Find 128MB cards with the next highest numbered **logical** slots next.
  - c Find the 64MB card with the lowest numbered logical slot next.
  - d Find 64MB cards with the next highest numbered logical slots next.
  - e Find the 16MB memory segment with the lowest numbered logical slot next.
  - f Find the rest of the 16MB memory segments in numerical order of the logical slots.Skip any logical slots that are empty.

Memory Address Range	Memory Card Capacity (MB)	Logical Slot	Physical Slot
	32	6	3
	16 16 64 128	7	
	32 16	5	2
	16 16 64 128	4	2
	32 16	3	1
	16 16 64 128	1	
	32 16	2	0
	16 16 64 128	0	Ū

Figure 4-4 Memory Address Worksheet

Memory Range	Address Range	Memory Range	Address Range	
0 - 16	0x00000000 - 0x00FFFFF	512 - 528	0x20000000 - 0x20FFFFFF	
16 - 32	0x01000000 - 0x01FFFFFF	528 - 544	0x21000000 - 0x21FFFFFF	
32 - 48	0x02000000 - 0x02FFFFF	544 - 560	0x22000000 - 0x22FFFFFF	
48 - 64	0x03000000 - 0x03FFFFF	560 - 576	0x23000000 - 0x23FFFFFF	
64 - 80	0x04000000 - 0x04FFFFF	576 - 592	0x24000000 - 0x24FFFFFF	
80 - 96	0x05000000 - 0x05FFFFFF	592 - 608	0x25000000 - 0x25FFFFFF	
96 - 112	0x06000000 - 0x06FFFFF	608 - 624	0x26000000 - 0x26FFFFFF	
112 - 128	0x07000000 - 0x07FFFFFF	624 - 640	0x27000000 - 0x27FFFFFF	
128 - 144	0x08000000 - 0x08FFFFFF	640 - 656	0x28000000 - 0x28FFFFFF	
144 - 160	0x09000000 - 0x09FFFFF	656 - 672	0x29000000 - 0x29FFFFFF	
160 - 176	0x0A000000 - 0x0AFFFFF	672 - 688	0x2A000000 - 0x2AFFFFF	
176 - 192	0x0B000000 - 0x0BFFFFFF	688 - 704	0x2B000000 - 0x2BFFFFFF	
192 - 208	0x0C000000 - 0x0CFFFFF	704 - 720	0x2C000000 - 0x2CFFFFFF	
208 - 224	0x0D000000 - 0x0DFFFFF	720 - 736	0x2D000000 - 0x2DFFFFFF	
224 - 240	0x0E000000 - 0x0EFFFFF	736 - 752	0x2E000000 - 0x2EFFFFFF	
240 - 256	0x0F000000 - 0x0FFFFFFF	752 - 768	0x2F000000 - 0x2FFFFFFF	
256 - 272	0x10000000 - 0x10FFFFFF	768 - 784	0x30000000 - 0x30FFFFFF	
272 - 288	0x11000000 - 0x11FFFFFF	784 - 800	0x31000000 - 0x31FFFFFF	
288 - 304	0x12000000 - 0x12FFFFFF	800 - 816	0x32000000 - 0x32FFFFFF	
304 - 320	0x13000000 - 0x13FFFFFF	816 - 832	0x33000000 - 0x33FFFFFF	
320 - 336	0x14000000 - 0x14FFFFF	832 - 848	0x34000000 - 0x34FFFFFF	
336 - 352	0x15000000 - 0x15FFFFFF	848 - 864	0x35000000 - 0x35FFFFFF	
352 - 368	0x16000000 - 0x16FFFFF	864 - 880	0x36000000 - 0x36FFFFF	
368 - 384	0x17000000 - 0x17FFFFFF	880 - 896	0x37000000 - 0x37FFFFFF	
384 - 400	0x18000000 - 0x18FFFFFF	896 - 912	0x38000000 - 0x38FFFFFF	
400 - 416	0x19000000 - 0x19FFFFF	912 - 928	0x39000000 - 0x39FFFFFF	
416 - 432	0x1A000000 - 0x1AFFFFF	928 - 944	0x3A000000 - 0x3AFFFFF	
432 - 448	0x1B000000 - 0x1BFFFFFF	944 - 960	0x3B000000 - 0x3BFFFFFF	
448 - 464	0x1C000000 - 0x1CFFFFF	960 - 976	0x3C000000 - 0x3CFFFFF	
464 - 480	0x1D000000 - 0x1DFFFFFF	976 - 992	0x3D000000 - 0x3DFFFFFF	
480 - 496	0x1E000000 - 0x1EFFFFFF	992 - 1008	0x3E000000 - 0x3EFFFFFF	
496 - 512	0x1F000000 - 0x1FFFFFF	1008-1034	0x3F000000 - 0x3FFFFFF	

 Table 4-9 Memory Address Ranges
# **Field Replaceable Units**

# Introduction

This chapter contains the procedures to replace assemblies in the Model 745 chassis components (such as the board computer module, EISA/PCI module, mass storage module, power supply and chassis mounted hardware).

### **Tools Required**

All field replaceable parts can be accessed with these tools:

Grounding wrist strap. No. 1 Pozidriv screwdriver (with extension). T-10 or T-15 Torx screwdriver Small flat-tipped screwdriver. 3mm (0.125-in.) thin-wall nutdriver, maximum outer diameter of 5.7mm (0.225-in.).

## **Safety Precautions**

As with any electrical/electronic product, certain safety precautions must be practiced. These safety precautions, *when followed*, can protect you from injury, and the equipment from possible permanent damage.

CAUTION:Integrated circuit components in these products can be damaged by<br/>electro-static discharge. It doesn't make any difference whether the<br/>ICs are installed on a printed circuit board or laying on a table.<br/>Static charges can build up in people to a potential of several<br/>thousand volts by simply walking across a room.Integrated circuits can be protected by using a static free work place<br/>and wearing clothes that do not hold static charges before handling

any of the workstation's PC boards.

When you need to remove or install a part or assembly, remove power from the product first. At the static free work place, touch sheet metal with your fingers before touching a printed circuit assembly. If the assembly is not going to be re-installed, place the assembly in an anti-static bag and set it aside.

Following these precautions will extend the life of the computer products you maintain.

### **New Parts**

New parts are available direct from:

Support Materials Organization	Parts Center Europe
Hewlett-Packard Company	Hewlett-Packard GmbH
8050 Foothills Boulevard	Wolf-Hirth Strasse 33
Roseville, California 95678 USA	D-7030 Boblingen, Germany
Telephone: (916) 786-8000	Telephone: +41 7031 14-2253

### **Exchange Parts**

Exchange parts are available for some items at a reduced cost. When an exchange part is ordered, your account will be charged for a new part.

Place failed exchange parts in anti-static bags and package them securely in a sturdy container. It's a good idea to save the containers and static-free bags you receive parts in and use them to ship parts in. Please return failed exchange parts to your exchange parts source as soon as possible. Customers have 15 days to return the failed part to receive credit for the difference between a new and exchange part.

Exchange parts only are available direct from:

Support Materials Organization Hewlett-Packard Company 8050 Foothills Boulevard Roseville, California 95678 USA Telephone: (916) 786-8000	Support Material & Services Europe Hewlett-Packard Ltd. Filton Road - Stoke Gifford Bristol BS12 6QZ United Kingdom
	Telephone: +44 272 799910

### Local Hewlett-Packard Sales & Service Office

Name:

Address: \_\_\_\_\_

City, State, Zip: \_\_\_\_\_

Tel. Number: \_\_\_\_\_

# Field Replaceable Units Introduction

### **Replaceable Parts**

Figure 5-1 shows an exploded view of the Model 745 industrial system.



Model 745 Exploded View

Table 5-1 is a chassis parts list.

Table 5-1

#### Model 745 Chassis Parts List

Non-Exchange Part Number	Description
A4964-62008	Chassis Assembly
A4964-66006	System Backplane
A4505-66001	PCI Interface Board
A4964-66003	PCI Backplane
A4309-66001	EISA Interface Board
A4964-66004	EISA Backplane
A2636-00004	Slot 3 Cover Plate
A4964-40003	Feet
A4964-00003	Chassis Top Cover
A4964-00005	Chassis Front Bezel
0950-2690	Power Supply
A4964-62004	Cable - backplane to mid-tray
A4964-62005	Cable - fan power (front)
A4964-62006	Cable - ac input
A4964-62007	Cable - single fan (rear)
A4964-62016	Cable - LED (2)
A4190-62030	Fan (3)
2110-0528	Fuse (See CAUTION)

#### **CAUTION:**

For continued protection against fire replace only with same type and rating of fuse (10A, 250V, 3AG, Fast-acting, .25 in. x 1.25 in.).

- VORSICHT:Zum fortgesetzten Schutz gegen Feuer die Sicherung nur durch eine<br/>Sicherung desselben Typs und derselben Nennleistung austauschen<br/>(10A, 250V, 3AG, schnell wirkend, 0,25 Zoll x 1.25 Zoll [0,64 cm<br/> x 3,18 cm]).
- ATTENTION:Pour assurer la continuité de la protection contre l'incendie, ne<br/>remplacer la pile qu'avec une pile du même calibre de fusible (10A,<br/>250V, 3AG, action rapide, 6,3 mm x 32 mm).

# Field Replaceable Units Introduction

Table 5-2 is a mass storage parts list.

Table 5-2	Mass Storage Parts List		
Exchange Part Number	Non-Exchange Part Number	Description	
A2084-69005		3.5 in. Flexible Disk Drive	
A1658-69012		4GB Hard Disk Drive, SE	
C1539-69201		DDS-2 Tape Drive	
	A1658-60015	CD-ROM Drive	
	A4964-62002	Internal SCSI Cable	
	A4964-62001	Internal Power Cable	
	A1658-62016	SE SCSI Terminator	
	8120-5547	0.5 m External SCSI Cable	

# **Model 744 Board Computer Parts**

Consult the appropriate model Service Handbook for parts and part numbers.

Figure 5-2 lists the major pieces of the Model 744 assembly. Table 5-3 lists the part numbers of the exchange parts and Table 5-3 lists the part numbers of the non-exchange parts of the Model 744.

This section refers to exchange and nonexchange part numbers. You must return parts with exchange part numbers in exchange for a replacement part. Do not return parts with nonexchange part numbers. You may discard them.



Figure 5-2 Model 744 Board Computer (Exploded View)

### Field Replaceable Units Model 744 Board Computer Parts

Callout Number	Exchange Part Number	Non- Exchange Part Number	Description	
1	A4500-69001		System board: 132 MHz	
			(with on-board graphics)	
	A4500-69006		System board: 165 MHz	
			(with on-board graphics)	
2	A4502-69001		32 MB RAM card	
	A4503-69001		64 MB RAM card	
	A4500-69005		128 MB RAM card	
	A4500-69018		256 MB RAM card	
3		A2636-00002	Slot 2 Cover Plate	
4		1420-0541	Real-time clock battery (See Warn-	
			ing Below)	
Not Shown		A4504-60001	PMC Bridge Adapter Board	
Not Shown		A4504-60002	PMC Expansion Adapter Board	
Not Shown		A4979-60001	PMC Visualize-EG Graphics Card	
Not Shown		A4500-00003	Standoff, Memory	
Not Shown		A2636-61601	Cable, 9/9 Serial External	
Not Shown		A2636-61602	Cable, 15/15 AUI, External	
Not Shown		A2636-61604	Cable, 15/15, Parallel, External	
Not Shown		A2636-61605	Cable, 9/9, Audio, External	
Not Shown		A4500-62009	Cable, EVC Monitor, 15-Pin-35-pin	
Not Shown		A4500-62004	Cable, Monitor, 15-Pin to 15-pin	
Not Shown		S2413-40001	Chip Extractor, Firmware	
Not Shown		A2261-62021	Rackmount Kit	

Table 5-3Replaceable Parts

WARNING:

Replace battery only with HP Part No. 1420-0541! Using any other battery can cause fire or explosion. Lithium batteries can explode if mistreated. Do not put lithium batteries in fires, try to recharge, or disassemble them.

# **Removing and Replacing the Model 744 Board Computer**

This section provides step-by-step instructions for removal and replacement of a single slot and dual slot 744 board computer.

## **Preliminary Requirements**

If you are replacing a defective 744 board computer with a new one, you must determine the LAN ID of the existing 744 board computer before replacing it.

If the 744 board is operational you can access the LAN ID information from the Boot Console Handler's Information menu. At the information menu prompt, enter the following command:

Information Menu: Enter Command>LA

If the 744 board is non-operational, you can find the LAN ID on the label of UE1 which is the non-volatile stable store EEPROM where the LAN ID is saved.

The label on UE1 lists the last six digits of the LAN ID. Locate these digits as shown in Figure 5-3 and write them down here with the first six digits. LAN ID: **0060b0**\_\_\_\_\_



Locating the LAN ID

### Field Replaceable Units Removing and Replacing the Model 744 Board Computer

### Removal

Follow these steps to remove the board computer from its card cage:

- 1 Shut down the system.
- 2 Loosen the captive screws, as shown in Figure 5-4. Loosen screws 1, 2, 3, and 4 for a dual slot Model 744 (the factory default), and loosen screws 1, 2, 3, 4, 5, and 6 for a three slot Model 744.
- **3** Swing both ejector levers outwards and pull the board computer forward out of the chassis

If you are replacing a defective Model 744 board, continue with Step 4, otherwise go to the section of this chapter that pertains to the FRU with which you are concerned.



#### Figure 5-4 Model 744 Captive Screws

### Replacement

- 1 After removing all the accessories, place them on the new/exchange board and return the failed board to Hewlett-Packard.
- 2 Install the new Model 744 board computer in the chassis and reconnect any cables or peripherals.

### Field Replaceable Units Removing and Replacing the Model 744 Board Computer

3 When you power on the new Model 744 for the first time, you need to enter the LAN ID that you recorded from the defective board in the Removing and Replacing the Model 744 Board Computer section earlier in this chapter. At the Boot Console's Service menu, enter the following command to enter the LAN ID:

Service Menu: Enter Command> ss\_update

**CAUTION:** When installing additional cards or replacing the CPU, always use the latest version firmware (replaceable Boot ROM or downloadable code) available.

# **Removing and Replacing RAM Cards**

This section provides step-by-step instructions for removing RAM cards from your Model 744.

# **Preliminary Requirements**

Before you remove a RAM card:

Remove the Model 744 from its card cage. (See Removing and Replacing the Model 744 Board Computer, earlier in this chapter.)

### Removal

Follow these steps to remove RAM cards:

1 Remove the retaining screws from the uppermost RAM card, as shown in Figure 5-5.





**RAM Card Fasteners** 

### Field Replaceable Units Removing and Replacing RAM Cards

- 2 Pull the RAM card up and off the RAM stack or board computer.
- **3** Repeat the procedure for multiple RAM cards. The spacers between cards act as retaining screws for the card below; remove them to access the card.

### Replacement

- 1 To replace a card, remove the old card according to the removal procedure.
- 2 Place the new card so the card is orientated in the same way as the old card.
- 3 Line up the connectors to match, then gently seat the card.
- 4 Replace the screws or standoffs used for that card.

# **Removing and Replacing the PMC Adapters**

This section provides step-by-step instructions for replacing the adapter (expansion kit) fixture in your Model 744.

## **Preliminary Requirements**

Before removing the adapter (Expansion Kit) fixture from your Model 744, remove the Model 744 from it's card cage. (See Removing and Replacing the Model 744 Board Computer, earlier in this chapter.)

## **Removal and Replacement**

Follow these steps to remove the adapters from your Model 744:

- 1 Remove the ejector handle sleeve labels and springs, as shown in Figure 5-6.
- 2 Remove the ejector handle sleeves, as shown in Figure 5-7.
- 3 Remove the expansion adapter's two front panel screws, as shown in Figure 5-8.
- 4 Remove the expansion adapter's four backplane connector screws, as shown in Figure 5-8.
- 5 Separate the expansion adapter from the bridge adapter.



Figure 5-6

**Removing the Labels and Springs** 



Figure 5-7

**Removing the Sleeves** 



#### Figure 5-8Removing the PMC Expansion Adapter

6 To remove a PMC card from the expansion adapter, remove the four screws from the bottom of the expansion adapter and separate the PMC card from the expansion adapter, as shown in Figure 5-9.



#### Figure 5-9 Removing a PMC card from the Expansion Adapter

- 7 Remove the bridge adapter's four front panel screws, as shown in Figure 5-10.
- 8 Remove the bridge adapter's four backplane connector screws, as shown in Figure 5-10.
- 9 Separate the bridge adapter from the board computer.



Figure 5-10

Removing the PMC Bridge Adapter



#### Figure 5-11 Removing a PMC card from the Bridge Adapter

- 10 To remove a PMC card from the bridge adapter, remove the four screws from the bottom of the bridge adapter and separate the PMC card from the bridge adapter, as shown in Figure 5-11.
- **NOTICE:** To replace the adapters, reverse the steps in the procedure for removing the adapters. The bridge and expansion adapters must be assembled together before assembling to the SBC. When installing an expansion adapter, be certain that the connector between the bridge adapter and the expasion adapter is fully seated.

# **Removing and Replacing the Front Panel**

This section provides step-by-step instructions for removing the front panel of your Model 744.

### **Preliminary Requirements**

Perform the following steps before removing the front panel:

- 1 Remove the Model 744 from its card cage.
- 2 Remove PMC adapters, if present.
- **3** Remove the slot 2 cover plate, if present.

NOTICE:

The RFI clips on the front panel are not individually replaceable. Replacing the RFI clips requires replacing the complete front panel.

### Field Replaceable Units Removing and Replacing the Front Panel

### **Removal and Replacement**

Follow these steps to remove the front panel:

1 Remove the interface port jack screws (There are two around each port - SCSI, video, and so forth) using the appropriate 3mm (0.125-inch) or 4mm (0.160-inch) nutdriver. The port jack screws are shown in Figure 5-12.



Port jack screws, 14 total, two each around seven of the ports.

#### Figure 5-12 Port Jack Screws

- 2 Remove the two small screws, one on each underside front corner of the board, that fasten the ejector handles to the board.
- **3** Pull the front panel forward, away from and off the system board.
- 4 Remove the RFI clip on the two RS-232 ports.

**NOTICE:** To replace the front panel, reverse the steps for removing the front panel extension panel.

### Field Replaceable Units Firmware ICs

# **Firmware ICs**

This section provides information on the Model 744 firmware ICs.

## Description

The ICs in the Model 744 are designated: UC1, UD1 an UE1. They perform booting functions, input/output and provide non-volatile stable storage.



Figure 5-13 744 ICs

UE1 is non-volatile stable storage. UD1 is input/output dependent code. UC1 is processor dependent code. The 744 firmware code is downloadable and can be upgraded by LAN and through the various storage media.

# **Removing and Replacing the Real-Time Clock Battery**

This section provides step-by-step instructions for removing and replacing the real-time clock (RTC) in your Model 744.

### **Preliminary Requirements**

WARNING:	Lithium batteries may explode if mistreated. Replace
	battery with only HP Part No. 1420-0541! Use of any
	other battery may cause fire or explosion. Use the
	following guidelines when handling old batteries:

Do not put lithium batteries in fires. Do not try to recharge lithium batteries. Do not disassemble lithium batteries.

## Removal

Perform the following steps before removing the RTC battery from your Model 744:

- 1 Remove the 744 from the chassis.
- 2 Remove any accessory cards installed at the board computer's left position which cover the battery.

### Replacement

Follow these steps to replace the RTC battery:

- 1 Locate the battery behind the left RAM connector. It is held in place by a spring arm marked with a "+".
- 2 Raise the spring arm holding the battery in place and remove the battery.
- **3** Install the new battery with its "+" side up.

# **Removing the Top Cover, Front Bezel, and Mid-Tray**

Removing the top cover is necessary to gain access to internal components such as:

- mass storage devices
- PCI or EISA cards

Removing the front bezel is necessary to gain access to internal components such as:

- front fans
- mid-tray removal

Removing the mid-tray is necessary to gain access to internal components such as.

- power supply
- backplanes
- internal cabling

### **Preliminary Requirements**

Before you remove the top cover perform the following:

- **1** Shut down any applications.
- 2 Shut down the Operating System.
- 3 Refer to the owner's guide, for information on properly shutting down HP-UX.
- 4 Turn off power to the Model 745.
- 5 Set up a static-free work place.
- 6 Disconnect all cables to the system.



Figure 5-14

**Top Cover Removal** 

Removing the Top Cover, Front Bezel, and Mid-Tray



Figure 5-15

Front Bezel Removal

### Removing the Top Cover, Front Bezel, and Mid-Tray



Figure 5-16

Mid-Tray Removal

NOTE: All Installation procedures are the reverse of removal in this section.

#### Procedure

- Remove the system top cover using the procedure earlier in this chapter. 1
- 2 If replacing a device go to Selecting Device Address.
- 3 If the only action is to remove a device go to Mass Storage Device Removal.

### **Selecting Device Address**

#### **Procedure**

Table 5-4

- 1 Unpack the device.
- 2 Set only jumpers or switches that are required to change the device SCSI address, any others should remain as shipped.

The default SCSI addresses for devices is shown in Table 5-4. You should check the address as set on the failing drive and set the address on the new drive to the same value.

Default SCSI Addressing	
1st Hard Disk Drive	ID 6
2nd Hard Disk Drive	ID 5
3rd Hard Disk Drive	ID 4
DDS Drive	ID 3
CD-ROM Drive	ID 2
Floppy Drive	ID 0

#### 

#### **CD-ROM**

Figure 5-17 shows the CD-ROM disk drive address settings.





**CD-ROM Disk Drive** 

### **Floppy Disk Drive**

Figure 5-18 shows the floppy disk drive address settings.







**Floppy Disk Drive** 

### **DDS Tape Drive**

Figure 5-19 shows the DDS tape drive address settings.







**DDS Tape Drive Address Selection** 

### Hard Disk Drive Address Selection

All replacement hard disk drives are shipped with jumper/configuration documentation. Please refer to the documentation shipped with the replacement disk drive for jumper settings and any applicable software patch dependencies.

### **Device Locations**

Figure 5-20 shows the factory default device locations for the Model 745 industrial system. Note that the front and rear disk carriers can be reversed.



Figure 5-20

**Device Locations** 

#### **Removing a Device from the Mass Storage Carriers**

**CAUTION:** Hard disk drives are vulnerable to physical shock. Dropping a hard disk drive from even a small height will damage its heads and platters. Always handle hard disk drives with extreme caution. Do not place a hard disk drive upside down on any surface.

Follow these steps to remove a drive.

1 Remove the disk retainer bracket (see Figure 5-21).



#### Figure 5-21 Removing Retainer Bracket

- 2 Unplug power and SCSI cables for the drive.
- **3** Remove the appropriate disk carrier by pulling it towards the center of the chassis, and then up and out.
- 4 Loosen the screws for that drive on the sides of the disk carrier.
- 5 Lift the drive up or slide the drive out of the carrier, depending on its slot position and other drives in the carrier.
- 6 Repeat this procedure, as needed, if you are removing additional devices

7 If necessary, remove the disk adapter brackets used to mount a 3.5-inch device in a 5.25-inch bay.

### Installing a Device in a Mass Storage Carrier

- 1 Remove the new device from its shipping box
- 2 Ensure that the hardware SCSI bus address selected on the device is not already used by the system.
- **3** In the case of a removable media device (flexible disk, CD-ROM, or DDS tape) note any special requirements for bezel installation.

#### NOTE:

Hard disk drives require special rubber grommets and mounting screws, shipped with the system.

- **4** If this is a hard disk drive, place the four rubber grommets in the mounting holes, as shown in Figure 5-23.
- 5 Place the device in the carrier and align the screw holes. See Figure 5-22 though Figure 5-24.
- 6 Adapter brackets are shipped with the system to allow mounting a 3.5-inch device in the upper (5.25-inch) slots of the disk carriers. If these brackets are installed into the disk carriers, you do not need to remove them to install the device. The brackets are packaged seperately if a 5.25-inch device is mounted in this slot.
- 7 Start, but do not tighten, each mounting screw.
- 8 After all mounting screws are started, tighten the mounting screws.
- 9 Replace disk carrier into the system. See Figure 5-25.
- 10 Replace the individual SCSI and power connectors.
- 11 Replace the retainer bracket. See Figure 5-26.
- 12 Replace the system's top cover.
- **13** Reconnect the power cable.
- 14 If the system is to be rack mounted, install into the rack now.
- 15 Turn on the power and boot the operating system.



Figure 5-22 Device Installation in the Disk Carrier
## **Replacing Mass Storage Devices**



5.25-inch to 3.5-inch adapter brackets

Figure 5-23

Installing the 3.5-inch adapter brackets



Figure 5-24

3.5-Inch Hard Disk Installation with Filler Panel

# **Replacing Mass Storage Devices**



Figure 5-25

**Replacing Disk Carriers** 

# **Replacing Mass Storage Devices**



Figure 5-26

**Replacing Retainer Bracket** 

# **EISA or PCI Backplane Replacement**

# **Preliminary Requirements**

- 1 Remove the top cover using the procedure earlier in this chapter.
- 2 Remove the front bezel using the procedure earlier in this chapter.
- 3 Remove the mid-tray using the procedure earlier in this chapter.

#### Procedure

- 4 Remove any EISA or PCI cards from the chassis.
- 5 Remove the screws that hold the backplane assembly in the mid-tray. See Figure 5-27.
- 6 Slide out backplane assembly



#### Figure 5-27 Backplane Assembly Removal

7 Separate the backplane from the converter card by pulling the apart.

# **EISA or PCI Backplane Replacement**



Figure 5-28

EISA or PCI Converter Board and Backplane Removal

# **Power Supply Replacement**

Two power supplies are used in the Model 745 - a Cherokee and an Astek

# **Preliminary Requirements**

- 1 Remove the top cover using the procedure earlier in this chapter.
- 2 Remove the front bezel using the procedure earlier in this chapter.
- 3 Remove the mid-tray using the procedure earlier in this chapter.

# **Power Supply Removal**

- 1 Disconnect the four wire harness leads three from the system backplane and one from the ac switches. See Figure 5-29.
- 2 Slide the power supply out of the chassis.
- **3** If you are replacing the power supply with the same type supply, slide the new supply into the chassis and reconnect the harnesses.
- **NOTE:** If you are installing an Astec power supply, make sure the long cable from the far end of the supply is positioned in the slot under the backplane cover (see Figure 5-30).
- 4 If you are replacing the supply with a different brand, you will need to move the screw located in the system backplane cover plate (see Figure 5-30).

# **Power Supply Replacement**



Figure 5-29 Cherokee Power Supply Removal and Replacement

## **Power Supply Replacement**





Astec Power Supply Replacement

# System Backplane Replacement

# **Preliminary Requirements**

- 1 Remove the top cover using the procedure earlier in this chapter.
- 2 Remove the front bezel using the procedure earlier in this chapter.
- 3 Remove the mid-tray using the procedure earlier in this chapter.
- 4 Remove the power supply using the procedure earlier in this chapter.

## System Backplane Replacement

## System Backplane Removal

- 1 Disconnect all wire harness from the backplane
- 2 Remove the Model 744 board compter and PMC bridge and expander baords, if present, from the chassis
- **3** Remove the system backplane cover plate. See Figure 5-31.
- 4 Remove the screws that secure the backplane to the chassis, and remove the backplane.





System Backplane Removal

# **Fuse Replacement**

# **Preliminary Requirements**

- 1 Remove the top cover using the procedure earlier in this chapter.
- 2 Remove the front bezel using the procedure earlier in this chapter.
- 3 Remove the mid-tray using the procedure earlier in this chapter.

See Figure 5-32.



**Fuse Removal** 

# **Rear Fan Replacement**

1 Remove fan guard (see Figure 5-33), disconnect the fan cable from the fan, and push the fan upwards.





Rear Fan Removal (Step 1)

### **Rear Fan Replacement**

- 2 Push the bottom of the fan inwards, moving the top of the fan down. See Figure 5-34.
- **3** Pull the fan out through the rear panel. See Figure 5-35



Figure 5-35

Rear Fan Removal (Step 3)

# **Front Fans Replacement**

# **Preliminary Requirements**

- 1 Remove the top cover using the procedure earlier in this chapter.
- 2 Remove the front bezel using the procedure earlier in this chapter.
- **3** Disconnect the fan cables from the fans.

See Figure 5-36.





**Front Fans Removal** 

# Diagrams

## Diagrams Functional Description of Model 745 Chassis

# **Functional Description of Model 745 Chassis**

The Model 745 chassis provides the following:

- One 400-Watt power supply.
- Four slot EISA backplane or four slot PCI backplane
- Five Internal Mass Storage Device mounting and electrical capability.

Figure 6-3 shows the Model 745 functional block diagram.





Model 745 Functional Block Diagram

## Diagrams Functional Description of Model 745 Chassis





Figure 6-2

Model 744 Block Diagram

## Diagrams Functional Description of Model 745 Chassis





Figure 6-3

Model 745 Power Distribution Diagram

# **Reference Documentation**

# Introduction

Information in this chapter should help you in various situations. The references include part numbers of many hardware documents relating to this system.

# **Service Documentation**

#### Table 7-1

#### **Related Service Documentation**

Manual Title	Part Number
HP Model 744 Board Computer Service Handbook	A4511-90603
Model 745 Technical Reference Manual for OEMs	A4964-90063

#### Table 7-2

## **Diagnostic Documentation**

Manual Title	Part Number
Support Tools Manager User's Manual; HP 9000 Series 700 and 800	5961-1612
HP Apollo 9000 Series 700 Diagnostics Manual, Volume 1	09740-90041
HP Apollo 9000 Series 700 Diagnostics Manual, Volume 2	09740-90043
HP Apollo 9000 Series 700 Support Tape/CD-ROM User's Manual	B2380-90000
PA-RISC Support Tools Manual Licensed Users Volume 1, SPU	5960-3149
PA-RISC Support Tools Manual Licensed Users Volume 2, Device Adapters/MUXes	5960-3151
PA-RISC Support Tools Manual Licensed Users Volume 3, LAN	5960-3153
PA-RISC Support Tools Manual Licensed Users Volume 4, SCSI	5960-3155
PA-RISC Support Tools Manual Licensed Users Volume 5, Disks	5960-3157
PA-RISC Support Tools Manual Licensed Users Volume 6, Tapes/Printers	5960-3159
PA-RISC Support Tools Manual Licensed Users Volume 7, Utilities	5960-3161
PA-RISC Support Tools Manual Licensed Users Volume 8, ISL Support Tools	5960-3163
PA-RISC Support Tools Manual HP Employees	5960-3165
Offline Diagnostics Environment (ODE) User's Manual	5962-3648
System Exerciser Install and Operating Guide	5961-1624

# System Installation and Getting Started Documentation

Table 7-3

#### System Installation and Getting Started Documentation

Manual Title	Part Number
Model 745 Industrial Controller Owner's Guide	A4964-90605
Model 744 Board Computer Owner's Guide	A4511-90606

# **Service Notes**

## **Service Notes**

Place service notes here.

# Index

#### A

accessories 1-8 adapter cables 1-9 altitude 2-3 audio 1-13 auto boot 3-26 changing state 3-26 auto search 3-26 changing state 3-26 auto start 3-26

#### B

battery 5-24 block diagram 6-2 board computer configurations 1 - 8boot commands 4-5 boot console features 3-2 menus 3-3 configuration 3-4 information 3-5 main 3-3 service 3-6 boot failure dealing with 4-2 bootable media searching for 3-11 budgeting power 3-1

#### С

cables 1-9, 5-8 CD-ROM SCSI settings 5-30 chassis codes 4-10 codes chassis 4-7 error 4-7 commands all 3-31 auto 3-26 boot 3-9 eisa 3-25 fastboot 3-29 lanaddress 3-30 memory 3-23 path 3-13 pim 3-32 reset 3-12 search 3-11 conversion cables 1-9

#### D

DDS tape drive SCSI settings 5-32 devices booting from 4-2 diagnostic documentation 7-3 diagnostics running ODE-based 4-21 dimensions 1-7 documentation diagnostic 7-3 installation 7-4 service 7-2

#### E

EISA module removal 5-40 EISA slots displaying status 3-25 environmental specifications 2-3

#### F

fastboot 3-29 disabling 3-29 displaying status 3-29 enabling 3-29 features 1-5 firmware 5-23 floppy disk drive SCSI settings 5-31 fuctional description 6-2

#### H

hard disk drive SCSI settings 5-33 heat dissipation 2-3 HPMC errors 4-25 humidity 2-3

## I

information online 1-12 system 1-11 Initial System Loader. See ISL installation 2-5 ISL environment 4-6 interacting with 4-2 invoking ODE-based diagnostics 4-21 program, defined 4-6

#### L

LAN station address 3-30 displaying 3-30 LEDs error codes 4-8

#### М

man commands cstm 4-23 mstm 4-23 xstm 4-23 manuals system information 1-11 mass storage devices 5-25 mass storage module removal 5-29 media searching for bootable 4-4 memory address ranges 4-38 displaying configuration 3-23 failure 3-23 nonvolatile 3-26 monitor displaying type 3-16, 3-17 setting type 3-18 setting type at power on 3-20

#### N

nonvolatile memory 3-26

# Index

#### 0

ODE-based diagnostics 4-21 offline diagnostics environment (ODE) 4-21 operating system 1-10 HP-RT 1-10 HP-UX 1-10 overview 1-10 operating temperature 2-3

#### P

part numbers board computer 5-7 EISA module 5-5 mass storage SE 5-6 PCI module 5-5 parts board computer 5-7 exchange 5-3 new 5-3 replaceable 5-4 path 3-13 displaying 3-13 setting 3-15 PCI module removal 5-40 physical dimensions 1-7 PIM information displaying 3-32 PMC adapters 5-14 power budgeting 3-1 power supply replacement 5-42 power switch removal 5-47, 5-48, 5-50 preventive maintenance 2-6 product identification 1-14 product overview 1-5 pwer requirements 1-7

#### R

RAM cards 5-12 regulatory requirements 2-4 repair services 1-15

#### S SCSI

SCS1 default ID 5-29 hard disk drives 5-33 serial number 1-14 service documentation 7-2 service notes 8-2 stable storage 4-4 storage stable 4-4 support 1-14 system information displaying 3-31 system verification tests running 4-23

#### Т

tests running system verification 4-23 tools 5-2

#### W

workstation booting 3-9 resetting to predefined parameters 3-12