

**Service Handbook**  
**B Class**  
**Model B132L/B132L+/B160L/B180L**



**HP Part No. A4190-90041**  
**Edition E1097**  
**Printed in U.S.A.**

© Hewlett-Packard Co. 1997

Printing History

First Printing: October 1997

UNIX is a registered trademark in the United States and other countries, licensed exclusively through X/Open Company Limited.

NOTICE

The information contained in this document is subject to change without notice.

HEWLETT-PACKARD MAKES NO WARRANTY OF ANY KIND WITH REGARD TO THIS MATERIAL INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Hewlett-Packard shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance or use of this material.

Hewlett-Packard assumes no responsibility for the use or reliability of its software on equipment that is not furnished by Hewlett-Packard.

This document contains proprietary information that is protected by copyright. All rights reserved. No part of this document may be photocopied, reproduced or translated to another language without the prior written consent of Hewlett-Packard Company.

RESTRICTED RIGHTS LEGEND. Use, duplication, or disclosure by government is subject to restrictions as set forth in subdivision (c) (1) (ii) of the Rights in Technical Data and Computer Software Clause at DFARS 252.227.7013. Hewlett-Packard Co., 3000 Hanover St., Palo Alto, CA 94304.

10 9 8 7 6 5 4 3 2 1

## **Safety and Regulatory Statements**

This section contains safety and regulatory statements pertaining to your B132L/B132L+/B160L/B180L workstation. It provides information on the following topics:

- Special video configuration statements
- Emissions regulations
- Emissions regulations compliance
- Datacom users statement
- Acoustics
- Electrostatic discharge (ESD) precautions
- Safety statement
- Laser safety statements
- Warnings and cautions

## Special Video Configuration Statements

The following statements apply only to those applications which include a cable connected to the S-Video connector on the A4248A card. No modification to the regulatory statements is necessary for applications which include cables connected to other connectors on the card but not to the S-Video connector.

### For EN55022 or CISPR 22 Applications:

---

**WARNING:**

**This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.**

---

### For FCC Applications:

---

**NOTICE:**

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

---

## Emissions Regulations

### Federal Communications Commission (FCC)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules and the Canadian Department of Communications. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception (determined by turning the equipment off and on), you can correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Ask the dealer or an experienced radio/television technician for help.

Hewlett-Packard's system certification tests were conducted with HP-supported peripheral devices and HP shielded cables, such as those you receive with your computer. Changes or modifications not expressly approved by Hewlett-Packard could void the user's authority to operate the equipment.

## Emissions Regulations

Operation of this device is subject to the following conditions:

- This device may not cause harmful interference.
- This device must accept interference received, including interference that may cause undesired operation.
- Cables used with this device must be properly shielded to comply with the requirements of the FCC.

## VCCI Class 2 ITE

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づく第二種情報技術装置です。この装置は、家庭環境で使用することを目的としていますが、この装置がラジオやテレビジョン受信機に近接して使用されると、受信障害を引き起こすことがあります。  
取り扱い説明書に従って正しい取り扱いをして下さい。

---

## **Emissions Regulations Compliance**

Any third-party I/O device installed in HP system(s) must be in accordance with the requirements set forth in the preceding Emissions Regulations statements. In the event that a third-party noncompliant I/O device is installed, the customer assumes all responsibility and liability arising therefrom.

---

## **Acoustics**

### **Regulation On Noise Declaration For Machines -3. GSGV7**

Lpa <70dB	Lpa<70dB
operator position	am Arbeitsplatz
normal operation	nomaler Betrieb
per ISO 7779	nach DIN 45635 T.19

## **Electrostatic Discharge (ESD) Precautions**

Electrostatic charges can damage the integrated circuits on printed circuit boards. To prevent such damage from occurring, observe the following precautions during board unpacking and installation:

- Stand on a static-free mat.
- Wear a static strap to ensure that any accumulated electrostatic charge is discharged from your body to ground.
- Connect all equipment together, including the static-free mat, static strap, routing nodes, and peripheral units.
- Keep uninstalled printed circuit boards in their protective antistatic bags.
- Handle printed circuit boards by their edges, once you have removed them from their protective antistatic bags.

---

## **Safety Statement**

This equipment conforms to the following safety standards:

- UL 1950
- CSA 950
- IEC 950
- EN 60950



---

## **Laser Safety Statement (U.S.A. Only)**

The CD ROM mass-storage system is certified as a Class-1 laser product under the U.S. Department of Health and Human Services (DHHS) Radiation Performance Standard according to the Radiation Control for Health and Safety Act of 1968.

This means that the mass-storage system does not produce hazardous laser radiation. Because laser light emitted inside the mass-storage system is completely confined within protective housings and external covers, the laser beam cannot escape from the machine during any phase of user operation.

## Warnings and Cautions

**WARNING:**

Removing device cover may expose sharp edges in equipment chassis. To avoid injury, use care when installing customer add-on devices.

**WARNUNG:**

Das Entfernen der Geräteabdeckung legt die scharfen Kanten im Inneren des Gerätes frei. Um Verletzungen zu vermeiden, seien Sie vorsichtig beim Einbau von zusätzlichen Bauteilen, die vom Kunden selber eingebaut werden können.

**AVERTISSEMENT:**

Des bords tranchants du châssis de l'équipement peuvent être exposés quand le cache de l'unité n'est pas en place. Pour éviter des blessures, faire très attention lors de l'installation de modules supplémentaires par le client.

**WARNING:**

Disconnect power plug from wall outlet or source power before moving or removing the device, or installing add-on components.

**WARNUNG:**

Entfernen Sie die Stromzuführung von der Steckdose oder der Stromquelle bevor Sie das Gerät bewegen, abbauen, oder zusätzliche Bauteile installieren.

**AVERTISSEMENT:**

Débrancher la fiche de la prise de courant ou de la source d'alimentation électrique avant de déplacer ou de retirer l'unité, ou avant d'installer des modules supplémentaires.

**WARNING:**

Lithium batteries may explode if mistreated. Do not put lithium batteries in fires or try to recharge or disassemble them.

Replace battery only with Matsushita Electric BR-2325 three-volt lithium battery (HP part number 1420-0314)! Use of any other battery may cause fire or explosion.

---

# Contents

## 1 Product Information

Product Description 3

System Unit Front Panel Controls and LEDs 6

System Power Switch 7

Power LED 7

System LEDs 7

Audio Controls 8

Removable Storage Devices 9

System Unit Rear Panel Connectors 10

Security Loop 11

Audio Connectors 11

Keyboard Connectors 14

PS/2 Keyboard and Mouse Connectors 14

HP Parallel I/O Connector 14

802.3 Network Connectors 14

Serial I/O Connectors 15

SCSI Connectors 16

TOC Button 16

Power Cord Connector 16

Monitors 17

Keyboard 17

Pointing Devices 17

Operating System Overview 18

Important Information You Need to Note 19

LANIC ID 19

IP Address and Subnetwork Mask Information 20

---

## Contents

### Networking Overview 21

- Mail 21
- telnet 21
- rlogin 22
- ftp 22
- rcp 23
- NFS 23

## **2 Environmental/Installation/PM**

Environmental Specifications 27

Installation 29

Preventive Maintenance 29

## **3 Configuration**

Workstation Configurations 33

FRU Configurations 34

- Internal Storage Configurations 34

- Allowable Memory Configurations 43

- Monitor-Type Selection 45

Graphics Configuration Consideration 46

- Special Video Configuration Statements 46

- For EN55022 or CISPR 22 Applications: 46

- For FCC Applications: 46

- Graphics Paths 47

- Graphics Configuration Restrictions 48

---

## Contents

### 4 Troubleshooting

Getting Ready to Troubleshoot 51

Dealing with a Boot Failure 56

    Searching for Bootable Media 58

    Stable Storage 59

    Boot Command Notations 59

    Supported Boot Paths 59

    ISL Environment 60

Selftest Failures 61

    Chassis Codes 63

Running System Verification Tests 77

Running ODE-Based Diagnostics 79

Dealing with HPMC  
(Uncorrectable Error) 81

    HPMC Caused by a Multi-Bit Memory  
    Parity Error 83

        Interpreting the Table 84

        Determining the Faulty SIMM Pair 85

    HPMC Caused by a Data Cache Parity Error 90

    Changing the Console to External Terminal 91

### 5 Field Replaceable Units

Exchange and Nonexchange Part Numbers 95

FRU Removal and Replacement 102

    Main Tray Assembly 105

---

## Contents

Removing Memory Modules	106
Installing Memory Modules	109
Second Level Cache Boards	112
Storage Tray Assembly	114
Storage Tray Cover	117
Disk Filler Panel	118
CD-ROM Drive or DDS Tape Drive	119
3.5-Inch Floppy Disk Drive	121
Hard Disk Drive	124
Removing EISA, GSC, and PCI Option Boards	126
CPU Board Assembly	128
Determining LAN ID	129
Removing the CPU Board	130
Optional EGRAM Module	131
System Fans and Speaker	133
Battery	135
Power Supply	136
Fast Wide SCSI Controller	138
Backplane	139

## 6 Diagrams and Pinouts

System Power	145
System Block Diagrams	172

## 7 Reference

Installation Manual	177
Service Manuals	177

---

## Contents

Reference Manuals 177

### **8 Service Notes**

### **9 Boot Console Interface**

Accessing the Boot Console Interface 183

Booting Your Workstation 185

Searching for Bootable Media 187

Resetting Your Workstation 189

Displaying and Setting Paths 190

Displaying and Setting the Monitor Type 193

    The Monitor Command 193

    Displaying the Current Monitor Configuration 195

    Setting the Monitor Type 197

    Setting the Monitor Type at Power On 199

    Changing the Console to External Terminal 200

Displaying the Current Memory Configuration 201

Setting the Auto Boot and Auto Search Flags 203

Displaying and Setting the Fastboot Mode 205

Displaying the LAN Station Address 206

---

## Contents

Configure and Display LAN Settings (B132L+/B180L Only)	207
Displaying System Information	209
Displaying PIM Information	210
Stable Storage	211
ISL Environment	212
Invoking ISL from the Boot Console Interface	212
ISL User Commands	213
Updating System Firmware with ODE	215



---

## Contents

### Figures

System Unit Front Panel Controls 6

System Unit Rear Panel Connectors 10

Disk Tray Positions 34

Early Model CD-ROM Drive  
SCSI Address/Jumper Settings 37

Later Model CD-ROM Drive  
SCSI Address/Jumper Settings 38

Early Model DDS-DC Tape Drive  
SCSI Address/Jumper Settings 39

Later Model DDS-DC Tape Drive  
SCSI Address/Jumper Settings 40

DDS-2 Tape Drive SCSI Address/Jumper Settings 41

DDS Drive Switch Settings for Data Compression Operation Mode 42

Memory Connectors 44

Power On Troubleshooting 52

Selftests Troubleshooting 53

HP-UX Compatible Mode Troubleshooting 54

HP-UX Compatible Mode Troubleshooting  
(Continued) 55

B132L/B132L+/B160L/B180L Major Components 95

Main Tray FRUs 96

---

## Contents

### Figures

Storage Tray FRUs	97
Removing the Floor Stand	103
Removing the Main Tray Assembly	105
Memory Module Location	106
Removing the Memory Retainer	107
Removing a Memory Module	108
Memory Module Location	109
Removing the Memory Retainer	110
Installing Memory Modules	111
Cache Boards Location	112
Removing Second Level Cache Boards	113
Removing the Memory Retainer	114
Disconnecting the Storage Tray Assembly	115
Removing the Storage Tray Assembly	116
Removing the Storage Tray Cover	117
Removing a Disk Filler Panel	118
Removing a CD-ROM Drive or DDS Tape Drive	119
Disconnecting the Floppy Drive Cable	121
Removing the Floppy Disk Carrier	122

---

## Contents

### Figures

Removing the Floppy Disk Drive 123

Removing a Hard Disk Drive 125

Removing an EISA, GSC, or PCI Option Board 126

Installing an Option Slot Blank Plate 127

Removing the CPU Board 130

Removing the Optional EGRAM Module 131

Disconnecting the Fan and Speaker Connectors 133

Removing the System Fans and Speaker 134

Removing the Battery 135

Removing the Option Board Support Bracket 136

Removing the Power Supply 137

Removing the FW SCSI Controller 138

Disconnecting the Speaker and Fan Connectors 140

Removing the Backplane 141

System Unit Functional Block Diagram (B132L/B160L)  
173

System Unit Functional Block Diagram (B132L+/  
B180L) 174

---

## Contents

### Tables

Audio Electrical Specifications	13
Serial I/O Pins	15
Sample LANSCAN COMMAND TABLE	20
Environmental Specifications	27
Storage Configurations	35
Default SCSI IDs	36
LED Error Codes	61
PIM_INFO Action Table	82
Multi-Bit Memory Parity Error	83
Memory Address Ranges	85
Example Table	87
Processor Module Error (Data Cache Parity)	90
Exchange Parts FRU List	98
Nonexchange Parts FRU List	100
Backplane to System Board Connector	145
Backplane PCI Connector	147
FWSCSI Board Backplane Connector	148
Backplane EISA Slot Connector (Rows F, B, E, and A)	149

---

## Contents

### Tables

Backplane EISA Slot Connector (Rows H, D, G, and C)  
150

Backplane PCI Slot Connector (5.0V Environment) 152

Backplane GSC Slot Connector 153

Backplane Fan Connector 155

Backplane Speaker Connector 156

System Board DRAMM DIMM Connector 156

System Board Cache DIMM Connector 159

Hard Disk Drive Power Pinouts 162

System Board Disk Tray SCSI Connector 163

System Board Disk Tray Power Connector 164

System Board Disk Tray CD-ROM Audio Connector  
164

Optional FWSCSI Board to Disc Tray FWSCSI Con-  
nector 165

System Fan Power Pinouts 166

Parallel Port Connector Pinouts 167

Single-Ended SCSI Connector Pinouts 168

EGRAM Connector 169

AUI Connector Pinouts 170

---

## Contents

### Tables

Serial Port Connector Pinouts 170

PS/2 Connector 171

System Paths 190

Mnemonic Style Notation 191

---

**1**

---

**Product Information**

## Product Information

This chapter introduces the HP 9000 B132L/B132L+/B160L/B180L workstation. Its purpose is to familiarize you with your workstation and its controls and indicators. The information is presented in the following sections:

- Product Description
- System unit front panel controls and LEDs
- System unit rear panel connectors
- Monitors
- Keyboard
- Pointing devices
- Operating system overview
- Important information you need to note
- Networking overview



## Product Description

The B Class workstations have the following key features:

- Processor Performance
  - Model B132L - 132 Mhz (33 Mhz GSC)
  - Model B132L+ - 132 Mhz (33 Mhz GSC)
  - Model B160L - 160 Mhz (40 Mhz GSC)
  - Model B180L - 180 Mhz (36 Mhz GSC)
- Operating System
  - Model B132L/B160L - Native HP-UX (version 10.20 or greater)
  - Model B132L+/B180L - Native HP-UX (version 10.20 with ACE or greater)
- User Interface
  - HP VUE graphical user interface
  - HP CDE graphical user interface
- Compatibility
  - Source and binary code compatible with the Series 700 product family
- Optional Graphics:
  - Model 132L/160L** - HP VISUALIZE-24Z, 24-plane graphics
  - HP VISUALIZE-8/24, Accelerated 8-plane or 24-plane 3D graphics
  - Model 132L+/180L** - HP VISUALIZE-8/24/48/48XP
  - HP VISUALIZE-EG/DualEG

## Product Information

### Product Description

- Main Memory
  - Model B132L/B160L - 6 slots of main memory allowing from 32 to 384 MBytes
  
  - Model B132L+/B180L - 6 slots of main memory allowing from 32 to 768 MBytes
  
- Second Level Cache
  - 2 slots allowing 1 MB of second level cache
  
- Internal Storage Devices
  - Fast, Wide Differential SCSI Hard Disk Drives (requires optional FW SCSI adapter)
  - Single-Ended SCSI Hard Disks (up to two)
  - Single-Ended SCSI CD-ROM Drive
  - Single-Ended SCSI 2.0/4.0/8.0 GB, 4-mm DDS-Format Tape Drive
  - 3.5-inch Slimline Floppy Disk Drive (not a SCSI Device)
  - Models B132L+/B180L only - Ultra, Wide Single-Ended SCSI 2.0/4.0/9.0 GB Hard Disks
  
- Standard Network
  - Ethernet IEEE 802.3 AUI
  - RJ45, UTP Twisted Pair
  - Models B132L+/B180L only - 100Base T/10Base T
  
- Standard I/O
  - SE SCSI Connector - 8-bit, 5 MB/sec synchronous 1.5 MB/sec asynchronous 50-pin, high density SCSI connector
  - Models B132L+/B180L only - Ultra, Wide Single-Ended SCSI Connector - 68 pin, high density SCSI connector.
  - Two Serial Interfaces RS232C, 9-pin male
  - One Parallel Interface, Centronics, BUSY handshake 25 pin female
  - Audio Line-in, Line-out, Mic, and Headphone
  - Two PS/2 ports (Keyboard and Mouse)


- EISA/PCI/GSC Option Slots
  - Slot 1 - GSC or PCI
  - Slot 2 - EISA, GSC, or PCI
- User I/O
  - PS/2 Keyboard
  - PS/2 Mouse

---

## System Unit Front Panel Controls and LEDs

Before powering on your system, you should become familiar with the system unit controls.

Figure 1 shows the system unit front panel controls.



**Figure 1** System Unit Front Panel Controls

## System Power Switch

Use the Power switch to power the system unit on and off.

---

**NOTICE:**

There is no need to manually shut down the HP-UX operating system on your workstation before powering it off. When you turn off the power switch, your workstation automatically shuts down the operating system before terminating the power.

---

## Power LED

The Power LED lights when the system unit power is on.

## System LEDs

The system LEDs indicate the status of your workstation. In the event of a system problem, the LEDs are lighted in different patterns to indicate error codes. See Chapter 6 for a complete list of the system LED error codes.



LED 4 - System Heartbeat



LED 3 - SCSI Bus Activity



LED 2 - Network Receive



LED 1 - Network Transmit

### Audio Controls

Next to the system LEDs are the following audio controls:

Headset Jack	Accommodates mini-headphones with a 3.5-mm diameter miniature stereo plug.
Volume Control	Adjusts the audio output volume to the headset jack or line out.
Mic Jack	Accommodates microphones with a 3.5-mm diameter miniature stereo plug.
Mute Button	Turns off the audio output to line out and speaker only.

---

**NOTICE:** The Volume Control, Headphone Jack, and Mic (microphone) Jack features of the CD-ROM are supported through software applications only.

---

For more information on the features and electrical specifications, see “Audio Connectors” later in this chapter.

### Removable Storage Devices

The Models B132L/B132L+/B160L/B180L support the following removable storage devices:

- CD-ROM Disc Drive
- DDS-Format Tape Drive
- Floppy Diskette Drive

---

***NOTICE:***

---

Due to space limitations, a DDS-format tape drive and a CD-ROM drive cannot both be mounted in the system at the same time.

A description of each drive's controls and indicators is in the chapter describing that device, later in this book.

---

## System Unit Rear Panel Connectors

This section describes the connectors on the system unit's rear panel

---

**NOTICE:** To maintain electro-magnetic and radio frequency emissions compliance, verify that all cables are fully seated and properly fastened.

---

Figure 2 shows the locations of the connectors on the system unit's rear panel.




Figure 2 System Unit Rear Panel Connectors



## Security Loop

The security loop provides a means of locking the storage tray, with a padlock or other locking device, to prevent unauthorized removal from the system.

## Audio Connectors

Your workstation has audio input and output capability through external input and output connectors on the rear panel and through an internal speaker. The rear panel contains the Audio IN (stereo line-in) and Audio OUT (stereo line-out) connectors.

---

**NOTICE:**

---

To maintain compliance with FCC/CISPR B you must use fully shielded, unbalanced audio cables and plugs.

The audio connectors are standard stereo audio mini-jacks. Hewlett-Packard recommends using gold-plated plugs available through audio retailers for best quality recording and playback through the external connectors. The following is a summary of the workstation audio features:

- Audio Features
  - Programmable sample rates:  
8kHz, 16kHz, 32kHz, 48kHz, 11.025kHz, 22.05kHz, and 44.1kHz.
  - Programmable output attenuation:  
0 to -96dB in -1.5dB steps
  - Programmable input gain:  
0 to 22.5dB in 1.5dB steps
  - Input monitoring:  
16-bit linear, 8-bit u-law, or A-law coding

## Product Information

### System Unit Rear Panel Connectors

- Audio Input
  - Line In
  - Mono microphone (on the front panel) compatible with
    - 1.5V phantom supply (bias voltage supplied by the system).
    - CD-ROM audio (if internal CD-ROM is installed)
- Audio Output
  - Line-out
  - Headphone (on the front panel)
  - Built-in mono speaker
- Audio CODEC
  - Crystal CS4215

The audio electrical specification for this workstation are summarized in Table 1

**Table 1**

**Audio Electrical Specifications**

<b>Frequency Response</b>	<b>25-20,000 Hz</b>
<b>Input Sensitivity/Impedance</b>	
Line In	2.0Vpk/47k ohm
Microphone	22mVpk/1k ohm
<b>Max Output Level/Impedance</b>	
Line Out	2.8Vpp/47k ohm
Headphone	2.75Vpp/50 ohm
Speaker (internal)	5.88Vpp/48 ohm
<b>Output Impedance</b>	
Line Out	619 ohm
Headphone	118 ohm
<b>Signal to Noise*</b>	
Line Out	65 dB
Headphone	61 dB
Speaker	63 dB
Line In	61 dB
Microphone	57 dB
<b>THD (w nominal load)</b>	
Line Out	-73 dB
Headphone	-70 dB
Speaker	-68 dB
Line In	-75 dB
Microphone	-73 dB

\*To convert from dB to number of significant bits, use the formula:

$$n = \left( \frac{\text{dB}}{[20 \log 10]} \approx \frac{\text{dB}}{6} \right)$$

For example, for 61dB S/N then n=61/6 or approx. 10 significant bits, or in other words, about 6 bits of noise.

## Keyboard Connectors

### PS/2 Keyboard and Mouse Connectors

The PS/2 connectors provide an interface for a keyboard and a mouse to the system. Consult the documentation that accompanies each input device for specific information concerning its use.

### HP Parallel I/O Connector

The 25-pin HP Parallel I/O interface uses Centronics interface protocols to support peripheral devices such as printers and plotters. Consult the documentation that accompanies each peripheral device for specific information concerning its use.

## 802.3 Network Connectors

Your workstation has built-in ThickNet LAN-AUI and LAN-TP (Twisted Pair) connectors for the 802.3 (ETHERNET) network. Connections to ThinLAN networks require an external transceiver. Your workstation will autoselect the correct network setting.

---

**NOTE:**

---

Only one of the network connectors can be used at one time.

### Serial I/O Connectors

You can attach a variety of pointing devices (such as a mouse or trackball), or peripheral devices to the Serial Input/Output (SIO) ports on the B132L/B132L+/B160L/B180L workstation. Peripheral devices include printers, plotters, modems, and scanners. Consult the documentation that accompanies each pointing or peripheral device for specific information concerning its use.

The SIO ports are programmable. You can set functions such as bit rate, character length, parity, and stop bits. The SIO ports are used as an interface for serial asynchronous devices to the CPU. The ports operate at up to a 460.8K baud rate.

Table 2 shows the SIO connector pin listings. The serial connectors are 9-pin D-sub connectors. Signal names are those specified in the EIA RS-232 standard.

**Table 2**                      **Serial I/O Pins**

<b>Pin No.</b>	<b>Signal</b>	<b>Description</b>
1	DCD	Data Carrier Detect
2	RXD	Receive Data
3	TXD	Transmit Data
4	DTR	Data Terminal Ready
5	GND	Ground
6	DSR	Data Set Ready
7	RTS	Request To Send
8	CTS	Clear To Send
9	RI	Ring Indicator

### **SCSI Connectors**

Use the single-ended and fast, wide connectors to connect external SCSI devices such as DDS-format tape drives and CD-ROM drives. Consult the documentation that accompanies each SCSI device for specific information concerning its use.

---

***NOTICE:***

When attaching external SCSI devices, be sure to terminate the last device on the external SCSI bus. If there are no external SCSI devices, attach a SCSI terminator to the back of the system.

---

### **TOC Button**

The TOC (transfer of control) button resets the system and transfers control from the default device to an auxiliary device.

### **Power Cord Connector**

Plug the workstation's power cord into the power cord connector to provide ac power to the system.

---

## Monitors

You can use one of the following HP monitors with your workstation:

- 17-inch, 1280x1024 color monitor (A4330)
- 20-inch, 1280x1024 color monitor (A4331)

Before using your monitor you should become familiar with its controls, connectors, and indicators. For this information, consult the documentation that was packaged with your monitor.

---

## Keyboard

The B132L/B132L+/B160L/B180L uses a PS/2 keyboard which connects to the PS/2 interface connector on the rear of your workstation.

---

## Pointing Devices

You can use an HP three-button mouse, a trackball, or other options as pointing devices using the PS/2 connector or the Serial ports. For instructions on using your particular pointing device, see the manual that came with it.

## Operating System Overview

Your workstation uses the HP-UX operating system, version 10.20 or greater. Instant Ignition systems, (systems with preloaded software), have X-windows and either the HP VUE or the HP CDE graphical user interface installed and configured.

Please refer to the “Instant Ignition System Configuration Information” sheet that shipped with your system for details on configuration.

If you have any questions about Instant Ignition, refer to *Using Your HP Workstation* for more information.

---

**NOTICE:**

---

When you power on your workstation, a self-test is performed before the system boots.



## Important Information You Need to Note

Before you begin using your workstation, take a moment to gather the following important information and note it in the appropriate subsection for future use:

- LANIC ID
- SCSI device ID(s)
- Device file used for each SCSI device
- Internet Protocol (IP) address
- Subnetwork mask

---

**NOTICE:**

For help with these, refer to *Using your HP Workstation*.

---

### LANIC ID

Locate the contents label that comes with the workstation shipping carton. Find the LANIC ID listed there and write it down in the space provided:

LANIC ID

---

You can also get your LANIC ID by using the lanscan command in a terminal window. To do this, follow these steps:

- 1 Turn your workstation and monitor on, if you have not already done so. Figure 1 of this chapter shows the location of the power switch on the workstation. See the documentation that came with your monitor for the location of the monitor power switch.
-

2 In a terminal window, enter the following at the prompt:

**/usr/sbin/lanscan**

You will see a table similar to Table 3.

**Table 3 Sample LANSCAN COMMAND TABLE**

Hardware	Station	Dev	Hardware	Net-Interface	NetMgt	Encapsulation
Path	Address	lu	State	Name Unit State	ID	Methods
2.0.2	0x0800091595EE	0	UP	lan0 UP	4	ETHER IEEE8023

The LANIC ID in this example is 0800091595EE.

At alternative method for listing the system's LANIC ID is to enter the following command at the information menu of the Boot Console Handler:

**lanaddress**

### **IP Address and Subnetwork Mask Information**

Get the IP address and the subnet mask information for your workstation from either your System Administrator or your Network Administrator and note them here:

IP address

---

subnet mask

---

## Networking Overview

Your workstation is capable of many more tasks than are described in this owner's guide. This section gives an overview of some of the networking capabilities of your system and directs you to the appropriate source for more information.

### Mail

Electronic mail allows you to send and receive mail messages on your workstation. For information on setting up and using electronic mail on your workstation, contact your system administrator and also see the *Using Your HP Workstation* manual that came with your workstation.

### telnet

The telnet application uses the TELNET protocol to communicate with another computer system on the network. The telnet application allows you to log on to the remote system from your workstation. If your system has man pages installed, you may read the on-line **telnet** man page by entering the following at a command-line prompt:

**man telnet**

### **rlogin**

The rlogin application also allows you to log on to another computer system on the network from your workstation. For more information on rlogin, see the *Using Your HP Workstation* manual that came with your workstation and read the on-line man page by entering the following at a command-line prompt:

**man rlogin**

### **ftp**

The ftp application is a user interface to the File Transfer Protocol. Use ftp to copy files between your workstation and another computer system on the network. For more information, see the *Using Your HP Workstation* manual that came with your workstation and read the on-line man page by entering the following at a command-line prompt:

**man ftp**

## **rcp**

The rcp application allows you to remotely copy files from another computer system on a network to your workstation. For more information, see the *Using Your HP Workstation* manual that came with your workstation and read the on-line man page by entering the following at a command-line prompt:

**man rcp**

## **NFS**

The Network File System (NFS) allows your workstation to access files on remote computer systems as if they were on your local system. The file system on the remote computer system does not have to be compatible with your workstation's file system. For more information, see *Installing and Administering NFS Servers* and *HP-UX System Administration Tasks* manuals.

Product Information  
**Networking Overview**

---

**Environmental/Installation/  
PM**

## Environmental/Installation/PM

This chapter lists the environmental specifications and regulatory requirements for the system. Installation and preventive maintenance information, if applicable, is also provided.



---

## Environmental Specifications

Table 4 lists the environmental specifications for this workstation.

**Table 4**                      **Environmental Specifications**

Type	Specifications
Altitude	
Operating	0-10,000 ft
Non-operating	15,000 ft
DC magnetic field	
Operating	<5 Gauss
Non-operating	<2 Gauss @ 7 ft
Electromagnetic Interference (EMI)	
Emissions	FCC Class B, CISPR B
Susceptibility	FCC Class B, CISPR B
Electrostatic Discharge	
Air discharge	0-15 kV, no effect
Contact discharge	0-3 kv, no effect
Humidity (Non-condensing)	
Operating	95%
Leakage Current	less than 3.5 mA
Temperature	
Operating	0 to +40° C
Non-operating	-40 to +70° C
Shock	
Operating	20g at 3 ms, 1/2 sine in normal axis with no hard errors
Non-operating	80g at 3 ms, 1/2 sine, normal axis
Vibration	

Environmental/Installation/PM  
Environmental Specifications

**Table 4**                      **Environmental Specifications**

<b>Type</b>	<b>Specifications</b>
Operating random	0.21 G rms, 5-50 Hz
Swept sine survival	0.5 G peak, 5-500 Hz
Random survival	2.09 G rms, 5-500 Hz
Acoustics	<5 bels 5-30° C <6 bels 30-40° C

---

## **Installation**

Refer to the *Hardware Install Card Model B132L/B160L*, (Part Number A4190-90010) for system installation information.

---

## **Preventive Maintenance**

The system unit requires no preventive maintenance. Some removable media storage devices require operator preventive maintenance. Refer to the *B132L/B132L+/B160L/B180L Owner's Guide* (Part Number A4190-90023) for more information.

Environmental/Installation/PM  
**Preventive Maintenance**

---

**Configuration**

## Configuration

This chapter provides details about setting up and changing the system configuration.

---

## Workstation Configurations

Refer to the *HP 9000 B Class Configuration Guide* for a complete list of supported accessories, peripherals, and operating systems for this workstation.


## FRU Configurations

This section provides information for setting up or changing the configuration of the system Field Replaceable Units (FRUs).

### Internal Storage Configurations

Each storage device is restricted as to where in the storage tray it may be installed. Before installing a storage device, use Figure 3 and Table 5 to determine which disk tray position is correct for your device.

Figure 3 shows the storage device positions in the disk tray. Table 5 lists what devices are supported in the different disk tray positions. The numbers in the left column of Table 7 refer to the position numbers in Figure 3.



**Figure 3**      **Disk Tray Positions**



**Table 5 Storage Configurations**

<b>Disk Tray Position</b>	<b>Supported Devices</b>	<b>Conditions</b>
<b>3</b>	Floppy Drive	The floppy drive is not a SCSI device.
<b>2</b>	CD-ROM DDS-Tape Single-Ended SCSI Disk Fast Wide SCSI Disk * Ultra Wide SCSI Disk**	The CD-ROM drive and the DDS tape drive are single-ended SCSI devices.
<b>1</b>	Single-Ended SCSI Disk Fast Wide SCSI Disk * Ultra Wide SCSI Disk**	
<p>* Fast Wide SCSI devices are supported only with the optional Fast Wide SCSI controller.</p> <p>**Ultra Wide SCSI is built-in on SPU board on B132L+ and B180L only.</p>		

Configuration  
FRU Configurations

Table 6 lists the recommended SCSI IDs for internal storage devices.

**NOTE:** There are no jumper settings to change for the floppy drive.

These SCSI IDs are the default IDs for each storage device. If an existing device already uses an ID, select an alternate ID.



**Table 6** Default SCSI IDs

<b>Fast, Wide SCSI</b>	
1st Hard Disk Drive	ID 6
2nd Hard Disk Drive	ID 5
Note: The Fast, Wide SCSI controller is set to SCSI ID 7.	
<b>Single-Ended SCSI</b>	
CD-ROM Drive	ID 2
DDS Drive	ID 3
1st Hard Disk Drive	ID 6
2nd Hard Disk Drive	ID 5
Notes: The floppy drive is NOT a SCSI device. The SCSI controller is set to SCSI ID 7.	
<b>Ultra Wide SCSI</b>	
1st Hard Disk Drive	ID 6
2nd Hard Disk Drive	ID 5
Note: The Ultra Wide SCSI controller is set to SCSI ID 7.	

**NOTICE:** The floppy disk drive is not a SCSI device.


The following figures show the CD-ROM and DDS tape drive SCSI address and jumper settings. For jumper settings for other types of drives, refer to the label on your hard drive for specific jumper information for that device.

**NOTE:** Remove or disable the terminators on all drives (disk, CD-ROM, and DDS).




**Figure 4** Early Model CD-ROM Drive SCSI Address/Jumper Settings

Configuration  
FRU Configurations



Jumpers							Jumpers								
Target ID	ID1	ID2	ID4	PRTY	PRV/ALV	TEST	TERM	Target ID	ID1	ID2	ID4	PRTY	PRV/ALV	TEST	TERM
0	○	○	○	○	○	○	○	4	○	○	○	○	○	○	○
1	○	○	○	○	○	○	○	5	○	○	○	○	○	○	○
2	○	○	○	○	○	○	○	6	○	○	○	○	○	○	○
Default	○	○	○	○	○	○	○	Default for root (NOT recommended for CD-ROM drive)	○	○	○	○	○	○	○
3	○	○	○	○	○	○	○								


Figure 5 Later Model CD-ROM Drive SCSI Address/Jumper Settings




SCSI ID		SCSI ID
<b>0</b>	○ ○ ○ ○ ○ ○ ○ ○ ○ ○ <input type="checkbox"/> ○ ○ ○ ○ ○ ○ ○ ○ ○ ○	<b>4</b>
<b>1</b>	○ ○ ○ ○ ○ ○ <input type="checkbox"/> ○ ○ ○ ○ ○ ○ <input type="checkbox"/> ○ ○ ○ ○ ○ ○ <input type="checkbox"/>	<b>5</b>
<b>2</b>	○ ○ ○ ○ <input type="checkbox"/> ○ ○ ○ ○ ○ ○ <input type="checkbox"/> <input type="checkbox"/> ○ ○ ○ ○ ○ ○ <input type="checkbox"/>	<b>6</b>
<b>3</b>	○ ○ ○ ○ <input type="checkbox"/> <input type="checkbox"/> ○ ○ ○ ○ ○ ○ <input type="checkbox"/> <input type="checkbox"/>	

**Figure 6**      **Early Model DDS-DC Tape Drive  
SCSI Address/Jumper Settings**

Configuration  
FRU Configurations




**Figure 7** Later Model DDS-DC Tape Drive SCSI Address/Jumper Settings



\*Term PWR is not used in HP workstation configurations.

**Figure 8 DDS-2 Tape Drive SCSI Address/Jumper Settings**

Configuration  
FRU Configurations



**Figure 9** DDS Drive Switch Settings for Data Compression Operation Mode



### **Allowable Memory Configurations**

This workstation has 6 memory slots, labeled 0A, 0B, 1A, 1B, and 2A, 2B. The memory configuration is 32 MB to 768 MB installed in pairs of 16 MB, 32MB, 64 MB, or 128 MB memory modules.


Memory modules must be installed in pairs of equal capacity.

Always install the largest capacity memory modules in the lowest numbered memory slots and don't skip any numbers.

For example, if you have a pair of 16 MB memory modules and a pair of 32 MB memory modules, first install the pair of 32 MB memory modules in slots 0A and 0B, then install the 16 MB modules in slots 1A and 1B.

Figure 10 shows the position of the memory connectors on the Main Tray.

Configuration  
FRU Configurations



**Figure 10**      **Memory Connectors**

See chapter 5 of this manual for details on installing memory modules.

### Monitor-Type Selection

The built-in graphics in the Model B132L/B132L+/  
B160L/B180L workstation supports the following two  
monitors:

- 17-inch, 1280x1024 color monitor (A4330)
- 20-inch, 1280x1024 color monitor (A4331)

The monitor type does not have to be changed on this  
workstation since the workstation is set up to support  
these monitors. However, if for some reason the moni-  
tor type needs to change, refer to Chapter 9 of this  
book.

---

***NOTICE:***

---

Unsupported monitors may “lock up” if they  
cannot sync to a scan rate.

## Graphics Configuration Consideration

If you are installing a graphics option, read the information in this section first.

### Special Video Configuration Statements

The following statements apply only to those applications which include a cable connected to the S-Video connector on the A4248A card. No modification to the regulatory statements is necessary for applications which include cables connected to other connectors on the card but not to the S-Video connector.

#### For EN55022 or CISPR 22 Applications:

---

**WARNING:**

**This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.**

---

#### For FCC Applications:

---

**NOTICE:**

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

---

### Graphics Paths

*graphics(0)* is the built-in 8-plane graphics adapter.

*graphics(1)* and *graphics(2)* are graphics adapters installed in option slots 1 and 2.

When a dual display graphics adapter (an adapter which has two video output connectors) is installed, the video connector on the left (when looking at the system from the rear) is *graphics(NA)* and the video connector on the right is *graphics(NB)*. Where *N* is the slot number in which the graphics adapter is installed. *A* and *B* denote the two video output connectors on the dual display adapter.

For example, a Dual Visualize Enhanced Graphics Card (A4451A) installed in option slot 2 would be *graphics(2A)* and *graphics(2B)*.

### Graphics Configuration Restrictions

The system supports only four graphics displays at a time. A “display” is a video output port or connector. For example, the Dual Visualize Enhanced Graphics Card (A4451A) is a dual display card. It has two external video connectors so it accounts for two of the maximum of four displays. Installing two of these cards accounts for four displays, which is the maximum supported by the system.

The built-in graphics adapter accounts for one graphics display (*graphics(0)*). If four displays are installed in the option slots, the built-in graphics adapter is automatically disabled.

---

**NOTICE:**

The A4077A Color Graphics Card, A4078A Dual Color Graphics Card, A4079B HCRX-8Z graphics adapter, and the A4071B HCRX-24 graphics adapter with the A4072A Z Accelerator attached are **not supported** in the B Class workstations.

---

---

**Troubleshooting**

## Troubleshooting

This chapter provides information about isolating a failing component, known as a Field Replaceable Unit (FRU), in a Model B132L/B132L+/B160L/B180L workstation.



## Getting Ready to Troubleshoot

To troubleshoot a B132L/B132L+/B160L/B180L workstation, you must be familiar with the HP-UX operating system and be able to start and stop processes. You should also be familiar with the boot ROM diagnostics, ISL diagnostics, and the Support Tools Manager online tests, which we describe in this chapter.

Note any error or status messages, then run the power-up boot ROM diagnostics, known as Self Test. If the Self Test diagnostics fail, replace the FRU that is indicated. If the tests pass but you still suspect a problem, run the ISL diagnostics and the Support Tools Manager online tests.

For a complete description of using ISL diagnostics and Support Tools Manager, see the *Precision Architecture RISC HP 9000 Series 700 Diagnostics Manual*.

In the following flowcharts, use Figure 11 (flowchart 1) and Figure 12 (flowchart 2) to troubleshoot based on whether or not the LEDs light. Use Figure 13 (flowchart 3) and Figure 14 to troubleshoot the HP-UX environment.

Troubleshooting  
Getting Ready to Troubleshoot

Flowchart 1





Figure 11 Power On Troubleshooting



**Figure 12** Selftests Troubleshooting

Troubleshooting  
Getting Ready to Troubleshoot

Flowchart 3





Figure 13 HP-UX Compatible Mode Troubleshooting

Flowchart 4



**Figure 14**      **HP-UX Compatible Mode Troubleshooting (Continued)**

## Dealing with a Boot Failure

To start this workstation from an operating system stored on a device different from the usual boot device, to boot from a different disk, or to boot from another type of device (such as a DDS tape drive), see the following situations and examples that use the Boot Console Interface. To access the Boot Console Interface, see Chapter 9 of this book.

- To boot from a known device containing a bootable operating system, type the following at the prompt:

```
boot <device>
```

where *device* is the **hardware path** to the device, specified in Mnemonic Style Notation.

For example, to boot an operating system stored on a DDS-format tape in a drive located at “scsi.1.0,” go to the Main Menu of the Boot Console Interface and then type the following command at the prompt:

```
boot scsi.1.0
```

The operating system on the specified device is used to start the workstation.

- To interact with the Initial System Loader (ISL) before booting the workstation, type the following at the prompt:

```
boot <device>
```

You are prompted:

```
Interact with ISL (Y or N) >
```

Answering yes (**y**) causes the ISL to be loaded from the specified device. After a short time, the following prompt appears on the screen:

ISL>

ISL is the program that actually controls the loading of the operating system. By interacting with ISL, you can choose to load an alternate version of the HP-UX operating system.

For example, if the usual kernel (**/stand/vmunix**) on the root disk (**fwscsi.6.0**) has become corrupted, boot the workstation from the backup kernel (**/stand/vmunix.prev**) by typing the following at the ISL> prompt:

**hpux /stand/vmunix.prev**

- To find the location of the bootable operating systems on the various media in the file system, use the search command.

### Searching for Bootable Media

To list all devices that may contain bootable media, go to the Main Menu of the Boot Console Interface and then type the following at the prompt:

```
search ipl
```

The search may turn up more devices than there are lines on the display. If using a text terminal, control the progress of the search from the terminal's keyboard by performing the following steps:

- To hold the display temporarily, press **Ctrl S**
- To continue the display, press **Ctrl Q**
- To halt the search, press **Esc**

These flow-control commands do not work with a bitmapped display, but such a display can show more than forty lines of text, so they are unnecessary.

To search for devices of *just one type* that actually contain bootable media, go to the Main Menu of the Boot Console Interface and then type the following at the prompt:

```
search ipl device_type
```

where *device\_type* is one of the following:

**fwscsi** is the built-in fast, wide differential SCSI bus or the built-in ultra, wide single-ended SCSI bus

**slotn.fwscsi** is an optional fast, wide SCSI bus

**sescsi** is the built-in narrow single-ended SCSI bus

**lan** is all connections to the built-in LAN



## Stable Storage

Stable Storage is non-volatile memory associated with each PA-RISC processor module. Stable storage is used by the processor (CPU) to store device path information, the state of the boot flags, HPMC error information, and operating system initialization data.

## Boot Command Notations

The **boot** command supports the following two notations:

- Mnemonic
- Path number

Type **help scsi** or **help lan** for more information on the boot path parameters.

Here are examples of mnemonic notation:

- **boot** with “no parameters” selects the primary boot path in stable storage.
- **boot** with the **alternate** or **alt** parameter selects the alternate boot path in stable storage.

Here is an example of path number notation:

**boot p1** attempts to boot from the second path indicated by the **search** command.

## Supported Boot Paths

SCSI devices are bootable when connected to the built-in SCSI or optional Fast, Wide SCSI bus. Diskless workstations can only boot from the LAN port on the System card.

### **ISL Environment**

The ISL environment provides the means to load the operating system (HP-UX) environment. The ISL environment also provides an offline platform to execute diagnostic and utility programs from a boot device when HP-UX does not load.

The ISL program is the first program loaded into main memory from an external media (LAN, disk, or tape) and launched by the initial program loader (IPL) routine during the Boot Administration environment.

The ISL environment provides the following capabilities:

- Execute user-entered commands to modify boot device paths and boot options in stable storage.
- Run offline diagnostic programs (TDIAG, IOMAP).
- Provide automatic booting of the HP-UX O/S after power-on or reset.

The ISL program provides a standalone environment for loading offline diagnostic and utility programs from the LIF directory. The ISL program also provides user commands to configure the boot parameters into Stable Storage.






## Selftest Failures

Chassis codes are the key to debugging selftest errors. If a failure is found during selftest, chassis codes are displayed in the diagnostic LEDs. Using Table 7, find the LED error code.

To get additional information about failures from the boot console interface, use the Service menu **pim**, **pdt**, and **Chassis Code** commands.










In the following table, shaded LEDs indicate that they are lit.

**Table 7** LED Error Codes


LED Value	RS-232 Chassis Code Range	Description
	N/A	Reserved
	7401	No memory found FAULT <i>Likely cause: SIMMs or processor board</i>
	N/A	Reserved
	7000-7F00	Memory Error FAULT <i>Likely cause: Memory SIMMs. System Console indicates which SIMM.</i>
	1030 - 4099	Processor board FAULT

Troubleshooting  
Selftest Failures

**Table 7**                      **LED Error Codes**

LED Value	RS-232 Chassis Code Range	Description
	5000 - 500F 8000 - 8FFF CD00 - CDff*	I/O System FAULT *Except backplane faults listed below
	8500, 8501 8C00-8CFF	Backplane FAULT PCI FAULT
	Any INIT/TEST code	INITIALIZATION and TESTING Note: These two LED codes will alternate to indicate forward progress: 0111, 1000, 0111,...
	Any fault not in this table including 1000-101C	Unknown FAULT
	CBF0 - CBFF 1001	HPMC FAULT
	A088 - A0FF	No console/IPL error FAULT
	N/A	Reserved
	N/A	Reserved
	N/A	Reserved

**Table 7 LED Error Codes**

LED Value	RS-232 Chassis Code Range	Description
	N/A	Power on value (processor board fault when this value remains for more than one second)

### Chassis Codes

Below are definitions for all L2 chassis display codes. The codes are organized in approximate numerical order for ease of reference.

The 'ostat' or operating state of the machine have been omitted. Possible values are: OFF, FLT (Fault), TEST, INIT (Initialize), SHUT (Shutdown), WARN (Warning), RUN, and ALL.

Where a number varies, it is represented with:

- v = error number
- w = other (explained in that area)
- x = slot number
- y = bus number (gsc or nio)

For the following section of DINO hardware test error chassis codes:

These appear only after a PCI failure; see chassis codes "8C0y".

They are preceded by "TEST ".

Code	Name	Meaning
0001	DINO_IAR0_ONES_TEST	srs iar0 register
0002	DINO_IAR0_ZERO_TEST	srs iar0 register
0003	DINO_IAR1_ONES_TEST	srs iar1 register
0004	DINO_IAR1_ZERO_TEST	srs iar1 register
0005	DINO_IC0_ONES_TEST	srs icr register
0006	DINO_ICR_ZERO_TEST	srs icr register
0007	DINO_IO_CONTROL_INIT	srs io_control register
0008	DINO_IO_FBB_EN_INIT	ars io_fbb_en register
0009	DINO_IIO_ADDR_EN_ZERO_TEST	ars io_addr_en register
000A	DINO_CONFIG_ADDR_ONES_TEST	ars config_addr register
000B	DINO_CONFIG_ADDR_ZERO_TEST	ars config_addr register
000C	DINO_GMAST_ONES_TEST	hvsr gmask register
000D	DINO_GMAST_ZERO_TEST	hvsr gmask register
000E	DINO_PAMR_INIT	hvsr pamr register
000F	DINO_PAPR_ONES_INIT	hvsr papr register
0010	DINO_PAPR_ZERO_INIT	hvsr papr register
0011	DINO_DAMODE_ONES_TEST	hvsr dmode register
0012	DINO_DAMODE_ZERO_TEST	hvsr dmode register
0013	DINO_PCICMD_INIT	hvsr pcicmd register
0014	DINO_MLTIM_INIT	hvsr mltim register

## Troubleshooting Selftest Failures

0015	DINO_BRDG_FEAT_INIT	hvrs brdg_feat reg- ister
0016	DINO_PCIROR_INIT	hvrs pciror register
0017	DINO_PCIWOR_INIT	hvrs pciwor register
0018	DINO_TLTIM_INIT	hvrs tltim register
* = Unexpected interrupts that should never occur in PDC code.		
Code	Name	Meaning
1x01	UNEXPECTED_INTERRUPT	HPMC
1x02	UNEXPECTED_INTERRUPT	Powerfail interrupt
(unused)*		
1x03	UNEXPECTED_INTERRUPT	Recovery Counter Trap*
1x04	UNEXPECTED_INTERRUPT	External Interrupt
1x05	UNEXPECTED_INTERRUPT	LPMC
1x06	UNEXPECTED_INTERRUPT	ITLB page fault*
1x07	UNEXPECTED_INTERRUPT	Instruction mem protec- tion trap*
1x08	UNEXPECTED_INTERRUPT	Illegal instruction trap
1x09	UNEXPECTED_INTERRUPT	Break instruction trap
1x0A	UNEXPECTED_INTERRUPT	Privileged instruction trap*
1x0B	UNEXPECTED_INTERRUPT	Privileged register trap*
1x0C	UNEXPECTED_INTERRUPT	Overflow trap*
1x0D	UNEXPECTED_INTERRUPT	Conditional trap*
1x0E	UNEXPECTED_INTERRUPT	Assist exception trap
1x0F	UNEXPECTED_INTERRUPT	DTLB miss/page fault*
1x10	UNEXPECTED_INTERRUPT	Non-access ITLB fault*
1x11	UNEXPECTED_INTERRUPT	Non-access DTLB/page fault*
1x12	UNEXPECTED_INTERRUPT	Data memory protection trap*
1x13	UNEXPECTED_INTERRUPT	Data memory break trap*
1x14	UNEXPECTED_INTERRUPT	TLB dirty bit trap*
1x15	UNEXPECTED_INTERRUPT	Page Reference trap*
1x16	UNEXPECTED_INTERRUPT	Assist emulation trap*
1x17	UNEXPECTED_INTERRUPT	Higher-privilege trans- fer trap*
1x18	UNEXPECTED_INTERRUPT	Lower-privilege trans- fer trap*
1x19	UNEXPECTED_INTERRUPT	Taken branch trap*
1x1A	UNEXPECTED_INTERRUPT	Data memory access rights trap*
1x1B	UNEXPECTED_INTERRUPT	Data memory protection id trap*
1x1C	UNEXPECTED_INTERRUPT	Unaligned data ref trap*
Code	Name	Meaning
1000	UNEXPECTED_INTERRUPT	Interrupt occurred dur- ing PDC execution
1030	STARTING_EST	Starting Early Selftest
1031	EST_SKIPPED	Early Selftest skipped
1032	BAD_CPU_TEST_MODE	
103C	CPU_INIT	Initialize the CPU
103E	EXITING_EST	Exiting Early Selftest
103F	CACHE_LOAD_ERROR	
1040-1048	CPU_BASIC	CPU basic selftest
1049-1050	CPU_ALU	CPU ALU selftest
1051-1058	CPU_BR	CPU branch selftest
1059-105A	CPU_SIDE_EFF	CPU side effect self- test
1061-1066	CPU_CB	
1067-1075	CPU_ARITH_COND	CPU arithmetic condi- tion selftest
1076-1077	CPU_BIT_OP	CPU bit operation self- test

## Troubleshooting Selftest Failures

1078-1079	CPU_SAR	CPU SAR selftest
107A-1080	CPU_EX_DEP	
1081-1083	CPU_BE	
1084-1089	CPU_CR	
108B-108D	CPU_EXT_INT	CPU external interrupt
selftest		
108E-1093	CPU_ITIME	CPU itimer selftest
1094-1097	CPU_SHADOW	CPU Shadow register
selftest		
1098-1099	CPU_DIAGS	CPU Diagnose register
selftest		
10A0	COPROC	Starting CPU COPROC
selftest		
10A1	COPROC_REG	COPROC register selftest
selftest		
10A2	COPROC_INSTR	COPROC instruction
selftest		
10A3	COPROC_TRAPS 10A4	COPROC_MISC
10AF	FPU_S_DISABLED	FPU's are disabled
10B0	TLB_INIT	Initialize the TLB
10B3-10B4	TLB_ADDR	
10B6-10B7	TLB_PROT	
10C0	BAD_PDH_SPEED	
10CE	CPU_EXTINGUISH	CPU was extinguished
via PDC_PROC call		
10D1	EEH_CONSOLE_PATH_FAILED	
10D2	EEH_CPATH_NOT_IN_SYS_MAP	
10D3	EEH_STI_PTR_NULL	
10D4	EEH_GR_INIT_FAILED	
10D5	EEH_HALT_CPU	
10D6	INVALID_USEC_WAIT_PARM	
10D7	INVALID_EUSEC_WAIT_PARM	
10D8	INVALID_SPEED_IN_PDH	
10EF	ST_WARNING	Selftests returned a warning
10FF	MONARCH_ST_FLT	Selftest returned a failure
Code	Name	Meaning
2000	ICACHE_ALINE	Icache Address line
selftest		
2001	ICACHE_ALINE_0100	Icache aline control
failure		
2002	ICACHE_ALINE_0105	Icache aline shorts
failure		
2003	ICACHE_ALINE_0110	Icache aline opens
failure		
2010	ICACHE_DLINE	Icache Data line selftest
2011	ICACHE_DLINE_0100	Icache dline tag error
2012	ICACHE_DLINE_0105	Icache dline data error
2020	ICACHE_RAM	Icache RAM selftest
2021	ICACHE_RAM_DATA_ERR	Icache RAM data error
2022	ICACHE_RAM_TAG_ERR	Icache RAM tag error
2023	ICACHE_RAM_LOAD_ERR	Icache RAM load error
2030-2x34	ITAG	Icache tag selftest
2040-2x45	CACHE_IERR	
2050	DCACHE_ALINE	Dcache Address line
selftest		
2051	DCACHE_ALINE_0100	Dcache aline control
failure		
2052	DCACHE_ALINE_0105	Dcache aline shorts
failure		
2053	DCACHE_ALINE_0110	Dcache aline opens
failure		
2060	DCACHE_DLINE	Dcache Data line selftest
2061	DCACHE_DLINE_0100	Dcache dline tag error
2062	DCACHE_DLINE_0105	Dcache dline data error

## Troubleshooting

### Selftest Failures

2070	DCACHE_RAM	Dcache RAM selftest
2071	DCACHE_RAM_DATA_ERR	Dcache RAM data error
2072	DCACHE_RAM_TAG_ERR	Dcache RAM tag error
2073	DCACHE_RAM_LOAD_ERR	Dcache RAM load error
2080-2x84	DTAG	Dcache tag selftest
2090-2x95	CACHE_DERR	
20A0-2xA8	CACHE_BIST	
20B0	DCACHE_PARITY	Dcache parity error
20B1	DCACHE_TAG_PARITY	Dcache parity error in the tag
20B2	DCACHE_WORD0_PARITY	Dcache parity error in word 0
20B3	DCACHE_WORD1_PARITY	Dcache parity error in word 1
20C0	ICACHE_PARITY	Icache parity error
20C1	ICACHE_TAG_PARITY	Icache tag parity error
20C2	ICACHE_WORD0_PARITY	Icache word0 parity error
20C3	ICACHE_WORD1_PARITY	Icache word1 parity error

21.. second level cache Code

Name	Meaning
2100-2102 SLC_ALINE	
2110-2111 SLC_DLINE 2120	SLC_RAM
2121 SLC_RAM	P1 data error in SLC
card B	
2122 SLC_RAM	P1 data error in SLC
card B	
2123 SLC_RAM	P1 data miss from SLC
2124 SLC_RAM	P1 STTEADD address mismatch
2125 SLC_RAM	P2 data error in SLC
card B	
2126 SLC_RAM	P2 data error in SLC
card A	
2127 SLC_RAM	P2 data hit error from SLC
2128 SLC_RAM	P2 STTEADD address mismatch
2131 SLC_TAG_COMP_DATA_ERR	
FLT extended info	Expected address[0:15]
	Expected address[16:31]
	Actual address (SlteAdd)[0:15]
	Actual address (SlteAdd)[16:31]
	Expected data[0:15]
	Expected data[16:31]
	Actual data[0:15]
	Actual data[16:31]
	Expected SlteStat[0:15]
	Expected SlteStat[16:31]
	Actual SlteStat[0:15]
	Actual SlteStat[16:31]
2132 SLC_TAG_COMPU_NO_HIT	
FLT extended info	same as 2131
2133 SLC_TAG_COMP_ADDR_ERR	
FLT extended info	same as 2131
2134 SLC_TAG_COMP_TAG_ERR	
FLT extended info	same as 2131
2135 SLC_TAG_PATT_DATA_ERR	
FLT extended info	same as 2131
2136 SLC_TAG_PATT_NO_HIT	



## Troubleshooting Selftest Failures

```

                FLT extended info same as 2131
2137 SLC_TAG_PATT_ADDR_ERR
                FLT extended info same as 2131
2138 SLC_TAG_PATT_TAG_ERR
                FLT extended info same as 2131
2140 SLC_MISS
2141 SLC_TAG_MISS_DATA_ERR
                FLT extended info same as 2131
2142 SLC_TAG_MISS_NO_MISS
                FLT extended info same as 2131
2143 SLC_TAG_MISS_ADDR_ERR
                FLT extended info same as 2131
2144 SLC_TAG_MISS_TAG_ERR
                FLT extended info same as 2131
2150 SLC_INV
2151 SLC_INV_UNEXP_SLC_SIZE
2152 SLC_INV_LDCSETUP_SLCSTAT_ERR
                FLT extended info Actual SLTESTAT[0:15]
                                Actual SLTESTAT[16:31]
                                Expected SLTESTAT[0:15]
                                Expected SLTESTAT[16:31]
2153 SLC_INV_LDCLEAR_SLCSTAT_ERR
                FLT extended info same as 2152
2154 SLC_INV_LDCLOAD_SLCSTAT_ERR
                FLT extended info same as 2152
2155 SLC_INV_UBITSETUP_SLCSTAT_ERR
                FLT extended info same as 2152
2156 SLC_INV_UBITEST_SLCSTAT_ERR
                FLT extended info same as 2152
2157 SLC_INV_LDCLEAR_DATA_ERR
                FLT extended info Actual data[0:15]
                                Actual data[16:31]
                                Expected data[0:15]
                                Expected data[16:31]
2158 SLC_INV_LDCLOAD_DATA_ERR
                FLT extended info same as 2157
2159 SLC_INV_UBIT_DATA_ERR
                FLT extended info same as 2157
2160 SLC_ERR
2161 SLC_ERR_NML_HPMC_ERR
                FLT extended info Actual MIOC status[0:15]
                                Actual MIOC status[16:31]
2162 SLC_ERR_MISS_HPMC_ERR
                FLT extended info same as 2161
2163 SLC_ERR_UNEXP_SLC_SIZE
2164 SLC_ERR_MEM_NO_HPMC_ERR
2165 SLC_ERR_INV_NO_HPMC_ERR
2166 SLC_ERR_SLC_NO_HPMC_ERR
2167 SLC_ERR_NML_RD_CHK_ERR
                FLT extended info Actual data[0:15]
                                Actual data[16:31]
                                Expected data[0:15]
                                Expected data[16:31]
```

## Troubleshooting

### Selftest Failures

```

                Actual M_RD_CHK[0:15]
                Actual M_RD_CHK[16:31]
                Expected M_RD_CHK[0:15]
                Expected M_RD_CHK[16:31]
2168      SLC_ERR_NML_DATA_ERR
          FLT extended info same as 2167
2169      SLC_ERR_MEM_RD_CHK_ERR
          FLT extended info same as 2167
216A      SLC_ERR_SLC_RD_CHK_ERR
          FLT extended info same as 2167
216B      SLC_ERR_NML_SLCSTAT_ERR
          FLT extended info same as 2152
216C      SLC_ERR_MEM_SLCSTAT_ERR
          FLT extended info same as 2152
216D      SLC_ERR_INV_SLCSTAT_ERR
          FLT extended info same as 2152
216E      SLC_ERR_SLC_SLCSTAT_ERR
          FLT extended info same as 2152
216F      SLC_ERR_MISS_SLCSTAT_ERR
          FLT extended info same as 2152
2170      SLC_ERR_MEM_MIOCSTAT_ERR
          FLT extended info Actual MIOC_STATUS[0:15]
                               Actual MIOC_STATUS[16:31]
                               Expected MIOC_STATUS[0:15]
                               Expected MIOC_STATUS[16:31]
2171      SLC_ERR_SLC_MIOCSTAT_ERR
          FLT extended info same as 2170
2172      SLC_ERR_MEM_EWORD0_ERR
          FLT extended info Actual DR0_M_ERR0[0:15]
                               Actual DR0_M_ERR0[16:31]
                               Expected DR0_M_ERR0[0:15]
                               Expected DR0_M_ERR0[16:31]
2173      SLC_ERR_MEM_EWORD1_ERR
          FLT extended info Actual DR0_M_ERR1[0:15]
                               Actual DR0_M_ERR1[16:31]
                               Expected DR0_M_ERR1[0:15]
                               Expected DR0_M_ERR1[16:31]
2174      SLC_ERR_SLC_EWORD0_ERR
          FLT extended info same as 2172
2175      SLC_ERR_SLC_EWORD1_ERR
          FLT extended info same as 2173
2176      SLC_ERR_MEM_ERRADDR_ERR
          FLT extended info Actual MDERRADD[0:15]
                               Actual MDERRADD[16:31]
                               Expected MDERRADD[0:15]
                               Expected MDERRADD[16:31]
2177      SLC_ERR_SLC_ERRADDR_ERR
          FLT extended info same as 2176
2190      SLC_DMA
2191      SLC_SCSI_INIT_FAILED
          FLT extended info SCSI ENTRY_INIT return val-
ue[0:15]                               SCSI ENTRY_INIT return val-
          ue[16:31]
2192      SLC_DMA_SETUP_SLCSTAT_ERR

```

## Troubleshooting Selftest Failures

	FLT extended info same as 2152	
2193	SLC_DMA_TEST_SLCSTAT_ERR FLT extended info same as 2152	
2194	SLC_DMA_UNEXP_SLC_SIZE	
2195	SLC_DMA_SETUP_DATA_ERR FLT extended info same as 2157	
2196	SLC_DMA_TEST_DATA_ERR FLT extended info same as 2157	
21F0	SLC_INIT	
Code	Name	Meaning
3000	ROM_XSUM	checksuming the EEPROM
3001	PDH_CNTRL	PDH_CONTROL_REGISTER
3002	SCR_SELFTEST	Scratch RAM under test
3003	SS_ERROR	Error reading Stable
Storage		
3004	ERR_WRITING_EEPROM	Error writing to the
EEPROM		
3005	EEPROM_WRITE_LIMIT	Write limit exceeded
3006	ERR_READING_EEPROM	Error reading EEPROM
3006	FATAL_ERR_READING_EEPROM	Fatal error reading
EEPROM		
3007	INVOKE_LDB	Entering LDB
3008	BAD_SYS_BRD_BYTE	Invalid
SYSTEM_BOARD_BYTE		
3009	BAD_SYS_MODE_BYTE	Invalid
SYSTEM_MODE_BYTE		
300A	BAD_SYS_MFG_TEST_BYTE	Invalid
SYSTEM_MFG_TEST_BYTE		
300B	PDH_IO_CNTRL	
301A	HVERSION_MISMATCH	Stable Store value <>
calculated value		
301B	MODEL_STRING	Model String check
301C	SW_ID	Check Software ID
30BC	CPU_CLOCKS	Sets clock speeds
30C4	CLEARING_EEPROM	Clearing and revalidat-
ing EEPROM		
30CD	CHECK_DEFAULTS	Checking Stable Store
is valid		
30D4	DEFAULTING_EEPROM2	Setting EEPROM2 de-
faults		
30F4	EEPROM_BOOT_LIMIT	Number of boots exceed-
ed 95,000		
30FC	BAD_PROC_BD_ID	Bad processor board ID
or backplane or combo		
30FD	BAD_SYS_BD_ID	Bad System Board ID
30FF	FAN_FAILURE	Failure of one or more
fans		
Code	Name	Meaning
4x00	STARTING_LST	Starting Late Selftest
4x01	LST_SKIPPED	Skipping Late Selftest
4x0E	EXITING_LST	Exiting Late Selftest
4x10	CACHE_PM_BYTE	PM cache byte selftest
4x20-4x27	CACHE_BYTE	Cache byte selftest
4x30	CACHE_PM_FLUSH	PM cache flush selftest
4x40-4x47	CACHE_FLUSH	Cache flush selftest
4x50-4x56	ICACHE_MISS	Icache miss selftest
4x60-4x69	DCACHE_MISS	Dcache miss selftest
4x70-4x71	DUAL_ISSUE	Dual Issue selftest
Code	Name	Meaning
5xy0	UNKNOWN_BUS_ERROR	
5xy1	INTERNAL_ERROR	
5xy2	PATH_ERROR_ASSERTED	Assertion of
PATH_ERROR detected		

## Troubleshooting Selftest Failures

5xy3	MODE_PHASE_ERROR	
5xy4	PARITY_ERROR	Data Parity Error
5xy5	PROTOCOL_ERROR	Bus protocol error
5xy7	DIR_ERROR	Runway Directed Error
5xy8	BROAD_ERROR	Runway Broad Error
5xy9	IMPROPER_ACCESS_ERROR	
5xyA	ILLEGAL_RESPONSE	
5xyB	BUS_TIMEOUT	
5xyD	WATCHDOG_TIMEOUT	
5xyE	GBOA_TOC	GeckoBoa TOC Error
504F	BUS_PMAE_HPMC	memory access error
(unconfigured mem space)		
505F	US_PIOAE_HPMC	proc transaction to IO
timed out		
506F	BUS_DMDP_HPMC	data parity detected
on GSC from L2 slave		
507F	BUS_PMDP	data parity detected
on GSC from L2 master		
58C0	GENERAL_PCI_HPMC	{Dino/PCI} bus error
detected		
5xyF	TLB_FAULT	U2 TLB fault or in-
valid PDIR entry		
Code	Name	Meaning
7000	MEM_HPMC_ERR	HPMC in memory system
7001	ICACHE_PARITY_ERROR	Icache parity error in
memory test		
7002	DCACHE_PARITY_ERROR	Dcache parity error im
memory test		
7003	MSI_READ_ERROR	MSI read timeout
7004	MSI_WRITE_ERROR	MSI write timeout
7005	RUNWAY_ERROR	Runway parity error
7006	WRITE_BOMB_ERROR	Write bomb error
7007	MEMORY_ADDRESS_ERROR	Memory address error
7008	MULTI_BIT_ERROR	Multi-bit memory error
7009	SINGLE_BIT_ERROR	Single-bit memory error
70FF	UNKNOWN_HPMC	
7101	MMC_NOT_RESPONDING	
7102	MMC_NOT_READY_ERROR	
7103	MMC_FAILED_TO_CLEAR	
7104	MMC_STICKY_BITS	
7105	MMC_BAD_REV	
7106	MMC_REG_ERROR	
7107	MMC_ERR_IN_ECC_TEST	
7200	NO_SMC_AVAILABLE	
721w	SMC_FAILED	w = SMC number
722w	SMC_BAD_REV	w = SMC number
7230	SMC_FAILED_TO_RESPOND	
7301	SIMM_0_DATA_ERROR	SIMM 0 bytes are not
equal		
7302	SIMM_1_DATA_ERROR	SIMM 1 bytes are not
equal		
7303	SIMM_MISMATCH_ERROR	SIMM 0 data <> SIMM 1
data		
7304	UNKNOWN_SIZING_ERROR	Unknown sizing compare
error		
7305	SIZING_MBE_ERROR	MBE occurred during
sizing		
7306	ADDR_TEST_ERROR	Addr test failed on
bank		
7307	ECC_TEST_ERROR	Ecc test failed on bank
7308	MBE_BY_SBE_ERROR	SBE caused an MBE
7401	NO_DRAMS	No DRAMS installed
7402	MIXED_DRAMS	Both EDO and STD DRAMS
7403	BAD_ADDR	Address did not map to
bank		
7404	BAD_GCT_ADDR	Address did not map in
GCT		
7405	DUAL_ISSUE_FAILED	Dual issue test failed

## Troubleshooting Selftest Failures

```

7406      HPMC_SLC_ACCESS_ERR
7407      HPMC_SLC_TAG_ERR 7500      NO_RAM_FOUND
7501      GOOD_MEM_FAILED      Not enough good memory
to run OS
7502      BCH_MEM_FAILED      Not enough good memory
to run BCH
7604      BAD_MCT_MEM_TEST_STATUS No bits set in Test
Status
7701      USING_ALT_CONFIG      Using Alternate memory
config
7702      MEMORY_INIT_ONLY      Memory not tested, ini-
tialized only
7703      SIM_LOADING_WARNING
7704      RAM_BUS_WARNING
7705      GOOD_MEM_GOOFY      GOOD_MEM > memory size
770F      SMC_REV_1_WARNING      REV 1 SMC search rou-
tine being used
7800      PDT_DISABLED_WARNING
7800      PDT_DISABLED_HALT
7801      UPDATE_SBE_OVRWRT      Overwrite SBE with MBE
7802      UPDATE_DUP_ENTRY      Duplicate PDT entry
7803      UPDATE_EEPROM_ERR
7804      UPDATE_TABLE_FULL      PDT table is full

```

Code	Name	Meaning
7C00	MIOC_ERR_NML_HPMC_ERR FLT extended info same as 2161	
7C01	MIOC_ERR_MEM_NO_HPMC_ERR	
7C02	MIOC_ERR_NML_RD_CHK_ERR FLT extended info same as 2167	
7C03	MIOC_ERR_NML_DATA_ERR FLT extended info same as 2167	
7C04	MIOC_ERR_MEM_RD_CHK_ERR FLT extended info same as 2167	
7C05	MIOC_ERR_MEM_MIOCSTAT_ERR FLT extended info same as 2170	
7C06	MIOC_ERR_MEM_EWORD0_ERR FLT extended info same as 2172	
7C07	MIOC_ERR_MEM_EWORD1_ERR FLT extended info same as 2173	
7C08	MIOC_ERR_MEM_ERRADDR_ERR FLT extended info same as 2176	
7D03	HPMC_MSI_READ_ERROR	MSI read timeout
7D04	HPMC_MSI_WRITE_ERROR	MSI write timeout
7D05	HPMC_RUNWAY_ERROR	Runway parity error
7D06	HPMC_WRITE_BOMB_ERROR	Write bomb error
7D07	HPMC_MEMORY_ADDR_ERROR	Memory address error
7D08	HPMC_MULTI_BIT_ERROR	Multi-bit memory error
7D09	HPMC_SINGLE_BIT_ERROR	Single-bit memory error
7D0A	HPMC_BAD_ADDR	Address did not map to bank
7Fww	MEM_FRU_ID	ww = SIMM number from the following list:
		0A 0B 1A 1B 2A 2B 3A 3B

Memory FLT extended info 7XXX (one of the  
above error chassis codes)

```

MEM_FRU_ID
Address in er-
ror[0:15]
Address in er-
ror[16:31]

```

## Troubleshooting Selftest Failures

		Expected data[0:15]
		Expected data[16:31]
		Actual data[0:15]
		Actual data[16:31]
7FFF	CATASTROPHIC_MEM_ERR	
Code	Name	Meaning
8000-8004	GECKOBOA_REG	
802B	IO_BUS_OVERLAP	Most likely graphics
	on core and carrier	
803D	TOO_MANY_GRAPHICS	Graphics cards space
	overlap	
80F3	ERR_READING_IODC_BYTES	PDC_IODC failed to re-
	trieve header info	
80F4	ERR_READING_EINIT	PDC_IODC failed to re-
	turn entry_init	
80F5	ERR_EXEC_EINIT	Error executing
	entry_init	
80F6	ERR_READING_EIO	PDC_IODC failed to re-
	turn entry_io	
80F7	ERR_ENTRY_IO_ERR	Error executing
	ENTRY_IO	
80F8	INVALID_DEVICE_CLASS	must be sequential,
	random or tftp	
80F9	ERR_READIN_ETEST	PDC_IODC failed to re-
	turn entry_test	
80FA	ERR_EXEC_ETEST	Error executing
	ENTRY_TEST	
80FC	INVALID_DEVICE	Probably internal PDC
	structure error	
811A	HOT_SWAP_RETRY	
Code	Name	Meaning
8400	LASI_TEST	Begin LASI tests, on
	an "arbitrary" GSC bus	
8404	LASI_RS232	
8405	LASI_SCSI	
8406	LASI_LAN	
8407	LASI_KYBD	
Code	Name	Meaning
8410	LASI_TEST	Begin LASI tests on
	the (sole) GSC bus, #1	
8414	LASI_RS232	
8415	LASI_SCSI	
8416	LASI_LAN	
8417	LASI_KYBD	
Code	Name	Meaning
84FF	FLT_NO_LASI	No LASI present
8500	WAX_EISA_MAP	
8501	WAX_EISA_ID	
8FFF	LATE_ST_FLT	Late Monarch selftest
	failure (I/O)	
Code	Name	Meaning
8w00	ERR_IOA_RAM_TEST	w = IOA; 8 = IOA0, A =
	IOA1	
8w01	ERR_IOA_TLB_TEST	w = IOA; 8 = IOA0, A =
	IOA1	
8w02	ERR_IOA_DMA_TEST	w = IOA; 8 = IOA0, A =
	IOA1	
8xyA	HOT_SWAP_RETRY	Hot Swap retry due to
	spin up time	
8xyA	GECKOBOA_NIO_0120	
8xyB	GECKOBOA_NIO_0125	

For the following section of PCI-related chassis codes:  
The "0" (in codes of the form 8C0y) may be re-

## Troubleshooting Selftest Failures

placed by the FRU slot number where appropriate.

Code	Name	Meaning
8C05	PCI_PATH_ERR	PATH error - wrong HW ?
8C06	PCI_BIST_TEST	Start exec dev's BIST test
8C07	PCI_BIST_ERR	Dev's BIST test failed
8C08	PCI_ALLOC_ERR	Resource allocation error
8C09	PCI_MEM_MANAGER_ERR	Memory manager error
8C0A	PCI_MEM_TYPE_ERR	Dev wanted mem below 1Mb
8C0B	PCI_MAX_BUS_EXCEEDED	> max allowed bus depth
8C0C	PCI_DEV_NOT_CONFIGURED	Dev not configured
8C0D	PDC_SYS_MAP_OVERFLOW	PDC_SYS_MAP is full (during PCI bus walk)
8C0E	SYS_PCI_MAP_OVERFLOW	SYS_PCI_MAP is full
8C0F	PCI_INT_KLUDGE_WARN	Raven interrupt kludge for flawed labproto BP

For the following section of PCI-related chassis codes:  
The "1" is the GSC bus number that DINO is attached to.

Code	Name	Meaning
8C10	INIT_PCI	DINO tests & PCI init begins
8C11	TEST_PCI_COMPLETE	DINO tests completed
8C12	INIT_PCI_COMPLETE	PCI init finished for DINO
8C13	PCI_NOT_FOUND	No DINO's found on GSC bus
8C14	PCI_TEST_ERR	A DINO test failed
8CCC	OLD_PARISC_CODE_TYPE	Need to get a new STI ROM rev in PCI graphics

Code	Name	Meaning
9000	NO_SS_CONS	Stable Storage console not found
9001	NO_CONS_FOUND	Alternate console(s) not found

Code	Name	Meaning
A088	NO_BOOT_NO_CONS	No console, unable to boot
A008	NO_BOOT_SELECTION	No bootable device found
A00F	RETRIEVE_PATH_FAILED	
A0BD	IODC_DEV_NOT_READY	ENTRY_INIT returned - 8, device not ready
A0FF	UNKNOWN_LAUNCH_FLT	
A50F	INIT_PRI_PATH_FAILED	
A70F	INIT_OTHR_PATH_FAILED	

Code	Name	Meaning
C0FF	CHASSIS_GSC_SLOT_WARNING	Program GSC slot off-sets to proper values
C200	RAM_CONFIG	Starting memory configuration
C201	BEG_DESTR_MEM_INIT	Starting destructive memory test
C202	BEG_NONDESTR_MEM_INIT	Starting non-destructive memory test
C20F	RAM_CONFIG_FP	RAM config forward progress indicator
C210	MEM_RESET_HARD	
C220	PHYSICAL_CONFIG	
C230	BANK_SIZING	
C240	CONFIG_FROM_EEPROM	
C250	INTRLV_CONFIG	

## Troubleshooting Selftest Failures

C252	TEST_DUAL_ISSUE	
C260	INTRLV_RAM_TEST	
C261	TEST_1ST_PAGES	
C263	TEST_WRITE	
C264	TEST_READ_WRITE	
C265	TEST_READ	
C270	UPDATING_CONFIG	
C280	CONFIG_TO_EEPROM	
C2A0	FLAT_CONFIG	
C2B0	FLAT_RAM_TEST	
C2C1	MEM_RESET_SOFT	
C2C2	NON_DEST_RAM_TEST	
C2C3	MIOC_ERR	Starting MIOC error
test		
C2E0	MEM_STUFF_DONE	
C300	MONARCH_TEST	Monarch is executing
extended s		
C3FF	LATE_MONARCH_TEST	Monarch has finished
extended selftests		
C400	GET_SS_CONS	Retrieving the SS con-
sole path		
C40A	GET_SPECIAL_CONS	Retrieving special con-
sole path		
C440	INIT_SS_CONS	Initializing the SS
console path		
C44A	INIT_SPECIAL_CONS	Initializing the spe-
cial console path		
C4CC	INIT_CCP	Initialize Close Con-
sole		
C4CD	NO_CCP	Close Console not found
C4CF	CCP_FOUND	Found the Close Console
C500	GET_PRI_PATH	Retrieving the primary
boot path		
C540	INIT_PRI_PATH	Initializing the prima-
ry boot path		
C550	TEST_PRI_PATH	Execute ENTRY_TEST for
primary boot path		
C580	LOAD_IPL_PRI_PATH	Loading IPL from the
primary boot path		
C5F0	PRI_IPL_FAULT_	An error occurred read-
ing IPL		
C5F1	BAD_IPL_ADDR_PRI	LIF address is zero or
not 2K byte aligned		
C5F2	BAD_LIF_MAGIC_PRI	LIF file not present
on media		
C5F3	BAD_IPL_SIZE_PRI	LIF file is zero, not
n*2K bytes, or > 256Kb		
C5F4	BAD_IPL_ENTRY_PRI	LIF entry point not
word aligned or >= size		
C5F8	BAD_IPL_CHKSUM_PRI	The arithmetic sum of
the words in IPL <> 0		
C5FF	LAUNCH_IPL_PRI	Branching to IPL from
the primary boot device		
C600	GET_DEFAULT_CONS	Retrieving default con-
sole path		
C601	GET_GRAPHICS_CONS	
C602	GET_KEYBOARD_CONS	
C640	INIT_DEFAULT_CONS	Initialize default con-
sole path		
C641	INIT_GRAPHICS_CONS	
C642	INIT_KEYBOARD_CONS	
C64F	RESET_MONITOR_TYPE	retrying bad monitor
type		
C651	INIT_MONITOR_FA	Initialize GSC or PCI
graphics at HPA FA		
C652	INIT_MONITOR_F8	Initialize GSC or PCI
graphics at HPA F8		
C653	INIT_MONITOR_F6	Initialize GSC or PCI



## Troubleshooting Selftest Failures

graphics at HPA F6		
C654	INIT_MONITOR_F4	Initialize GSC or PCI
graphics at HPA F4		
C700	GET_MFG_DFLT5	
C740	INIT_OTHR_PATH	Initializing the other
boot path		
C750	TEST_OTHR_PATH	Execute ENTRY_TEST for
other boot path		
C780	LOAD_IPL_OTHR_PATH	Loading IPL from non-
primary boot path		
C7F0	OTHR_IPL_FAULT_	An error occurred read-
ing IPL		
C7F1	BAD_IPL_ADDR_OTHR	LIF address is zero or
not 2K byte aligned		
C7F2	BAD_LIF_MAGIC_OTHR	LIF file not present
on media		
C7F3	BAD_IPL_SIZE_OTHR	LIF file is zero, not
n*2K bytes, or > 256Kb		
C7F4	BAD_IPL_ENTRY_OTHR	LIF entry point not
word aligned or >= size		
C7F8	BAD_IPL_CHKSUM_OTHR	The arithmetic sum of
the words in IPL <> 0		
C7FF	LAUNCH_IPL_OTHR	Branching to IPL from
non-primary boot device		
CB00	TOC_INITIATED	TOC handling initiated
CB01	NO_OS_TOC	No OS_TOC vector
CB02	BAD_OS_TOC_ADDRESS	Invalid OS_TOC vector
CB03	BAD_OS_TOC_CODE	Invalid OS_TOC code
CB04	BAD_OS_TOC_LEN	Invalid OS_TOC code
length		
CB05	BAD_OS_TOC_CHECKSUM	Invalid checksum for
OS_TOC code		
CB09	TOC_SEED_IVA	Seed Error TOC entered
CB0A	PREV_TOC	Previous TOC PIM logged
CB0B	BR_TO_OS_TOC	Branching to OS_TOC
handler		
CB0C	OS_TOC_FAILED	Branch to OS_TOC failed
CB10	LPMC_INITIATED	LPMC handling initiated
CB15	ULPMC	Runway LPMC error
CB19	LPMC_SEED_IVA	Seed Error LPMC entered
CB1B	BR_TO_OS_LPMC	Branching to OS_LPMC
handler		
CB1F	OS_LPMC_FAILED	Branch to OS_LPMC re-
turned		
CB99	SEED_IVA_HANDLER	PDC_SEED_ERROR iva ta-
ble HPMC hndlr entered		
CB9A	HPMC_OVERWRITE	HPMC PIM overwritten
CBF0	HPMC_INITIATED	HPMC handling initiated
CBF1	NO_OS_HPMC_IN_IVA	OS did not replace PDC
IVA		
CBF2	BAD_OS_HPMC_LEN	Invalid length for
OS_HPMC code		
CBF3	BAD_OS_HPMC_ADDR	Invalid address for
OS_HPMC code		
CBF4	BAD_OS_HPMC_CHECKSUM	Invalid checksum for
OS_HPMC code		
CBF5	OS_VECTOR_0	IVA + 32 = 0
CBF7	PDC_IO_INITIATED	PDC_IO Proc entered
CBF8	PDC_IO_EXITED	PDC IO Proc completed
CBF9	BC_NOT_CONFIGURED	PDC IO found BC in un-
configured state		
CBFA	PREV_HPMC	Previous HPMC PIM
logged		
CBFB	BR_TO_OS_HPMC	Branching to the OS
HPMC handler		
CBFC	BR_TO_OS_HPMC_FAILED	Failed branc to the OS
HPMC handler		
CBFD	UNKNOWN_CHECK	Check for no known rea-

## Troubleshooting

### Selftest Failures

son		
CBFE	HPMC_DURING_TOC	HPMC interrupted a TOC
CBFF	MULTIPLE_HPMCS	Nested HPMC occurred
CC0x	OS_RENDEZVOUS CC1x	EARLY_CPU_RENDEZVOUS
CC2x	CPU_RENDEZVOUS CC3x	CACHE_CPU_RENDEZVOUS
CC4x	MEM_CPU_RENDEZVOUS	

Code	Name	Meaning
CD00	INITIALIZE_IO	Beginning IO bus walk
CD08	IOA0_INIT	Init GSC bus

For the following section of chassis codes:

The "1" (in codes of the form CD1x) refers to the (sole) GSC bus, #1

TEST: Looking for hardware on GSC bus  
 INIT: Found the hardware being looked for  
 WARN: Not able to use the hardware even

though it is found Code

Name		Meaning
CD10	DINO	Dino GSC to PCI bus
bridge		
CD11	SLOT1	Bluefish (or ATM or
??) card in GSC slot 1		
CD12	SLOT2	Bluefish (or ATM or
??) card in GSC slot 2		
CD13	ZALON	Builtin FWSCSI inter-
face		
CD14	OFFSET4	(No hardware expected
at GSC offset 4)		
CD15	OFFSET5	(No hardware expected
at GSC offset 5)		
CD1A	F4_GRAPHICS	GSC graphics in slot
2, HPA 0xF4000000		
CD1B	FA_GRAPHICS	GSC graphics in slot
1, HPA 0xFA000000		
CD1C	F8_GRAPHICS	Possibly built-in
graphics		
CD1C	F8_GRAPHICS	Possibly GSC head 2,
slot 1, HPA 0xF8000000		
CD1D	F6_GRAPHICS	Possibly built-in
graphics		
CD1D	F6_GRAPHICS	Possibly GSC head 2,
slot 2, HPA 0xF6000000		
CD1E	WAX initialization	(Expected in EISA-capable system only)
CD1F	LASI initialization	

Code	Name	Meaning
CDE0	INIT_EISA_COMPLETE	(Expected in EISA-capable system only)
CDE1	EISA_SLOT_INIT	(Expected in EISA-capable system only)
CDEA	INIT_EISA	(Expected in EISA-capable system only)
CDEB	EISA_CHECKING_FOR_CARDS	(Expected in EISA-capable system only)
CDEC	EISA_NO_CFG_DATA	(Expected in EISA-capable system only)
CDED	EISA_CFGID_NE_CARDID	(Expected in EISA-capable system only)
CDEE	EISA_CARD_INIT_ERROR	(Expected in EISA-capable system only)
CDEF	NO_EISA_FOUND	(Expected in EISA-capable system only)
CDFF	INIT_SYSTEM_MAP_TABLE	Building the system map table

## Running System Verification Tests

HP-UX uses an online diagnostics product called the Support Tools Manager that allows system operation verification.

Three interfaces are available with the Support Tools Manager: a command line interface (accessed through the **cstm** command), a menu-driven interface (accessed through the **mstm** command), and the graphical user interface (accessed through the **xstm** command).

For more information on these user interfaces see the online man pages by entering the following at a command line prompt:

**man cstm**

**man mstm**

**man xstm**

For information on the enhanced online diagnostics, see the *Precision Architecture RISC HP 9000 Series 700 Diagnostics Manual*.

## Troubleshooting

### Running System Verification Tests

To access the Support Tools Manager, perform the following steps:

- 1 In a terminal window, type the following at the # prompt to invoke the command line interface:

```
# cstm
```

- 2 The following message appears:

```
Support Tool Manager Version A.01.00
Type 'help' for a list of available com-
mands:
CSTM>
```

- 3 To verify the system operation, type the following at the CSTM> prompt:

```
CSTM> verify all
```

Messages similar to the following appear:

```
Verification has started on device (CPU).
Verification has started on device (FPU).
CSTM>Verification of (FPU) has completed.
CSTM>Verification of (CPU) has completed.
```

- 4 Press Enter to return to the CTSM> after all test results are reported .
- 5 To exit the Support Tools Manager, enter the following:

```
CTSM> exit
```

If any tests failed, run Self Test and ISL diagnostics to isolate the problem.

## Running ODE-Based Diagnostics

The Offline Diagnostic Environment (ODE) consists of diagnostic modules for testing and verifying system operation. ODE provides all the necessary functions for the user to load specified tests and interact with those tests.

ODE is an ISL utility. To boot ODE:

- 1 Invoke the ISL environment from the system disk.
- 2 Type **ode** after the ISL> prompt to invoke ODE from the LIF directory on the system disk. The prompt changes to ODE>.

Not all of the test modules are available on all systems. To see what test modules are available to run on this system, type **ls** at the ODE> prompt. The available modules include the following:

- **lasidiag** - tests and verifies the core-I/O functionality within the LASI chip. The diagnostics test the SCSI interface, LAN interface logic, parallel interface, audio, RS-232, PS/2 keyboard and mouse interface, real time clock, and the PC floppy interface and drive.
- **memtest** - tests and verifies the memory arrays. If an error is detected, the diagnostic reports the memory card and its slot number that needs replacement. Memtest also provides a map of the memory configuration so that the user can identify the type of memory and its slot location.
- **update** - updates the system's Processor Dependent Code (PDC) firmware on the FEPRM.

## Troubleshooting

### Running ODE-Based Diagnostics

- **mapper** - identifies the configuration of HPPA systems. It displays path, identification, and revision information of I/O components, configuration of memory controllers, processors, co-processors, cache, and TLB, as well as processor board component revisions and values of various HPPA system identifiers, revisions, and capabilities.

For further information on the various ODE commands and a complete listing of the command set, type **help** at the ODE> prompt or at the prompt of one of the test modules.

## Dealing with HPMC (Uncorrectable Error)

The power-on sequence follows this path:

Power-on -> Selftest -> Console Path -> Boot Admin Mode -> Boot Path -> ISL Mode -> HP-UX Mode

When the hardware detects an unrecoverable (HPMC) error in the HP-UX environment, an error message, referred to as an HP-UX Kernel Tombstone is displayed on the monitor. The state of the system is written to main memory and the entire contents of main memory is dumped (written) to the swap area on the system disk.

HPMC error information is logged into Stable Storage; this information is referred to as PIM (Processor Internal Memory). The HPMC error information is available from the Boot Administration environment using the **PIM\_INFO** command.

To identify the failed FRU(s) after an HPMC, follow these steps:

- 1 Examine the first line of the data returned from a PIM\_INFO command to display the latest error information from the last TOC, LPMC, or HPMC interruption detected.
- 2 Compare the values from the PIM\_INFO command with those shown in Table 8 and take the appropriate action.

Troubleshooting  
**Dealing with HPMC (Uncorrectable Error)**

**Table 8 PIM\_INFO Action Table**

<b>Check Type Word</b>	<b>Cache Check Word</b>	<b>Bus Check Word</b>	<b>System Responder Word</b>	<b>Action * See Note 1</b>
0x80000000	0x40000000	N/A	N/A	See Note 2
0x20000000	N/A	0x00210003	0x00000000 0xEEFFFFFF	Replace SIMM
0x20000000	N/A	0x00310007	0xF0000000 0xF7FFFFFF	Replace CPU board
0x20000000	N/A	0x00310007	0xF8000000 0xFBFFFFFF	Replace Optional Graphics Card in EISA slot
0x20000000	N/A	0x00310007	0xFC000000 0xFFBFDFFF	See Note 3
0x20000000	N/A	0x00310007	0xFFFBE000 0xFFBEFFF	See Note 2
0x20000000	N/A	0x00310007	0xFFBF000 0xFFFFFFFF	Replace CPU board
Note 1	When more than one failed FRU is identified, run the appropriate diagnostics to isolate the failed FRU.			
Note 2	Replace the CPU board. See “HPMC Caused by a Data Cache Parity Error” on page 90. for more information			
Note 3	There are two possible sources of failure. First, replace the EISA controller. If the error occurs again, replace the CPU board.			



**HPMC Caused by a Multi-Bit Memory Parity Error**

An HPMC interruption is forced when a multi-bit memory parity error is detected during a “DMA read” operation of fetching an I/D cache line (32 bytes).

Table 9 shows an example of the HPMC error information retrieved from Stable Storage by the PIM\_INFO command during the Boot Administration environment.

**Table 9 Multi-Bit Memory Parity Error**

Word	Value
Check Type	0x20000000
CPU State	0x9e000004
Cache Check	0x00000000
TLB check	0x00000000
Bus Check	0x00210004
Assists Check	0x00000000
Assists State	0x00000000
System Responder Address	0x00nnnnnn
System Requester Address	0x00000000
System Controller Status	0x00000nnn

### **Interpreting the Table**

The values in the Bus Check and System Responder Address words indicate that a multi-bit memory parity error was detected by logic in the memory module. Ignore the value in the System Controller Status word.

The System Responder contains the SPA of the faulty SIMM pair. To determine the pair, you need to know the following:

- The SIMM pair sizes and their locations (for example, 16 MB SIMMs in Pair 1 and 8 MB SIMMs in Pair 0)
- The total memory size in HEX

### Determining the Faulty SIMM Pair

The address given by the System Responder Address is contiguous, even though empty slots are permitted. Memory boards are installed in pairs of the same memory capacity. The operating system starts mapping memory at Pair 3, if it exists. In other words, it maps starting with the highest numbered pair through to the Pair 0. To determine the faulty pair of SIMMs, perform the following steps.

- 1 Using Table 10, determine the HEX value address range for each SIMM pair in the system.

**Table 10** Memory Address Ranges

Pair (3 thru 0)	Memory Size (MB)	Address Range
_____	0-8	0x00000000 - 0x007FFFFFFF
_____	8-16	0x00800000 - 0x00FFFFFFF
_____	16-24	0x01000000 - 0x017FFFFFFF
_____	24-32	0x01800000 - 0x01FFFFFFF
_____	32-40	0x02000000 - 0x027FFFFFFF
_____	40-48	0x02800000 - 0x02FFFFFFF
_____	48-56	0x03000000 - 0x037FFFFFFF
_____	56-64	0x38000000 - 0x03FFFFFFF
_____	64-72	0x04000000 - 0x047FFFFFFF
_____	72-80	0,048000000 - 0x04FFFFFFF
_____	80-88	0x05000000 - 0x057FFFFFFF
_____	88-96	0x05800000 - 0x05FFFFFFF
_____	96-104	0x06000000 - 0x067FFFFFFF

Troubleshooting  
Dealing with HPMC (Uncorrectable Error)

**Table 10** Memory Address Ranges

Pair (3 thru 0)	Memory Size (MB)	Address Range
_____	104-112	0x06800000 - 0x06FFFFFF
_____	112-120	0x07000000 - 0x077FFFFFF
_____	120-128	0x07800000 - 0x07FFFFFF
_____	128-136	0x08000000 - 0x087FFFFFF
_____	136-144	0x08800000 - 0x08FFFFFF
_____	144-152	0x09000000 - 0x097FFFFFF
_____	152-160	0x09800000 - 0x09FFFFFF
_____	160-168	0x0A000000 - 0x0A7FFFFFF
_____	168-176	0x0A800000 - 0x0AFFFFFF
_____	176-184	0x0B000000 - 0x0B7FFFFFF
_____	184-192	0x0B800000 - 0x0BFFFFFF
_____	192-208	0x0C000000 - 0x0CFFFFFF
_____	208-224	0x0D000000 - 0x0DFFFFFF
_____	224-240	0x0E000000 - 0x0EFFFFFF
_____	240-256	0x0F000000 - 0x0FFFFFFF

For example, if the system configuration is:

- Pair 3: 32 MB SIMMs = 64 MB total for pair
- Pair 2: 16 MB SIMMs = 32 MB total for pair
- Pair 1: 32 MB SIMMS = 64 MB total for pair
- Pair 0: 8 MB SIMMs = 16 MB total for pair

The SIMM address ranges are:

Pair 3: Addresses 0x00000000 - 0x03FFFFFF

Pair 2: Addresses 0x04000000 - 0x05FFFFFF

Pair 1: Addresses 0x06000000 - 0x09FFFFFF

Pair 0: Addresses 0x0A000000 - 0x0AFFFFFF

**Table 11**

**Example Table**

Pair (3 thru 0)	Memory Size (MB)	Address Range
___3___	0-8	0x00000000 - 0x007FFFFFFF
___3___	8-16	0x00800000 - 0x00FFFFFFF
___3___	16-24	0x01000000 - 0x017FFFFFFF
___3___	24-32	0x01800000 - 0x01FFFFFFF
___3___	32-40	0x02000000 - 0x027FFFFFFF
___3___	40-48	0x02800000 - 0x02FFFFFFF
___3___	48-56	0x03000000 - 0x037FFFFFFF
___3___	56-64	0x38000000 - 0x03FFFFFFF
___2___	64-72	0x04000000 - 0x047FFFFFFF
___2___	72-80	0,048000000 - 0x04FFFFFFF
___2___	80-88	0x05000000 - 0x057FFFFFFF
___2___	88-96	0x05800000 - 0x05FFFFFFF

Pair 3  
(32 MB  
SIMMs)

Pair 2  
(32MB  
SIMMs)

**Table 11** Example Table

Pair (3 thru 0)	Memor y Size (MB)	Address Range
___1___	96-104	0x06000000 - 0x067FFFFFFF
___1___	104-112	0x06800000 - 0x06FFFFFFF
___1___	112-120	0x07000000 - 0x077FFFFFFF
___1___	120-128	0x07800000 - 0x07FFFFFFF
___1___	128-136	0x08000000 - 0x087FFFFFFF
___1___	136-144	0x08800000 - 0x08FFFFFFF
___1___	144-152	0x09000000 - 0x097FFFFFFF
___1___	152-160	0x09800000 - 0x09FFFFFFF
___0___	160-168	0x0A000000 - 0x0A7FFFFFFF
___0___	168-176	0x0A800000 - 0x0AFFFFFFF
_____	176-184	0x0B000000 - 0x0B7FFFFFFF
_____	184-192	0x0B800000 - 0x0BFFFFFFF
_____	192-208	0x0C000000 - 0x0CFFFFFFF
_____	208-224	0x0D000000 - 0x0DFFFFFFF
_____	224-240	0x0E000000 - 0x0EFFFFFFF
_____	240-256	0x0F000000 - 0x0FFFFFFF

Pair 1  
(32 MB  
SIMMs)

Pair 0  
(8 MB  
SIMMs)

- Determine the SIMM pair that contains the System Responder Address (as shown using the PIM\_INFO command) within its range. Evaluate the SIMM pairs as follows:

---

**NOTICE:**

---

Addressing starts at Pair 3, not Pair 0.

- A** If the System Responder Address (as shown using the PIM\_INFO command) is between 0x000000 and 0x03FFFFFF:  
Error in Pair 3
  - B** If the System Responder Address (as shown using the PIM\_INFO command) is between 0x04000000 and 0x05FFFFFF:  
Error in Pair 2
  - C** If the System Responder Address is between 0x06000000 and 0x09FFFFFF:  
Error in Pair 1
  - D** If the System Responder Address is between 0x0A000000 and 0x0AFFFFFF:  
Error in Pair 0
  - E** If the Responder Address is between 0x0B000000 and 0x0FFFFFFF:  
Address Space Not Filled; (Probable) CPU board Failure
  - F** If the Responder Address is between 0x01000000 and 0x0EFFFFFF:  
Invalid Address Space; (Probable) CPU board Failure
- 3** Without the actual failed bit number, the failed pair number is as close a determination as possible. To try to locate the faulty (individual) SIMM, reboot the system. Turn FASTBOOT OFF at the BOOT\_ADMIN prompt, set FASTSIZE to ALL OF MEMORY (0F), and power cycle again.
- If the (destructive) memory selftest locates the faulty SIMM, the corresponding Chassis Code is shown on the LEDs. Replace the faulty SIMM, otherwise, replace the

## Troubleshooting

### Dealing with HPMC (Uncorrectable Error)

SIMM pair identified in this procedure. Return the system state (for example, FASTBOOT) to the original condition.

#### HPMC Caused by a Data Cache Parity Error

An HPMC interruption is forced when a data parity error is detected during a Load instruction to the memory address space or during a data cache flush operation.

Table 12 shows an example of the HPMC error information retrieved from Stable Storage by the PIM\_INFO command during the Boot Administration environment.

**Table 12**

#### Processor Module Error (Data Cache Parity)

Word	Value
Check Type	0x80000000
CPU State	0x9e000004
Cache Check	0x40000000
TLB Check	0x00000000
Bus Check	0x00000000
Assists Check	0x00000000
Assists State	0x00000000
System Responder Address	0x00000000
System Requester Address	0x00000000
System Controller Status	0x00000nnn



The value in the CPU State word indicates that register values and addresses stored in Stable Storage at the time of the HPMC were saved.

The value on the Cache Check word identifies that logic in the processor module detected a (data) cache parity error. Ignore the value in the System Controller Status word.

### **Changing the Console to External Terminal**

In the event that your console stops displaying to your graphics device, use the following procedure to display to console to an external terminal:

- 1** Turn system power off.
- 2** Disconnect the PC keyboard connector from the system rear panel.
- 3** Connect a serial terminal to the Serial 1 connector (the top serial connector) on the system rear panel.
- 4** Power on the system.

The system will now display the console to the terminal connected to the Serial 1 port.

Troubleshooting  
**Dealing with HPMC (Uncorrectable Error)**

---

**Field Replaceable Units**

## Field Replaceable Units

This chapter lists the B132L/B132L+/B160L/B180L Field Replaceable Units (FRUs) and provides procedures and illustrations showing their removal and replacement.

Use the following tools to remove or replace FRUs:

- Light-duty flat blade screwdriver with 150-mm (6-in.) blade or T10 Torx driver.
- ESD equipment (see the “ESD Precautions” section in the Preface for detailed information)

---

***WARNING:***

---

**To avoid electrical shock, you must power off the system and unplug the power cord from the wall outlet, before performing each of the procedures in this chapter.**

---

***NOTICES:***

---

There is no need to manually shutdown the HP-UX operating system on the workstation before switching it off. When the power switch is turned off, the workstation automatically shuts down the operating system before terminating the power. Wait for the system to completely shutdown and power off before disconnecting the power cord.

To maintain FCC/EMI compliance, verify that all covers, bezels, and modules are replaced and that all screws are properly seated.

Failing to push the main tray all the way in and tightening the four screws on the back may prevent the system from powering up.

---


---

## Exchange and Nonexchange Part Numbers

In this chapter we refer to exchange and nonexchange part numbers.

You must return FRUs with exchange part numbers in exchange for a replacement FRU. Do not return FRUs with nonexchange part numbers. You may discard them.


Figure 15 shows the major components of the system unit.



**Figure 15**      **B132L/B132L+/B160L/B180L Major Components**


Field Replaceable Units  
Exchange and Nonexchange Part Numbers

Figure 16 shows the Main Tray FRUs for the B132L/  
B132L+/B160L/B180L workstation. The numbers  
correspond to item numbers in Table 13 and Table 14.



**Figure 16**      **Main Tray FRUs**

Figure 17 shows the Storage Tray FRUs for the B132L/B132L+/B160L/B180L workstation. The numbers correspond to item numbers in Table 13 and Table 14.



**Figure 17** Storage Tray FRUs

Table 13 lists the exchange parts, and Table 14 lists the nonexchange parts in the B132L/B132L+/B160L/B180L workstation.

Field Replaceable Units  
Exchange and Nonexchange Part Numbers

**Table 13 Exchange Parts FRU List**

Figure Number	Part Number	Description
B1	A4190-69028 A4190-69013 A4190-69016 A4190-69032	180 MHz CPU Assy 132 MHz CPU Assy 160 MHz CPU Assy 132 MHz CPU/New I/O Assy
C1	A1658-69009 A2084-69016 A1658-69010 A1658-69020 A4081-69003 A1658-69021 A4218-69016 A1658-69022	2 GB SE SCSI Disk 2 GB FW SCSI Disk 2 GB W/Diff SCSI2 Disk 2 GB Ultra Wide SE disk 4 GB W/Diff SCSI2 Disk 4 GB Ultra Wide SE disk 9 GB W/Diff SCSI2 Disk 9 GB Ultra Wide SE disk
C4	C1536-69201 C1539-69201 C1537-69201	DDS1 Tape Drive DDS2 Tape Drive DDS3 Tape Drive
C4	A1648-60015 A1658-60019	CD-ROM Drive 12X CD-ROM-Flint Gray
B2	A4200-69040 A4200-69045	512KB CACHE-83 MHZ 512KB CACHE-100 MHZ
B3	A2579-69001 A2580-69001 A1236-69001 A3828-69001 A3829-69001 A3830-69001	16 MByte SIMM 64 MByte SIMM 2x32 MByte DIMM 32 MByte EDO DIMM 64 MByte EDO DIMM 128 MByte EDO DIMM



Field Replaceable Units  
**Exchange and Nonexchange Part Numbers**

Field Replaceable Units  
Exchange and Nonexchange Part Numbers

**Table 14**                      **Nonexchange Parts FRU List**

Figure Number	Part Number	Description
B4	A4190-66500 A4190-66523	PCI Backplane PCI -5V/EISA Backplane
B5	0950-3021	Power Supply
Not Shown	A4190-66501	Fast Wide SCSI PCA
Not Shown	A4190-61601	Single-Ended SCSI Cable
Not Shown	A4190-61602	Fast-Wide SCSI Cable
Not Shown	A4323-63001	Ultra-Wide SE SCSI Cable
C2	A4190-62020	Disk Drive Bracket
B6	A4190-62030	System Fan
Not Shown	A4190-62022	Disk Tray Fan/Power Cable
A5	A4190-62025	Disk Filler Panel
A1	A4190-62043	Chassis (includes Main Tray and Disk Tray)
B7	A4190-62048	Disk Tray Assembly (sheet metal only)
B8	A4190-62051	PCA Retainer Clip Assembly
Not Shown	A4190-40013	Tower Stand
A4	A4190-40018	Floppy Filler
B9	A4190-40023	Memory Retainer
C3	A4200-62914	Disk Ski Bracket (2 required)
	A4200-61607	CD Audio Cable

**Table 14**                      **Nonexchange Parts FRU List**

<b>Figure Number</b>	<b>Part Number</b>	<b>Description</b>
Not Shown	A2263-40042	Rubber Foot
Not Shown	A4190-00049	Thumbscrew 6-32
A3	A4190-84009 A4578-84001 A4190-84010 A4190-84012	Model Number Plate B132 Model Number Plate B132L+ Model Number Plate B160L Model Number Plate B180L
Not Shown	A4190-61603	Floppy Cable
B11	A4081-62021	Speaker
C5	A4190-60010	Slim Line Floppy Drive
C6	A4190-62024	Floppy Carrier Assy
Not Shown	8120-6861	EVC Video Adapter Cable
Not Shown	A4452-66501	EG RAM Card
B6	A4190-40016	Fan Shroud
Not Shown	0624-0727	6-32 Disk/Pwr holding screw
Not Shown	5180-1344	SE SCSI Jackscrew
Not Shown	A1658-62016	SE SCSI Terminator
Not Shown	1252-4367	FW SCSI Jackscrew
Not Shown	A1658-62024	FW SCSI Terminator
Not Shown	A1658-62070	SE WIDE SCSI Terminator

## FRU Removal and Replacement

The procedures in this section describe how to remove system unit FRUs. Observe any notices and prerequisites for removing a FRU. Replacement is the reverse of removal, unless noted.

- 1 Power off the system, the monitor, and any peripheral devices.

---

**NOTICE:**


There is no need to manually shut down the HP-UX operating system on the workstation before powering it off with the power switch. When the power switch is turned off, the workstation automatically shuts down the operating system before terminating the power.

---

**CAUTION:**

Unplugging the power cord while HP-UX is running can damage the system files.

- 2 When the system has completely shut down and powered off, unplug the system unit power cord and the power cords of any peripheral devices from ac wall outlets.
- 3 Unplug the system unit power cord from the ac input connector.
- 4 Disconnect any external cables from the connectors on the front and rear of the system unit.
- 5 Attach a static-grounding wrist strap to your wrist and a location on the system chassis that is bare metal. If you are using a disposable wrist strap, follow the instructions on the package.
- 6 If installed, remove the floor stand as shown in Figure 18.



**Figure 18**      **Removing the Floor Stand**

---

***CAUTION:***

Follow normal ESD, anti-static precautions when handling the workstation or any of its components. Failure to do so can cause component degradation or failure.

---


Field Replaceable Units  
**FRU Removal and Replacement**

- 7** Lay the workstation on a flat stable surface, such as a table top or floor.
- 8** If installed, remove any locking device from the storage tray security tab on the rear of the system unit.

### Main Tray Assembly

Perform the following steps to remove the main tray assembly from the system unit:

- 1 Completely loosen the four thumb screws on the rear of the system unit, as shown in Figure 19.



**Figure 19** Removing the Main Tray Assembly

- 2 Place one hand on the top of the system unit and push, while using your other hand to pull on the handle on the rear panel. See Figure 19.
- 3 Slide the main tray assembly out of the chassis.


### Removing Memory Modules

Before removing memory modules, remove the Main Tray Assembly from the system unit.

Refer to Chapter 3 for information about memory configurations.

Perform the following steps to remove memory modules:


- 1 Locate the memory modules on the CPU board, as shown in Figure 20.



**Figure 20** Memory Module Location




- 2 Pull the tab on the memory retainer and slide it toward the front of the main tray to remove it, as shown in Figure 21



**Figure 21**      **Removing the Memory Retainer**

Field Replaceable Units  
FRU Removal and Replacement

- 3 To remove a memory module, push the ejector tabs on each side of the module. Lift the memory module up and out of the connector and place it on a static-free surface. Figure 22 shows how to remove a memory module.



**Figure 22**      **Removing a Memory Module**

### Installing Memory Modules

Before installing memory modules, remove the Main Tray Assembly from the system unit.

Refer to Chapter 3 for information about memory configurations.

Perform the following steps to install memory modules:

- 1 Locate the memory connectors on the CPU board, as shown in Figure 23.





Figure 23

Memory Module Location

Field Replaceable Units  
FRU Removal and Replacement


- 2 Pull the tab on the memory retainer and slide it toward the front of the main tray to remove it, as shown in Figure 21



**Figure 24**      **Removing the Memory Retainer**

- 3 Close the ejector tabs on each side of the memory connector to lessen the force required to seat the memory module.

- 4 Line up the memory module with the guides making sure that the notched end of the memory module is toward the white ejector tabs (front of the main tray), as shown in Figure 25.



**Figure 25**      **Installing Memory Modules**

- 5 Press firmly and evenly on the memory module to ensure that it is fully seated.
- 6 To verify that this installation was successful, display the current memory information using the Boot Console Interface.


For more information on the Boot Console Interface, see Chapter 9 of this manual.

If only a faulty memory module is replaced, use the **pdt clear** command in the service menu of the Boot Console Interface. Answer **y** to the prompt *Continue? (Y/N)*.

### Second Level Cache Boards


Before removing second level cache boards, remove the main tray assembly.

- 1 Locate the cache board connectors on the CPU board, as shown in Figure 26.



**Figure 26** Cache Boards Location

- 2 To remove a second level cache board, swing the ejector tabs on each side of the board out and away from the board, as shown in Figure 27. Lift the board up and out of the connector and place it on a static-free surface.



**Figure 27**      **Removing Second Level Cache Boards**

***NOTICE:***

You must install cache boards in pairs of equal size. When installing cache boards, line the cache board up with the guides making sure that the keying notches along the connector edge of the board are away from the memory modules

### Storage Tray Assembly

Before removing the Storage Tray Assembly, remove the Main Tray Assembly from the system unit.

---


**NOTICE:**

The Storage Tray Assembly does not have to be removed from the system unit to access a hard disk drive or the 3.5-inch floppy drive.

---

Perform the following steps to remove the storage tray assembly from the Main Tray:


- 1 Pull the tab on the memory retainer and slide it toward the front of the main tray to remove it, as shown in Figure 28



**Figure 28**      **Removing the Memory Retainer**




- 2 Remove the storage tray retaining screw, as shown in Figure 29.
- 3 Disconnect the cables from the system board and the backplane, as shown in Figure 29.



**Figure 29**      **Disconnecting the Storage Tray Assembly**

Field Replaceable Units  
FRU Removal and Replacement

- 4 Hold the storage tray with both hands and slide it toward the front of the main tray approximately an inch, then lift it straight up to remove it.



**Figure 30**      **Removing the Storage Tray Assembly**

---


**NOTICE:**

When replacing the storage tray, use the following procedure:

- a Align the pins on the backpanel of the main tray with the holes on the rear of the storage tray and slide the storage tray onto the pins. See Figure 30.
- b Lower the front of the storage tray and move it slightly forward or backward to align the pins on its side with the slots on the main tray.
- c Slide the storage tray towards the rear of the main tray until the pins are fully seated in the main tray slots.
- d Replace and tighten the storage tray retaining screw.

### Storage Tray Cover

To remove the storage tray cover press in the two cover locking tabs then lift the front end of the cover and slide it forward off of the pins in the rear, as shown in Figure 31.



**Figure 31**      **Removing the Storage Tray Cover**

### Disk Filler Panel


---

**NOTICE:** If you remove a disk filler panel, you must replace it or install a removable media storage device in its place.

---

Before removing a disk filler panel, remove the Storage Tray Assembly.

To remove a disk filler panel, insert a coin or other blunt object into the groove where the filler panel meets the bezel and gently pry it out, as shown in Figure 32.



**Figure 32**      **Removing a Disk Filler Panel**

### CD-ROM Drive or DDS Tape Drive

Before removing the CD-ROM drive or DDS Tape drive, perform the following procedures:

- Remove the Main Tray Assembly.
- Remove the Storage Tray Assembly.
- Remove the Storage Tray Cover.

---

**NOTICE:**

---

Refer to Chapter 3 for supported storage tray configurations.

Perform the following steps to remove a CD-ROM drive or DDS tape drive:

- 1 Push in the locking tabs on each side of the disk tray and slide the device out approximately two inches, as shown in Figure 33.




Figure 33

Removing a CD-ROM Drive or DDS Tape Drive

---

Field Replaceable Units  
**FRU Removal and Replacement**

- 2 Disconnect the power and data cables from the device.
- 3 Slide the device completely out of the storage tray and place it on a static-free surface.

### 3.5-Inch Floppy Disk Drive

Perform the following procedures before removing a floppy disk drive:

- Remove the Main Tray Assembly from the system unit.
- Remove the Storage Tray Cover.

---

**NOTICE:**


The Storage Tray Assembly does not have to be removed from the Main Tray to access a hard disk drive or the 3.5-inch floppy drive.

Refer to chapter 3 for supported storage tray configurations.

---

Perform the following steps to remove a floppy disk drive from the system unit:

- 1 Disconnect the cable from the floppy disk drive, as shown in Figure 34.




**Figure 34**

**Disconnecting the Floppy Drive Cable**

Field Replaceable Units  
FRU Removal and Replacement


- 2 Lift the rear of the floppy disk carrier, push the carrier toward the rear of the disk tray, then lift the front of the floppy disk carrier from the Storage Tray, as shown in Figure 35.



**Figure 35**      **Removing the Floppy Disk Carrier**



- 3 Lift the floppy drive straight up to remove it from the floppy carrier, as shown in Figure 36.



**Figure 36**      **Removing the Floppy Disk Drive**

---

**NOTICE:**

When replacing the floppy drive in the carrier, make sure to align the pin in the carrier with the hole in the floppy drive. See Figure 33.

When replacing the floppy carrier in the storage tray, set the mounting pins near the front of the storage tray in place first, then push the carrier toward the front of the storage tray slightly and set the rear mounting pins in place. Push down firmly on the rear of the carrier to ensure that the carrier is fully locked in place.

---

### Hard Disk Drive

Perform the following procedures before removing a hard disk drive.

- Remove the Main Tray Assembly from the system unit.
- Remove the Storage Tray Cover.
- Remove the floppy disk drive if you are removing a hard disk drive in the front position of the Storage Tray.

---

**NOTICE:**

The Storage Tray Assembly does not have to be removed from the Main Tray to access a hard disk drive in the rear position or the 3.5-inch floppy drive.


Refer to Chapter 3 for supported storage tray configurations.

---

Perform the following steps to remove a hard disk drive from the storage tray:

- 1 Disconnect the power and data cables from the disk drive.

- 
- 2** Push the locking tab toward the drive and hold it there while simultaneously sliding the drive toward the front of the storage tray, as shown in Figure 37.



**Figure 37**      **Removing a Hard Disk Drive**

- 
- 
- 3** Lift the drive straight up to remove it from the Storage Tray.

### Removing EISA, GSC, and PCI Option Boards

Before removing EISA, GSC, or PCI option boards from the system unit, remove the Main Tray Assembly from the system unit.

---


**NOTE:**

Slot 1 supports GSC or PCI option boards; slot 2 supports EISA, GSC, or PCI option boards.

---

Perform the following steps to remove an EISA, GSC, or PCI option board:

- 1 Push in the locking tab and slide the option board support bracket toward the rear of the main tray to remove it, as shown in Figure 38.




**Figure 38**      **Removing an EISA, GSC, or PCI Option Board**

- 2 Remove the option board retaining screw, as shown in Figure 38.
- 3 Grasp the option board by the edge with both hands and pull it straight out.

---

**NOTICE:** If you are **not** replacing the board, perform the following procedure:

- a Install a blank plate in the rear panel, as shown in Figure 39
- b Perform Steps 2 through 1 in reverse order.



**Figure 39**      **Installing an Option Slot Blank Plate**

Field Replaceable Units  
**FRU Removal and Replacement**

**CPU Board Assembly**

Before removing the CPU board assembly perform the following procedures:

- Remove the Main Tray Assembly from the system unit.
- Remove the Storage Tray Assembly from the Main Tray Assembly.

If you are replacing the original CPU board with a new one, refer to the section, “Determining LAN ID” below **before** removing the board.

### Determining LAN ID

Enter the following at the prompt:

```
/usr/sbin/lanscan
```

The output is similar to the following:

Hardware Path	Station Address	Dev lu	Hardware State	Net-Interface Name	Interface Unit State	NM ID	Encapsulation Methods	Mjr Num
2.0.2	0x08000970ECC0	0	UP	lan0	UP	4	ETHER	52

An alternative way to find the system's LAN ID is to use the following command at the information menu of the Boot Console Handler:

### **lanaddress**

The "Station Address" represents the EtherLAN ID (ignore the "0x" in the number).

After you install the new CPU board and power on the system for the first time, you are prompted for the LAN ID. Record the information here so you have a record of it:

EtherLAN ID \_\_\_\_\_-\_\_\_\_\_


You must supply the dash (-) between the first six digits and the last six digits.

Field Replaceable Units  
FRU Removal and Replacement

**Removing the CPU Board**

Perform the following steps to remove the CPU board from the main tray:

- 1 Pull the two ejector handles at the same time, as shown in Figure 40.



**Figure 40**      **Removing the CPU Board**

- 2 Slide the CPU board out of the main tray.

***NOTICE:***

Before installing a CPU board assembly, swing the card ejectors out to the fully open position. After sliding the CPU assembly into place, push firmly on the ejector handles to fully seat the CPU board connector in the backplane.



### Optional EGRAM Module

Before removing the optional EGRAM (System Graphics RAM) module, perform the following procedures:

- Remove the Main Tray Assembly from the system unit.
- Remove the Storage Tray Assembly from the Main Tray Assembly.
- Remove the CPU board assembly from the Main Tray.

Perform the following procedure to remove the EGRAM module:

- 1 To release the EGRAM module from the standoffs, use a pair of needle-nose pliers to squeeze the tabs on the standoffs while lifting the corner of the EGRAM module slightly, as shown in Figure 41.




Figure 41

Removing the Optional EGRAM Module

Field Replaceable Units  
**FRU Removal and Replacement**

- 2 Grasp the EGRAM module from the sides and pull it straight up to disconnect it from the CPU board connector, as shown in Figure 41.

---

***NOTICE:***

When replacing the EGRAM module make sure that its connector is correctly aligned with the connector on the CPU board and press down firmly to make sure that it is fully connected. Press down on the corners of the module to make sure that the standoffs are fully engaged.

If you are moving the EGRAM module to a new CPU board assembly, from the underside of the CPU board assembly use a pair of needle-nose pliers to squeeze the tabs on the standoffs and push them out of the CPU board. Transfer the standoffs to the new CPU board.


---

### System Fans and Speaker

Before removing the fans, remove the Main Tray Assembly from the system unit.

Perform the following steps to remove the system fans:

- 1 Locate the desired fan or speaker connector on the backplane, push in the tab on the connector and disconnect it from the backplane, as shown in Figure 42.




**Figure 42**      **Disconnecting the Fan and Speaker Connectors**

- 2 Pull up on the fan or speaker wire to remove it from the slot in the backplane or fan shroud.

Field Replaceable Units  
FRU Removal and Replacement

- 3 Lift the fan out of the top of the fan shroud, or pull the speaker out of the front of the fan shroud, as shown in Figure 43.




**Figure 43**      **Removing the System Fans and Speaker**

## Battery

Before removing the battery, perform the following procedures:

- Remove the Main Tray
- Remove the Storage Tray

Lift the clip and slip the battery out of its holder, as shown in Figure 44.



**Figure 44**      **Removing the Battery**

---

**CAUTION:**

Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer.

---

**ATTENTION:**

Il y a danger d'explosion s'il y a remplacement incorrect de la batterie. Remplacer uniquement avec une batterie du même type ou d'un type recommandé par le constructeur. Mettre au rebut les batteries usagées conformément aux instructions du fabricant.


---

Field Replaceable Units  
FRU Removal and Replacement

**Power Supply**


Before removing the power supply, remove the Main Tray Assembly.

- 1 Remove the option board support bracket by pushing in on the locking tab and sliding it toward the rear of the main tray, as shown in Figure 45.



**Figure 45**      **Removing the Option Board Support Bracket**

- 2 Remove the two power supply retaining screws, as shown in Figure 46.



**Figure 46**      **Removing the Power Supply**

- 3 Pull the power supply out of the side of the main tray, as shown in Figure 46.

***CAUTION:***


To avoid damage, be sure to use two hands to remove the power supply and pull it straight out.

Field Replaceable Units  
FRU Removal and Replacement

**Fast Wide SCSI Controller**

Before removing the FW SCSI controller, remove the main tray assembly.

To remove the FW SCSI controller, use a pair of needle-nose pliers to squeeze the tabs on the standoffs so that they will pass through the board and pull the board straight out from the backplane to disconnect it. See Figure 47.



**Figure 47**      **Removing the FW SCSI Controller**



### **Backplane**


Before removing the backplane, perform the following procedures:

- Remove the Main Tray Assembly
- Remove the Mass Storage Tray
- Remove the CPU Board
- Remove any EISA, GSC, or PCI option boards
- Remove (optional) Fast Wide SCSCI board.
- Remove the Power Supply

Field Replaceable Units  
FRU Removal and Replacement

Perform the following steps to remove the backplane:


- 1 Disconnect the two fan connectors and the speaker connector by pushing in on the connectors locking tab and pulling the connector, as shown in Figure 48.



**Figure 48**      **Disconnecting the Speaker and Fan Connectors**

- 2 Pull the fan and speaker cables out of the slots in the backplane and fan shroud and move them so that they are away from the backplane.

- 3 Lift the backplane on its standoffs and swing the right end out away from the backplane support, as shown in Figure 49.



**Figure 49**      **Removing the Backplane**

Field Replaceable Units  
**FRU Removal and Replacement**

---

**Diagrams and Pinouts**

## Diagrams and Pinouts

This chapter provides functional information about the system including tables which list pinouts for the following connectors:

- Backplane to System Board connector
- Backplane PCI connector
- FWSCSI board backplane connector
- Backplane EISA slot connector
- Backplane PCI slot connector (5.0V environment)
- Backplane GSC slot connector
- Backplane Fan connector
- Backplane Speaker connector
- System board DRAMM DIMM connector
- System board Cache DIMM connector
- System board Disk Tray SCSI connector
- System board Disk Tray power connector
- System board Disk Tray CD-ROM Audio connector
- Optional FWSCSI board to Disk Tray FWSCSI connector
- System Fan connector
- Parallel Port connector
- Single-Ended SCSI connector
- SGRAM connector
- AUI connector
- Serial Port connector
- PS/2 connector

## System Power

This section provides information on the connectors and pinouts in the B132L/B132L+/B160L/B180L workstation.

Table 15 lists the pinouts for the Backplane to System Board primary connector.

**Table 15 Backplane to System Board Connector**

Pin Number	Row A	Row B	Row C	Row D
1	P12v_aud	spare(0)	bp_id(0)	speaker(0)
2	N12v_aud	gnd	bp_id(1)	speaker(1)
3	spare(1)	spare(3)	gnd	VDL
4	spare(2)	spare(4)	vfan_ps_minus	+5V
5	gnd	vfan_plus	fan_ps_pulse	VDL
6	gsc_syncH_sl1	VDL	vfan_cpu_minus	+5V
7	gsc_syncL_sl1	supply_onL	fan_cpu_pulse	VDL
8	gnd	buf_lasi_brL	gnd	+5V
9	gsc_syncH_sl2	gsc_brL_sl1	gsc_brL_fwscsi	VDL
10	gsc_syncL_sl2	gnd	gsc_bgL_fwscsi	+5V
11	gnd	gsc_bgL-sl1	gsc_brL_wax	VDL
12	gsc_syncH_fwscsi	gs_brL_sl2	gnd	+5V
13	gsc_syncL_fwscsi	gnd	gsc_bgL_wax	VDL
14	gnd	gsc_bgL_sl2	gsc_interruptL	+5V
15	gsc_syncH_wax	gsc_lsL	gsc_brL_dino	VDL
16	gsc_syncL_wax	gnd	gnd	+5V
17	gnd	gsc_addvL	gsc_bgL_dino	VDL
18	gsc_syncH_dino	gsc_errorL	gsc_type(0)	+5V
19	gsc_syncL_dino	gnd	gsc_type(1)	VDL
20	gnd	gsc_readyL	gnd	+5V
21	gsc_resetL_sl1	gnd	gsc_type(2)	VDL
22	gsc_resetL_sl2	gsc_parity	gsc_type(3)	gnd

Diagrams and Pinouts  
System Power

**Table 15 Backplane to System Board Connector**

Pin Number	Row A	Row B	Row C	Row D
23	gnd	gnd	gsc_ad(31)	VDL
24	gsc_resetL_fwscsi	gsc_ad(30)	gnd sense	+5V_sense
25	gsc_resetL_wax	gnd	gsc_ad(29)	VDL_sense
26	gsc_resetL_dino	gsc_ad(28)	gnd	VDL
27	gnd	gnd	gsc_ad(27)	gnd
28	gsc_ad(26)	gsc_ad(25)	gsc_ad(24)	VDL
29	gsc_ad(23)	gnd	gsc_ad(22)	+5VSTBY
30	gsc_ad(21)	gsc_ad(20)	gnd	VDL
31	gsc_ad(19)	gnd	gsc_ad(18)	+5V
32	gnd	gsc_ad(17)	gsc_ad(16)	VDL
33	gsc_ad(15)	GND	gsc_ad(14)	+5V
34	gsc_ad(13)	gsc_ad(12)	gnd	VDL
35	gsc_ad(11)	gnd	gsc_ad(10)	+5V
36	gnd	gsc_ad(9)	gsc_ad(8)	VDL
37	gsc_ad(7)	gnd	gsc_ad(6)	+5V
38	gsc_ad(5)	gsc_ad(4)	gnd	VDL
39	gsc_ad(3)	gnd	gsc_ad(2)	+5V
40	gnd	gsc_ad(1)	gsc_ad(0)	VDL
41	gsc_retryL	gnd	gsc_packL	+5V
42	gsc_gscL	gsc_drrL	gnd	VDL
43	clk_40Mhz	VDL	gsc_pendL	hil_si
44	gnd	pon_resetL	gsc_xqL	VDL
45	serial2_txd	serial2_rts	gnd	hil_si
46	serial2_rxd	serial2_ri	serial2_dtr	-12V
47	+12V	gnd	serial2_dsr	+12V
48	+12V	serial2_cts	serial2_dcd	+12V



Table 16 lists the pinouts for the Backplane PCI connector.

**Table 16 Backplane PCI Connector**

Pin Number	Row A	Row B	Row C	Row D
1	pci_par	GND	pci_spar(0)	VDL
2	pci_serrL	pci_ad(0)	pci_ad(1)	VDD
3	GND	pci_ad(2)	pci_ad(3)	VDL
4	pci_sboL	GND	pci_ad(4)	pci_rstL
5	pci_sdone	pci_ad(5)	pci_ad(6)	VDD
6	GND	pci_ad(7)	pci_cbeL(0)	VDL
7	pci_perrL	GND	pci_ad(8)	pci_intdL
8	pci_lockL	pci_ad(9)	pci_ad(10)	VDL
9	pci_stopL	GND	pci_ad(11)	VDD
10	GND	pci_ad(12)	pci_ad(13)	VDL
11	pci_clk(3)	pci_ad(14)	pci_ad(15)	VDD
12	pci_clk(4)	GND	pci_cbeL(1)	pci_inteL
13	pci_clk(5)	pci_ad(16)	pci_ad(17)	VDD
14	GND	pci_ad(18)	pci_ad(19)	VDL
15	pci_devselL	GND	pci_ad(20)	pci_intbL
16	pci_trdyL	pci_ad(21)	pci_ad(22)	VDD
17	pci_trdyL	GND	pci_ad(23)	pci_intaL(5)
18	GND	pci_cbeL(2)	pci_ad(24)	VDL
19	pci_frameL	pci_ad(25)	pci_ad(26)	VDD
20	pci_ad(27)	GND	pci_ad(28)	pci_intaL(4)
21	pci_ad(29)	pci_ad(30)	pci_ad(31)	VDL
22	GND	pci_reqL(3)	pci_cbeL(3)	VDD
23	pci_reqL(4)	GND	pci_reqL(5)	pci_intaL(3)
24	pci_gntL(3)	pci_gntL(4)	pci_gntL(5)	VDD

Diagrams and Pinouts  
System Power

Table 17 lists the pinouts for the Backplane Optional Fast-Wide SCSI board connector.

**Table 17 FWSCSI Board Backplane Connector**

Pin Number	Row A	Row B	Row C	Row D
1	VDD	VDD	gsc_syncH	gsc_syncL
2	gsc_resetL	GND	VDL	VDL
3	GND	init_addr(1)	VDD	gsc_lsL
4	gsc_brL	VDD	GND	gsc_bgL
5	gsc_addvL	gsc_errorL	VDD	gsc_readyL
6	gsc_parity	GND	gsc_type(0)	gsc_type(1)
7	GND	gsc_type(2)	gsc_type(3)	VDD
8	gsc_ad(31)	gsc_ad(30)	VDD	gsc_ad(29)
9	gsc_ad(28)	GND	gsc_ad(27)	gsc_ad(26)
10	GND	gsc_ad(25)	gsc_ad(24)	VDD
11	gsc_ad(23)	gsc_ad(22)	VDD	gsc_ad(21)
12	gsc_ad(20)	GND	gsc_ad(19)	gsc_ad(18)
13	GND	gsc_ad(17)	gsc_ad(16)	VDD
14	gsc_ad(15)	gsc_ad(14)	VDD	gsc_ad(13)
15	gsc_ad(12)	GND	gsc_ad(11)	gsc_ad(10)
16	GND	gsc_ad(9)	gsc_ad(8)	VDD
17	gsc_ad(7)	gsc_ad(6)	VDD	gsc_ad(5)
18	gsc_ad(4)	GND	gsc_ad(3)	gsc_ad(2)
19	GND	gsc_ad(1)	gsc_ad(0)	VDD
20	gsc_retryL	gsc_packL	VDD	gsc_pendL
21	gsc_dirL	gsc_xqL	GND	GND
22	init_addr(0)	pwr_rsL	GND	init_addr(2)
23	VDL	VDL	gsc_gscL	init_addr(3)
24	clk33Mhz	GND	GND	clk40Mhz

Table 18 lists the pinouts for the Backplane to EISA Slot connector for rows F, B, E, and A. Table 18 lists the pinouts for rows H, D, G, and C.

**NOTE:** Rows A, C, F, and H are Upper (ISA) contacts. Rows B, D, E, and G are Lower (EISA) contacts.

**Table 18 Backplane EISA Slot Connector (Rows F, B, E, and A)**

Pin	Row F	Row B	Row E	Row A
1	GND	GND	CMD	IOCHK
2	+5V	RESDRV	START	D<7>
3	+5V	+5V	EXRDY	D<6>
4	X	IRQ<9>	EX32	D<5>
5	X	-5V	GND	D<4>
6	ACCESS KEY	DRQ<2>	ACCESS KEY	D<3>
7	X	-12V	EX16	D<2>
8	X	NOWS	SLBURST	D<1>
9	+12V	+12V	MSBURST	D<0>
10	M-IO	GND	W-R	CHRDY
11	LOCK	SMWTC	GND	AENx
12	RESERVED	SMRDC	RESERVED	SA<19>
13	GND	IOWC	RESERVED	SA<18>
14	RESERVED	IORC	RESERVED	SA<17>
15	BE<3>	DAK<3>	GND	SA<16>
16	ACCESS KEY	DRQ<3>	ACCESS KEY	SA<15>
17	BE<2>	DAK<1>	BE<1>	SA<14>
18	BE<0>	DRQ<1>	LA<31>	SA<13>
19	GND	REFRESH	GND	SA<12>
20	+5V	BCLK	LA<30>	SA<11>
21	LA<29>	IRQ<7>	LA<28>	SA<10>

Diagrams and Pinouts  
System Power

**Table 18 Backplane EISA Slot Connector (Rows F, B, E, and A)**

Pin	Row F	Row B	Row E	Row A
22	GND	IRQ<6>	LA<27>	SA<9>
23	LA<26>	IRQ<5>	LA<25>	SA<8>
24	LA<24>	IRQ<4>	GND	SA<7>
25	ACCESS KEY	IRQ<3>	ACCESS KEY	SA<6>
26	LA<16>	DAK<2>	LA<15>	SA<5>
27	LA<14>	T-C	LA<13>	SA<4>
28	+5V	BALE	LA<12>	SA<3>
29	+5V	+5V	LA<11>	SA<2>
30	GND	OSC	GND	SA<1>
31	LA<10>	GND	LA<9>	SA<0>

**Table 19 Backplane EISA Slot Connector (Rows H, D, G, and C)**

Pin	Row H	Row D	Row G	Row C
1	LA<8>	M16	LA<7>	SHBE
2	LA<6>	IO16	GND	LA<23>
3	LA<5>	IRQ<10>	LA<4>	LA<22>
4	+5V	IRQ<11>	LA<3>	LA<21>
5	LA<2>	IRQ<12>	GND	LA<20>
6	ACCESS KEY	IRQ<15>	ACCESS KEY	LA<19>
7	D<16>	IRQ<14>	D<17>	LA<18>
8	D<18>	DAK<0>	D<19>	LA<17>
9	GND	DRQ<0>	D<20>	MRDC
10	D<21>	DAK<5>	D<22>	MWTC
11	D<23>	DRQ<5>	GND	D<8>
12	D<24>	DAK<6>	D<25>	D<9>

**Table 19**                      **Backplane EISA Slot Connector (Rows H, D, G, and C)**

<b>Pin</b>	<b>Row H</b>	<b>Row D</b>	<b>Row G</b>	<b>Row C</b>
13	GND	DAK<6>	D<26>	D<10>
14	D<27>	DAK<7>	D<28>	D<11>
15	ACCESS KEY	DRQ<7>	ACCESS KEY	D<12>
16	D<29>	+5V	GND	D<13>
17	+5V	MASTER16	D<30>	D<14>
18	+5V	GND	D<31>	D<15>
19	MAKx		MREQx	

Diagrams and Pinouts  
System Power

Table 20 lists the pinouts for the Backplane PCI slot connector in a 5.0V environment.

**Table 20 Backplane PCI Slot Connector (5.0V Environment)**

Pin	Side B	Side A	Pin	Side B	Side A
1	-12V	TRST#	32	AD[17]	AD[16]
2	TCK	+12V	33	C/BE[2]#	+3.3V
3	Ground	TMS	34	Ground	FRAME#
4	TDO	TDI	35	IRDY#	Ground
5	+5V	+5V	36	+3.3V	TRDY#
6	+5V	INTA#	37	DEVSEL#	Ground
7	INTB#	INTC#	38	Ground	STOP#
8	INTD#	+5V	39	LOCK#	+3.3V
9	PRSNT1#	Reserved	40	PERR#	SDONE
10	Reserved	+5.0V (I/O)	41	+3.3V	SBO#
11	PRSNT2#	Reserved	42	SERR#	Ground
12	Ground	Ground	43	+3.3V	PAR
13	Ground	Ground	44	C/BE[1]#	AD[15]
14	Reserved	Reserved	45	AD[14]	+3.3V
15	Ground	RST#	46	Ground	AD[13]
16	CLK	+5.0V (I/O)	47	AD[12]	AD[11]
17	Ground	GNT#	48	AD[10]	Ground
18	REQ#	Ground	49	Ground	AD[09]
19	+5.0V (I/O)	Reserved	50	Connector key	Connector key
20	AD[31]	AD[30]	51	Connector key	Connector key
21	AD[29]	AD[28]	52	AD[08]	C/BE[0]#
22	Ground	Ground	53	AD[07]	+3.3V
23	AD[27]	AD[26]	54	+3.3V	AD[06]

**Table 20 Backplane PCI Slot Connector (5.0V Environment)**

Pin	Side B	Side A	Pin	Side B	Side A
24	AD[25]	Ground	55	AD[05]	AD[04]
25	+3.3V	AD[24]	56	AD[03]	Ground
26	C/BE[3]#	IDSEL	57	Ground	AD[02]
27	AD[23]	+3.3V	58	AD[01]	AD[00]
28	Ground	AD[22]	59	+5.0V (I/O)	+5.0V (I/O)
29	AD[21]	AD[20]	60	ACK64#	REQ64#
30	AD[19]	Ground	61	+5V	+5V
31	+3.3V	AD[18]	62	+5V	+5V

Table 21 lists the power pinouts for the Backplane GSC Slot Connector.

**Table 21 Backplane GSC Slot Connector**

Pin	Signal	Pin	Signal
1	+12V	51	-12V
2	+5V	52	+5V
3	GSC_SYNC	53	GSC_SYNC_L
4	GND	54	GND
5	+3.3v	55	+3.3V
6	GSC_RESET_L	56	GSC_INT_L
7	+5V	57	GSC_LS_L
8	GSC_BR_L(1)	58	+5V
9	GND	59	GSC_BG_L
10	GSC_ADDV_L	60	GSC_ERROR_L
11	+5V	61	GSC_READY_L
12	GSC_PARITY	62	GND

**Table 21** **Backplane GSC Slot Connector**

Pin	Signal	Pin	Signal
13	GSC_TYPE_(0)	63	GSC_TYPE(1)
14	GND	64	GSC_TYPE(2)
15	GSC_TYPE(3)	65	+5V
16	GSC_AD(31)	66	GSC_AD(30)
17	+5V	67	GSC_AD(29)
18	GSC_AD(28)	68	GND
19	GSC_AD(27)	69	GSC_AD(26)
20	gnd	70	GSC_AD(25)
21	GSC_AD(24)	71	+5V
22	GSC_AD(23)	72	GSC_AD(22)
23	+5V	73	GSC_AD(21)
24	GSC_AD(20)	74	GND
25	GSC_AD(19)	75	GSC_AD(18)
26	GND	76	GSC_AD(17)
27	GSC_AD(16)	77	+5V
28	GSC_AD(15)	78	GSC_AD(14)
29	+5V	79	GSC_AD(13)
30	GSC_AD(12)	80	GND
31	GSC_AD(11)	81	GSC_AD(10)
32	GND	82	GSC_AD(9)
33	GSC_AD(8)	83	+5V
34	GSC_AD(7)	84	GSC_AD(6)
35	+5V	85	GSC_AD(5)
36	GSC_AD(4)	86	GND
37	GSC_AD(3)	87	GSC_AD(2)
38	GND	88	GSC_AD(1)



**Table 21**                      **Backplane GSC Slot Connector**

<b>Pin</b>	<b>Signal</b>	<b>Pin</b>	<b>Signal</b>
39	GSC_AD(0)	89	+5V
40	GSC_RETRY_L	90	GSC_PACK_L
41	+5V	91	GSC_PEND_L
42	GSC_DRR_L	92	GSC_XQ_L
43	GND	93	GND
44	GSC_TDO	94	TDI
45	TMS	95	PON_RESET_L
46	GND	96	TCK
47	+3.3V	97	+5V
48	GSC_GSC_L	98	GSC_PWRFAIL
49	OFFSET(?)	99	OFFSET(?)
50	OFFSET(?)	100	OFFSET(?)

Table 22 lists the Backplane Fan connector pinouts.

**Table 22**                      **Backplane Fan Connector**

<b>Pin</b>	<b>Signal</b>
1	FAN_PS_PULSE
2	VFAN
3	SAFETY+12V

Diagrams and Pinouts  
System Power

Table 23 lists pinouts for the Backplane Speaker connector.

**Table 23** **Backplane Speaker Connector**

Pin	Signal
1	SPEAKER 0
2	SPEAKER 1

Table 24 lists the pinouts for the System Board DRAMM DIMM connector.

**Table 24** **System Board DRAMM DIMM Connector**

Pin	Signal	Pin	Signal
1	GND	73	+5V
2	AD_0(1)	74	AD_0(2)
3	AD_0(3)	75	AD_0(4)
4	AD_0(5)	76	GND
5	AD_0(7)	77	AD_0(6)
6	GND	78	AD_0(8)
7	AD_0(9)	79	AD_0(10)
8	AD_0(11)	80	AD_0(12)
9	AD_0(13)	81	+5V
10	GND	82	D(1)/D(65)
11	D(0)/D(64)	83	D(3)/D(67)
12	+5V	84	D(5)/D(69)
13	D(2)/D(66)	85	D(7)/D(71)
14	D(4)/D(68)	86	GND
15	D(6)/D(70)	87	D(9)/D(73)
16	GND	88	D(11)/D(77)

**Table 24**                      **System Board DRAMM DIMM Connector**

<b>Pin</b>	<b>Signal</b>	<b>Pin</b>	<b>Signal</b>
17	D(8)/D(72)	89	D(13)/D(77)
18	D(10)/D(74)	90	D(15)/D(79)
19	D(12)/D(76)	91	GND
20	D(14)/D(78)	92	D(17)/D(81)
21	GND	93	D(19)/D(83)
22	D(16)/D(80)	94	D(21)/D(85)
23	D(18)/D(82)	95	D(23)/D(87)
24	D(20)/D(84)	96	GND
25	D(22)/D(86)	97	D(25)/D(89)
26	GND	98	D(27)/D(91)
27	D(24)/D(88)	99	+5V
28	D(26)/D(90)	100	D(29)/D(93)
29	D(28)/D(92)	101	GND
30	D(30)/D(94)	102	D(31)/D(95)
31	GND	103	ECC(1)/ECC(9)
32	ECC(0)/ECC(8)	104	ECC(3)/ECC(11)
33	ECC(2)/ECC(10)	105	GND
34	GND	106	RAS_0
35	CAS_0	107	CAS_1
36	MOE_0	108	STD_L
37	EDO_L	109	MOE
38	MWE	110	CAS_1
39	RAS_1	111	GND
40	GND	112	D(33)/D(97)
41	D(32)/D(96)	113	D(35)/D(99)
42	+5V	114	D(37)/D(101)

Diagrams and Pinouts  
System Power

**Table 24**                      **System Board DRAMM DIMM Connector**

<b>Pin</b>	<b>Signal</b>	<b>Pin</b>	<b>Signal</b>
43	D(34)/D(98)	115	D(39)/D(103)
44	D(36)/D(100)	116	GND
45	D(38)/D(102)	117	D(41)/D(105)
46	GND	118	D(43)/D(107)
47	D(40)/D(104)	119	D(45)/D(109)
48	D(42)/D(106)	120	D(47)/D(111)
49	D(44)/D(108)	121	GND
50	D(46)/D(110)	122	D(49)/D(113)
51	GND	123	D(51)/D(115)
52	D(48)/D(112)	124	GND
53	D(50)/D(114)	125	D(53)/D(117)
54	D(52)/D(116)	126	GND
55	D(54)/D(118)	127	D(55)/D(119)
56	GND	128	D(57)/D(121)
57	D(56)/D(120)	129	D(59)/D(123)
58	D(58)/D(122)	130	D(61)/D(125)
59	D(60)/D(124)	131	GND
60	D(62)/D(126)	132	D(63)/D(127)
61	GND	133	ECC(5)/ECC(13)
62	ECC(4)	134	ECC(6)/ECC(14)
63	GND	135	ECC(7)/ECC(15)
64	AD_1(13)	136	GND
65	AD_1(11)	137	AD_1(12)
66	AD_1(9)	138	AD_1(10)
67	GND	139	AD_1(8)
68	AD_1(7)	140	AD_1(6)

**Table 24**                      **System Board DRAMM DIMM Connector**

<b>Pin</b>	<b>Signal</b>	<b>Pin</b>	<b>Signal</b>
69	AD_1(5)	141	GND
70	AD_1(3)	142	AD_1(4)
71	AD_1(1)	143	AD_1(2)
72	GND	144	+5V

Table 25 lists the power pinouts for the System Board Cache DIMM connector.

**Table 25**                      **System Board Cache DIMM Connector**

<b>Pin</b>	<b>Signal</b>	<b>Pin</b>	<b>Signal</b>
1	Cache ID(0)	85	Cache ID(1)
2	D(0)/D(64)	86	GND
3	D(2)/D(66)	87	D(1)/D(65)
4	+3V	88	D(3)/D(67)
5	D(4)/D(68)	89	GND
6	D(6)/D(70)	90	D(5)/D(69)
7	+3V	91	D(7)/D(71)
8	D(8)/D(72)	92	GND
9	D(10)/D(74)	93	D(9)/D(73)
10	+3V	94	D(11)/D(75)
11	D(12)/D(76)	95	GND
12	D(14)/D(78)	96	D(13)/D(77)
13	+3V	97	D(15)/D(79)
14	D(16)/D(80)	98	GND
15	D(18)/D(82)	99	D(17)/D(81)
16	+3V	100	D(19)/D(83)

Diagrams and Pinouts  
System Power

**Table 25** System Board Cache DIMM Connector

Pin	Signal	Pin	Signal
17	D(20)/D(84)	101	GND
18	D(22)/D(86)	102	D(21)/D(85)
19	+3V	103	D(23)/D(87)
20	D(24)/D(88)	104	GND
21	D(26)/D(90)	105	D(25)/D(89)
22	+3V	106	D(27)/D(91)
23	D(28)/D(92)	107	GND
24	D(30)/D(94)	108	D(29)/D(93)
25	+3V	109	D(31)/D(95)
26	ECC(0)/ECC(8)	110	GND
27	ECC(2)/ECC(10)	111	ECC(1)/ECC(9)
28	+3V	112	ECC(3)/ECC(11)
29	SLTWCK	113	GND
30	SLT(0)/SLT(8)	114	SLT(1)/SLT(9)
31	+3V	115	SLA(14)
32	SLA(20)	116	GND
33	SLA(18)	117	SLA(26)
34	+3V	118	SLA(12)
35	SLA(22)	119	GND
36	SLA(14)	120	SLA(23)
37	+3V	121	SLA(10)
38	SLA(16)	122	GND
39	SLA(27)	123	SLA(15)
40	+3V	124	SLA(25)
41	+3V	125	GND
42	SLDWCK	126	SLDOE

**Table 25**                      **System Board Cache DIMM Connector**

Pin	Signal	Pin	Signal
43	+3V	127	SLTW
44	SLATV(13)	128	GND
45	SLA(8)	129	SLTOE
46	+3V	130	SLA(9)
47	SLA(17)	131	GND
48	SLA(6)	132	SLA(21)
49	+3V	133	SLA(11)
50	SLA(19)	134	GND
51	SLA(13)	135	SLATV_13
52	+3V	136	SLA(7)
53	SLT(2)/SLT(10)	137	GND
54	SLT(4)/SLT(14)	138	SLT(3)/SLT(11)
55	+3V	139	SLT(5)/SLT(13)
56	SLT(6)/SLT(14)	140	GND
57	D(32)/D(96)	141	SLT(7)/SLT(15)
58	+3V	142	D(33)/D(97)
59	D(34)/D(98)	143	GND
60	D(36)/D(100)	144	D(35)/D(99)
61	+3V	145	D(37)/D(101)
62	D(38)/D(102)	146	GND
63	D(40)/D(104)	147	D(39)/D(103)
64	+3V	148	D(41)/D(105)
65	D(42)/D(106)	149	GND
66	D(44)/D(108)	150	D(43)/D(107)
67	+3V	151	D(45)/D(109)
68	D(46)/D(110)	152	GND

Diagrams and Pinouts  
System Power

**Table 25** System Board Cache DIMM Connector

Pin	Signal	Pin	Signal
69	D(48)/D(112)	153	D(47)/D(111)
70	+3V	154	D(49)/D(113)
71	D(50)/D(114)	155	GND
72	D(52)/D(116)	156	D(51)/D(115)
73	+3V	157	D(53)/D(117)
74	D(54)/D(118)	158	GND
75	D(56)/D(120)	159	D(55)/D(119)
76	+3V	160	D(57)/D(121)
77	D(58)/D(122)	161	GND
78	D(60)/D(124)	162	D(59)/D(123)
79	+3V	163	D(61)/D(125)
80	D(62)/D(126)	164	GND
81	ECC(4)/ECC(12)	165	D(63)/D(127)
82	+3V	166	ECC(5)/ECC(13)
83	ECC(6)/ECC(14)	167	GND
84	Cache ID(2)	168	ECC(7)/ECC(15)

Table 26 lists the pinouts for the Hard Disk Drive.

**Table 26** Hard Disk Drive Power Pinouts

Pin Number	Description	Wire Color
1	+12V	red
2	GROUND	black
3	GROUND	black
4	+5V	orange



Table 27 lists the pinouts for the System Board Disk Tray SCSI connector.

**Table 27**                      **System Board Disk Tray SCSI Connector**

Pin	Signal	Pin	Signal
1	GND	26	TERMPWR
2	D(0)	27	GND
3	GND	28	N/C
4	D(1)	29	GND
5	GND	30	GND
6	D(2)	31	GND
7	GND	32	ATN
8	D(3)	33	GND
9	GND	34	GND
10	D(4)	35	GND
11	GND	36	BUSY
12	D(5)	37	GND
13	GND	38	ACK
14	D(6)	39	GND
15	GND	40	RST
16	D(7)	41	GND
17	GND	42	MSG
18	DP	43	GND
19	GND	44	SEL
20	GND	45	GND
21	GND	46	CD
22	GND	47	GND
23	GND	48	REQ

Diagrams and Pinouts  
System Power

**Table 27**                      **System Board Disk Tray SCSI Connector**

Pin	Signal	Pin	Signal
24	N/C	49	GND
25	GND	50	IO

Table 28 lists the pinouts for the System Board Disk Tray connector.

**Table 28**                      **System Board Disk Tray Power Connector**

Pin	Signal	Pin	Signal
1	+5V	5	GND
2	+12V	6	GND
3	Safety +12V	7	VDISKFAN
4	N/C	8	N/C

Table 29 lists the pinouts for the System Board Disk Tray CD-ROM Audio connector.

**Table 29**                      **System Board Disk Tray CD-ROM Audio Connector**

Pin	Signal
1	GND
2	Right
3	Left

Table 30 lists the pinouts for the Optional Fast Wide SCSI Board to the Disk Tray Fast Wide SCSI connector.

**Table 30**                      **Optional FWSCSI Board to Disc Tray FWSCSI Connector**

Pin	Signal	Pin	Signal
1	PDB(12)	35	NBDB(12)
2	PDB(13)	36	NDB(13)
3	PDB(14)	37	NDB(14)
4	PDB(15)	38	NDB(15)
5	PPDP(1)	39	NDP(1)
6	GND	40	GND
7	PDB(0)	41	NDB(0)
8	PDB(1)	42	NDB(1)
9	PDB(2)	43	NDB(2)
10	PDB(3)	44	NDB(3)
11	PDB(4)	45	NDB(4)
12	PDB(5)	46	NDB(5)
13	PDB(6)	47	NDB(6)
14	PDB(7)	48	NDB(7)
15	PDP(0)	49	NDP(0)
16	DIFFSENS	50	EXT_SCSI_ON
17	TERMPWR	51	TERMPWR
18	TERMPWR	52	TERMPWR
19	N/C	53	N/C
20	PATN	54	NATN
21	GND	55	GND
22	PBSY	56	NBSY

Diagrams and Pinouts  
System Power

**Table 30**                      **Optional FWSCSI Board to Disc Tray FWSCSI Connector**

<b>Pin</b>	<b>Signal</b>	<b>Pin</b>	<b>Signal</b>
23	PACK	57	NACK
24	PRST	58	NRST
25	PMSG	59	NMSG
26	PSEL	60	NSEL
27	PCD	61	NCD
28	PREQ	62	NREQ
29	PIO	63	NIO
30	GND	64	GND
31	PDB(8)	65	NDB(8)
32	PDB(9)	66	NDB(9)
33	PDB(10)	67	NDB(10)
34	PDB(11)	68	NDB(11)

Table 31 lists the power pinouts for the System Fan.

**Table 31**                      **System Fan Power Pinouts**

<b>Pin Number</b>	<b>Description</b>	<b>Wire Color</b>
1	Power	N/A
2	GROUND	N/A

Table 32 lists the pinouts for the Parallel Port connector.

**Table 32**

**Parallel Port Connector Pinouts**

<b>Pin</b>	<b>Description</b>	<b>Pin</b>	<b>Description</b>
1	Strobe	14	AFD
2	D[0]	15	ERR
3	D[1]	16	INIT
4	D[2]	17	SLIN
5	D[3]	18	GROUND
6	D[4]	19	GROUND
7	D[5]	20	GROUND
8	D[6]	21	GROUND
9	D[7]	22	GROUND
10	ACK	23	GROUND
11	BUSY	24	GROUND
12	PE	25	GROUND
13	SLCT		

Diagrams and Pinouts  
System Power

Table 33 lists the pinouts for the Single-Ended SCSI connector.

**Table 33**      **Single-Ended SCSI Connector Pinouts**

<b>Pin</b>	<b>Description</b>	<b>Pin</b>	<b>Description</b>
1	Ground	26	D[0]
2	Ground	27	D[1]
3	Ground	28	D[2]
4	Ground	29	D[3]
5	Ground	30	D[4]
6	Ground	31	D[5]
7	Ground	32	D[6]
8	Ground	33	D[7]
9	Ground	34	Data Parity
10	Ground	35	Ground
11	Ground	36	Ground
12	Ground	37	Ground
13	NC	38	Term Power
14	Ground	39	Ground
15	Ground	40	Ground
16	Ground	41	ATN
17	Ground	42	Ground
18	Ground	43	BUSY
19	Ground	44	ACK
20	Ground	45	Ground
21	Ground	46	RST
22	Ground	47	SEL
23	Ground	48	CD

**Table 33**

**Single-Ended SCSI Connector Pinouts**

Pin	Description	Pin	Description
24	Ground	49	REQ
25	Ground	50	IO

Table 34 lists the pinouts for the SGRAM connector.

**Table 34**

**EGRAM Connector**

Pin	Description	Pin	Description
1	Audio Out, Right	18	USB/1394 Shield
2	Audio Out, Left	19	P1394 Return
3	Audio Out, Ret	20	P1394 Power
4	Sync Return	21	Audio In, Left
5	Horizontal Sync	22	Audio In, Right
6	Vertical Sync	23	Audio In, Return
7	Reserved	24	Stereo Sync
8	Reserved	25	DDC Return
9	P1394, A-	26	DDC Data
10	P1394, A+	27	DDC Clock
11	Power Charge +	28	+5 VDC
12	Power Charge -	29	P1394 B+
13	Video In, Y	30	P1394 B-
14	Video In, Return	C1	Red Video Output
15	Video In, C	C2	Green Video Output
16	USB+	C3	Pixel Clock Output
17	USB-	C4	Blue Video Output

Table 35 lists the pinouts for the AUI connector.

**Table 35**                      **AUI Connector Pinouts**

<b>Pin</b>	<b>Description</b>	<b>Pin</b>	<b>Description</b>
1	GND	9	CLSN <sub>n</sub>
2	CLSN	10	TRMT <sub>n</sub>
3	TRMT	11	GND
4	GND	12	RCV <sub>n</sub>
5	RCV	13	+12V
6	GND	14	GND
7	N/C	15	N/C
8	GND		

Table 36 lists the pinouts for the Serial Port connector.

**Table 36**                      **Serial Port Connector Pinouts**

<b>Pin</b>	<b>Description</b>	<b>Pin</b>	<b>Description</b>
1	DCD - Carrier Detect	6	DSR - Data Set Ready
2	RXD - Receive Data	7	RTS - Request to Send
3	TXD - Transmit Data	8	CTS - Clear to Send
4	DTR - Data Terminal Ready	9	RI - Ring Indicator
5	Ground		



Table 37 lists the pinouts for the P/S2 connector.

**Table 37**


**PS/2 Connector**

<b>Pin</b>	<b>Description</b>
1	Data
2	(HIL_SI/HIL_SO or N/C)
3	Ground
4	+5V
5	Clock
6	(+12V/Ground or N/C)

---

## System Block Diagrams


Figure 50 shows the system unit block diagram for B132L and B160L.



**Figure 50** System Unit Functional Block Diagram (B132L/  
B160L)

Diagrams and Pinouts  
System Block Diagrams

Figure 51 shows the system unit block diagram for B180L systems.



**Figure 51** System Unit Functional Block Diagram (B132L+/  
B180L)

---

**Reference**

## Reference

This chapter provides part numbers and titles to reference documents.

---

## **Installation Manual**

*Hardware Install Card Model B132L/B160L*  
A4190-90010

---

## **Service Manuals**

*Service Handbook B132L/B132L+/B160L/B180L*  
*Workstations (this handbook)* A4190-90041

*Precision Architecture RISC HP 9000 Series 700*  
*Diagnostics Manual* 92453-90010

*System Administration Tasks Manual HP Apollo 9000*  
*Series 700* B2355-90040

---

## **Reference Manuals**

*B132L/B132L+/B160L/B180L Owner's Guide* A4190-  
90023

*Installing the B132L/B160L CPU Upgrade*  
A4190-90012

*Installing the B132L/B160L to B180L CPU Upgrade*  
A4190-90018

Reference  
**Reference Manuals**



---

**Service Notes**

Service Notes

---

**Boot Console Interface**

## Boot Console Interface

The Boot Console Interface provides an “interactive” environment after the power-on sequence.

## Accessing the Boot Console Interface

To access the boot console interface, follow these steps:

---

***NOTICE:***

This procedure should be done by a system administrator.

- 1 Close any files and applications on your workstation.
- 2 Press the power switch on the front panel of the system unit.

---

***NOTICES:***

There is no need to manually shut down the HP-UX operating system on your workstation before powering it off. When you turn off the power switch, your workstation automatically shuts down the operating system before terminating the power.

Make sure that you do not unplug the system's power cord or otherwise interrupt power to the system unit at this time.

---

- 3 When the system has completely shut down, power on your workstation.

If **Autoboot** is turned off, the boot sequence automatically stops at the boot console Main Menu.

If **Autoboot** is turned on, you will see the following messages:

```
Processor is starting Autoboot process.  
To discontinue, press any key within 10  
seconds.
```

If **Autoboot** and **Autosearch** are both turned on, you will see the following messages:

```
Processor is booting from first avail-  
able device.To discontinue, press any  
key within 10 seconds.
```

---

**NOTICE:**

---

If you are using a power-saving monitor, you will have less than 10 seconds from the time this message appears to press a key.

- 4 Press a key. You will then see the message:

```
Boot terminated
```

The Main Menu of the boot console appears.

## Booting Your Workstation

Usually, you start your workstation by turning it on and waiting for HP-UX to boot automatically. However, you may not always want the usual sequence to occur.

For example, you may want to start your workstation from an operating system that is stored on a device that is different from your usual boot device. If your normal operating system kernel or the disk on which it resides becomes damaged or unusable, you may wish to boot from a different disk or perhaps another type of device, such as a DDS-format tape drive.

Here are some situations and examples:

- If you know which device you want to boot from, and you know that it contains a bootable operating system, follow the directions in “Accessing the Boot Console Interface” earlier in this appendix, and then type the following at the prompt:

```
Main Menu: Enter command > boot device
```

where *device* is the **hardware path** to the device, specified in Mnemonic Style Notation.

For example, if you wish to boot an operating system that is stored on a DDS-format tape in a drive that is located at “sescsi.1.0”, follow the directions in “Accessing the Boot Console Interface” earlier in this appendix, and then type the following command at the prompt:

```
Main Menu: Enter command > boot sescsi.1.0
```

The operating system on the specified device is used to start your workstation.

- If you wish to interact with the Initial System Loader

## Boot Console Interface

### Booting Your Workstation

(ISL) before booting your workstation, follow the directions in “Accessing the Boot Console Interface” earlier in this appendix, and then type the following at the prompt

```
Main Menu: Enter command > boot device
```

You are prompted:

```
Interact with ISL (Y,N,Q)>
```

Answering yes (**y**) causes the ISL to be loaded from the specified device. After a short time, the following prompt appears on your screen:

```
ISL>
```

ISL is the program that actually controls the loading of the operating system. By interacting with ISL, you can choose to load an alternate version of the HP-UX operating system. If you do not want ISL to be loaded, you must enter **no**.

For example, if the usual kernel (**/stand/vmunix**) on your root disk (**fwscsi.6.0**) has become corrupted, and you wish to boot your workstation from the backup kernel (**/stand/vmunix.prev**), type the following at the ISL> prompt:

```
ISL> hpux /stand/vmunix.prev
```

- If you do not know which media in your file systems have bootable operating systems, you can find them with the **search IPL** command.



## Searching for Bootable Media

To list devices that contain bootable media, follow the directions in “Accessing the Boot Console Interface” earlier in this appendix, and then type the following at the prompt:

```
Main Menu: Enter command > search ipl
```

The search command searches all buses. The search may turn up more devices than there are lines on your display. If you are using a text terminal, you may control the progress of the search from your terminal’s keyboard by performing the following steps:

- To hold the display temporarily, press **Ctrl S**
- To continue the display, press **Ctrl Q**
- To halt the search, press any other key

These flow-control commands do not work with a bit-mapped display, but such a display can show more than forty lines of text, so you are unlikely to need them.

To search for devices of *just one type* that actually contain bootable media, follow the directions in “Accessing the Boot Console Interface” earlier in this appendix, and then type the following at the prompt:

```
Main Menu: Enter command> search ipl device_type
```

Boot Console Interface  
Searching for Bootable Media

Where *device\_type* is one of the following:

**fwscsi** is the built-in fast, wide differential SCSI bus or the built-in ultra, wide single-ended SCSI bus

**sescsi** is the built-in single-ended SCSI bus

**lan** is all connections to the built-in LAN

**gscn** is an optional FW SCSI interface in slot number *n*

## Resetting Your Workstation

To reset your workstation, follow the directions in “Accessing the Boot Console Interface” earlier in this appendix, and then type the following at the prompt:

```
Main Menu: Enter command > reset
```

To reset your workstation to its predefined values, follow the directions in “Accessing the Boot Console Interface” earlier in this appendix, and then type the following at the prompt to access the Configuration Menu:

```
Main Menu: Enter command > co
```

When the Configuration Menu appears, type the following at the prompt:

```
Config Menu:Enter command> default
```

## Displaying and Setting Paths

A **path** is the hardware address of a device that is attached to the I/O system of your workstation. The **path** command sets the system paths shown in Table 38.

The **path** command sets and displays the hardware address of a specified device attached to the I/O bus of your workstation.

**Table 38**                      **System Paths**

<b>Path Type</b>	<b>Device</b>
<b>primary</b> or <b>pri</b>	Your workstation's default boot device (usually the root disk)
<b>alternate</b> or <b>alt</b>	Your workstation's alternate boot device (usually a DDS-format tape device)
<b>console</b> or <b>con</b>	Your workstation's primary display device
<b>keyboard</b> or <b>key</b>	Your workstation's primary ASCII input device

To display the current settings for the system paths, type the following at the prompt:

```
Main Menu: Enter command > path
```

The paths are displayed in **Mnemonic Style Notation**, as shown in Table 39.

**Table 39** Mnemonic Style Notation

I/O Type	Specification Format
Built-in FWSCSI	<b>fwsci</b> . <i>scsi_address.logical_unit_number</i>
Built-in UWSCSI	<b>fwsci</b> . <i>scsi_address.logical_unit_number</i>
Built-in SCSI	<b>sescsi</b> . <i>scsi_address.logical_unit_number</i>
Optional	<b>gscn</b> . <i>scsi_address.logical_unit_number</i>
Built-in LAN	<b>lan</b> . <i>server_address.init_timeout.io_timeout</i>

To display the current setting for a particular system path, follow the directions in “Accessing the Boot Console Interface” earlier in this appendix, and then type the following at the prompt:

```
Main Menu: Enter command> path path_type
```

where *path\_type* is one of the path types listed in Table 38.

For example, to get the path to the primary boot device, follow the directions in “Accessing the Boot Console Interface” earlier in this chapter, and then type the following at the prompt:

```
Main Menu: Enter command > path primary
```

## Boot Console Interface

### Displaying and Setting Paths

To set a system path to a new value, follow the directions in “Accessing the Boot Console Interface” earlier in this chapter, and then type the following at the prompt:

```
Main Menu: Enter command> path path_type path
```

where *path\_type* is one of the path types listed in Table 38 and *path* is the specification of the path in Mnemonic Style Notation (as described in Table 39). For example, to set the primary boot path to a scsi disk with an ID of 6.0, follow the directions in “Accessing the Boot Console Interface” earlier in this appendix, and then type the following at the prompt:

```
Main Menu: Enter command> path pri sescsi.6.0
```

## Displaying and Setting the Monitor Type

Your system ships from the factory preset to use a monitor with a specific resolution and frequency. If you replace your workstation's monitor with a different type of monitor, you must reconfigure your workstation to support the new monitor.

### The Monitor Command

The **monitor** command lets you change your workstation's graphics configuration. This command is available in the Configuration Menu of the boot console interface.

---

**NOTICE:**

The monitor command lets you change your workstation's graphics configuration before you replace your monitor. For information about changing the configuration after you replace your monitor, go to the section "Changing Your Monitor Type" in Appendix B.

---

To display the current graphics and console information, enter the following command;

**monitor**

The correct usage for setting the graphics configuration is:

**monitor** *graphics\_path type*

where valid *graphics\_path* parameters are:

*graphics(0)* - The built-in 8-plane graphics adapter.

*graphics(1)* - Graphics adapter installed in option slot 1.

*graphics(2)* - Graphics adapter installed in option slot 2.

and *type* is the numerical monitor type as shown with the **monitor list** command.



When a dual display graphics adapter (an adapter which has two video output connectors) is installed, the video connector on the left (when looking at the system from the rear) is *graphics(NA)* and the video connector on the right is *graphics(NB)*. Where *N* is the slot number in which the graphics adapter is installed.

For example, a Dual Visualize Enhanced Graphics Card (A4451A) installed in option slot 2 would be *graphics(2A)* and *graphics(2B)*.

---

**NOTICE:**

There are graphics configuration restrictions of which you must be aware when adding graphics adapters or reconfiguring your graphics devices. For details on graphics configuration restrictions, see the subsection “Graphics Configuration Restrictions” in Appendix B.

---

### Displaying the Current Monitor Configuration

To display the current monitor configuration for your system from the Configuration Menu of the boot console interface, follow the directions in “Accessing the Boot Console Interface” earlier in this appendix. Once you are in the Boot Console Interface Main Menu, type:

```
Main Menu: Enter command > configuration
```

This places you in the Configuration Menu. From here type:

```
Config Menu: Enter command> monitor
```

## Boot Console Interface

### Displaying and Setting the Monitor Type

The screen displays a list of the current graphics adapters and their monitor types configured for your workstation.

#### MONITOR INFORMATION

Path	Slot	Head	HPA	Resolution	Freq	Type	Class
GRAPHICS(0)	0	1	f8000000	1280x1024	72Hz	12	

Configuration Menu: Enter command >

In this example, only the built-in graphic adapter graphics(0) is configured. The monitor type for graphics(0) is set to type 12, which is a 1280 by 1024 monitor that uses a frequency of 72 Hz.

## Setting the Monitor Type

You can set the monitor type for a graphics adapter by typing the following:

```
Config Menu:Enter command> monitor graphics(n) tt
```

Where *n* is the number of the graphics adapter and *tt* is the monitor type.

To display a list of supported monitors, enter the following command;

```
Config Menu: Enter command> monitor list
```

A list of valid monitor types similar to the following is displayed;

```
MONITOR INFORMATION
```

Path	Slot	Head	Type	Size	Freq	Class
GRAPHICS(0)	0	1	1	1280x1024	75Hz	VESA
GRAPHICS(0)	0	1	2	1280x1024	75Hz	VESA,Double buffered
GRAPHICS(0)	0	1	3	1280x1024	75Hz	VESA,Greyscale
GRAPHICS(0)	0	1	4	1280x1024	75Hz	VESA,Double buffered,Greyscale
GRAPHICS(0)	0	1	5	1024x768	75Hz	VESA
GRAPHICS(0)	0	1	6	800x600	75Hz	VESA
GRAPHICS(0)	0	1	7	640x480	75Hz	VESA
GRAPHICS(0)	0	1	8	1600x1200	75Hz	VESA
GRAPHICS(0)	0	1	9	1600x1200	75Hz	VESA,Greyscale
GRAPHICS(0)	0	1	10	1200x1600	75Hz	VESA
GRAPHICS(0)	0	1	11	1200x1600	75Hz	VESA,Greyscale
GRAPHICS(0)	0	1	12	1280x1024	72Hz	
GRAPHICS(0)	0	1	13	1280x1024	72Hz	Double buffered
GRAPHICS(0)	0	1	14	640x480	60Hz	
GRAPHICS(0)	0	1	15	-----user defined-----		

```
Configuration Menu: Enter command >
```

## Boot Console Interface

### Displaying and Setting the Monitor Type

To set the monitor type for graphics(0) to monitor type 2 you would enter the following;

```
Config Menu: Enter command> monitor graphics(0) 2
```

The boot console displays a message that tells you that your new monitor selection will take effect the next time you reboot your system.

This will take effect on the next reboot.

MONITOR INFORMATION

Path	Slot	Head	HPA	Resolution	Freq	Type	Class
GRAPHICS(0)	0	1	f8000000	1280x1024	72Hz	2	

The boot console also displays the new monitor information.

Trying to change the monitor type to a number not listed for that graphics device fails and gives you the following warning message:

```
Value of monitor type n out of range (n - nn)
```

Trying to change the monitor type on an empty slot fails and gives you the following warning message:

```
No such graphics card.
```

## Setting the Monitor Type at Power On

If you replace your workstation's monitor with a different monitor type, and do not set the workstation's graphics parameters by using the monitor command before doing so, you need to perform the following:

Wait 2 seconds after the **Num Lock** light flashes near the end of the boot sequence, then press **Tab** to initiate the automatic monitor selection process.

The system cycles through all of the available monitor types one at a time. When you can see a message similar to the following clearly and legibly, select that monitor type by pressing **Enter**.

MONITOR INFORMATION

```
Path      Slot  Head  Type      Size      Freq  Class
-----
GRAPHICS(0)  0    1    n      nnnnxnnnn  nnHz
Press [RETURN] to select this monitor type (type n of n types).
```

The system queries you to confirm your selection. Press **Y** to save this monitor type.

If you press any key other than **Y**, the following message is displayed:

```
Monitor type not saved.
```

At this point, the new monitor type is active, but not saved. Because you didn't save the monitor type, the next time you reboot the system the original monitor type will be used.

## Boot Console Interface

### Displaying and Setting the Monitor Type

Next, the following message is displayed:

```
To select a new Graphics Monitor Type press
the <TAB> key now, otherwise EXIT by enter-
ing any other key (or will time out in 15
seconds)...
```

To restart the monitor selection process, press TAB.

### Changing the Console to External Terminal

In the event that your console stops displaying to your graphics device, use the following procedure to display to console to an external terminal:

- 1 Turn system power off.
- 2 Disconnect the PC keyboard connector from the system rear panel.
- 3 Connect a serial terminal to the Serial 1 connector (the top serial connector) on the system rear panel.
- 4 Power on the system.

The system will now display the console to the terminal connected to the Serial 1 port. Note that you can use a 9-pin to 9-pin serial cable (HP F1044-80002) to connect an HP Omnibook laptop computer serial port to the workstation.

## Displaying the Current Memory Configuration

The following sample screen output using the **memory** command shows a sample memory configuration table.

To display the current memory configuration for your system, from the Information Menu of the boot console interface, follow the directions in “Accessing the Boot Console Interface” earlier in this appendix. Once you are in the Boot Console Interface Main Menu, type:

```
Main Menu: Enter command > information
```

This places you in the Information Menu. From here type:

```
Information Menu: Enter command > memory
```

## Boot Console Interface

### Displaying the Current Memory Configuration

The screen displays status and configuration information for the memory DIMMs installed in your workstation.

The following sample shows the memory information when memory modules are properly installed and configured

#### MEMORY INFORMATION

##### MEMORY STATUS TABLE

Slot	Size(a+b)	Status
0a/b	64MB	Configured
1a/b	32MB	Configured
2a/b	128MB	Configured
TOTAL	224MB	

Memory	
HVERSION	SVERSION
0x0710	0x0900



## Setting the Auto Boot and Auto Search Flags

**auto boot** and **auto search** are variables stored in your workstation's nonvolatile memory. If you reset these flags to a new value, the change takes effect the next time you reboot the workstation.

**auto boot** boots the operating system whenever your workstation is turned on.

To examine the state of the **auto boot** and **auto search** flags, type the following at the prompt:

```
Configuration Menu: Enter command > auto
```

If **auto boot** is set to **on**, your workstation automatically attempts to boot the operating system when turned on. If **auto boot** is set to **off**, your workstation enters the boot administration mode of the boot console user interface.

The state of the **auto search** flag determines how your workstation seeks a boot device during autoboot. If **auto search** is set to **on**, your workstation will search for other boot devices if the primary boot device is not available. If **auto search** is **off**, your workstation will default to the boot administration mode if it can't see the primary boot device.

To change the state of the **auto boot** or **auto search** flags, type the following at the prompt:

```
Config Menu: Enter command> auto boot state
```

or

```
Config Menu: Enter command> auto search state
```

where *state* is **on** or **off**.

Autosearch searches for devices in the following order:

- Primary Boot Path
- Alternate Boot Path
- Built-in Fast, Wide SCSI Devices
- SCSI card in slot 1
- SCSI card in slot 2
- Built-in Single-Ended SCSI Devices
- Built-in LAN bootp servers

---

***NOTICE:***

Fast Wide SCSI adapter option cards installed in the option slots are not searched unless they are referenced by the primary or alternate boot paths.

EISA cards are not searched.

---

## Displaying and Setting the Fastboot Mode

When **fastboot** is enabled (set to **on**), your workstation does a quick check of the memory and skips I/O interface testing during its power-on self tests. This enables your workstation to complete its boot process quicker. The default factory setting is for **fastboot** to be enabled (**on**).

The **fastboot** mode allows your workstation to boot quickly by performing a less extensive check of the system's memory.

When **fastboot** is disabled (set to **off**), more extensive memory testing and I/O interface testing is performed during the self tests, causing the boot process to take longer.

If you are experiencing difficulty in booting your workstation, set **fastboot** to **off** and reboot the system. The more extensive testing may reveal the error condition.

To display the status of **fastboot**, type the following at the prompt:

```
Config Menu: Enter command > fastboot
```

To disable **fastboot**, type the following at the prompt:

```
Config Menu: Enter command > fastboot off
```

To enable **fastboot**, type the following at the prompt:

```
Config Menu: Enter command > fastboot on
```

## Displaying the LAN Station Address

It is sometimes necessary to supply a LAN station address of your workstation to other users. For example, if your workstation is to become a member of a cluster, the cluster administrator needs to know your LAN station address in order to add your workstation to the cluster.

A **LAN station address** of your workstation is the label that uniquely identifies the LAN connection for your workstation at the **link level** (the hardware level).

To display your workstation's LAN station addresses, type the following at the prompt:

```
Info Menu: Enter command > lanaddress
```

The LAN station address is displayed as a twelve-digit number in hexadecimal notation, similar to the following:

```
LAN Station Addresses:    080009-789abc
```

The address is for the system's built-in LAN.

## Configure and Display LAN Settings (B132L+/B180L Only)

The LanConfig command configures and displays the current LAN settings. The hardware system supports 10Base-T, 100Base-T and AUI standards.

To automatically select the network speed (100 Mbits/sec or 10 Mbits/sec) and data transfer operation (full or half duplex), operating in compliance with IEEE 802.3u, (this is the default and recommended setting) type the following at the prompt:

```
Configuration Menu: Enter command  
> LanConfig AUTO
```

To select 10 Mbits/sec network speed and half duplex mode, type the following at the prompt:

```
Configuration Menu: Enter command  
> LanConfig 10/Half_dx
```

To select 10 Mbits/sec network speed and full duplex mode, type the following at the prompt:

```
Configuration Menu: Enter command  
> LanConfig 10/Full_dx
```

To select 100 Mbits/sec network speed and half duplex mode, type the following at the prompt:

```
Configuration Menu: Enter command  
> LanConfig 100/Half_dx
```

To select 100 Mbits/sec network speed and full duplex mode, type the following at the prompt:

Boot Console Interface  
**Configure and Display LAN Settings (B132L+/B180L Only)**

Configuration Menu: Enter command  
> **LanConfig 100/Full\_dx**

To select the AUI port (10 Mbits/sec, half duplex only),  
type the following at the prompt:

Configuration Menu: Enter command  
> **LanConfig AUI**

---

***NOTE:***

---

The LAN setting defaults to LAN-TP(RJ45). If that setting fails, the system tries the LAN-AUI setting. Also note that the new lan configuration settings take effect at the next B0ot or SEArch command

## Displaying System Information

The **all** command allows you to display the system's processor revision and speed, cache size, memory size, flag settings, and the boot and console paths. To display system information from the Information Menu, type the following at the prompt:

```
Information Menu: Enter command > all
```

This information is paged to allow you to view it as necessary.

## Displaying PIM Information

The **pim** command allows you to display the most recent PIM information for the specified fault type. To display PIM information for a specific fault, from the Service Menu, type the following at the prompt:

```
ServiceMenu:Entercommand> pim processor_number
```

You can use **pim** in the following ways:

**pim** - gives all fault types

**pim 0** - HPMC information on processor

**pim 0 *fault\_type*** - fault type information on processor



---

## Stable Storage

Stable storage is nonvolatile memory associated with the PA-RISC processor module. Stable storage is used by the processor (CPU) to store

- Device path information
- The state of the boot flags
- HPMC error information
- Operating system initialization data

## ISL Environment

The ISL environment provides the means to load the operating system (HP-UX) environment. The ISL environment also provides an offline platform to execute diagnostic and utility programs from a boot device when HP-UX does not load.

The ISL program is the first program loaded into main memory from an external media (LAN, disk, or tape) and launched by the initial program loader (IPL) routine from the Boot Administration environment.

The ISL environment provides the following capabilities:

- Execute user-entered commands to modify boot device paths and boot options in stable storage
- Run offline diagnostic programs and utilities
- Provide automatic booting of the HP-UX O/S after power-on or reset

### Invoking ISL from the Boot Console Interface

Perform the following steps to invoke ISL from the boot console interface:

- 1 Follow the directions in “Accessing the Boot Console Interface” earlier in this chapter, and then type the following at the prompt:

**boot** *device*

You are prompted:

```
Interact with ISL (Y,N,or Q) > y
```

- 2 Answering yes (**y**) causes the ISL to be loaded from the specified device. After a short time, the following prompt appears on your screen:

```
ISL>
```

ISL is the program that actually controls the loading of the operating system. By interacting with ISL, you can choose to load an alternate version of the HP-UX operating system.

For example, if the usual kernel (**/stand/vmunix**) on your root disk (**fwscsi.6.0**) has become corrupted, and you wish to boot your workstation from the backup kernel (**/stand/vmunix.prev**), type the following at the ISL> prompt:

```
ISL> hpux /stand/vmunix.prev
```

### ISL User Commands

The following commands available in the ISL environment allow you to display and modify the boot characteristics of the system.

- **help** - lists ISL command menu and available utilities.
- **display** - displays the boot and console paths in Stable Storage and the current setting of the ISL Boot Flags.
- **primpath** - modifies the primary boot path entry in Stable Storage. The entry in Stable Storage for the primary boot device begins at byte address 0 and ends at byte address 31.
- **altpath** - modifies the alternate boot path entry in Stable Storage. The entry for the alternate boot device begins at byte address 128 and ends at 159.

## Boot Console Interface

### ISL Environment

- **conspath** - modifies the console path entry in Stable Storage. The entry in Stable Storage for the console device begins at byte address 96 and ends at byte address 127. The entry for the keyboard and mouse devices begins at byte address 160 and ends at 191.
- **listautofl** or **lsautofl** - lists the contents of the (HP-UX) autoboot file.
- **support** - boots the Support Tape from the boot device.
- **readss** - displays 4 bytes (one word) from Stable Storage. The readss command requires a decimal number between 0 and 255 to address four bytes in Stable Storage.

## Updating System Firmware with ODE

The Offline Diagnostic Environment (ODE) consists of diagnostic modules for testing and verifying system operation. The update utility of ODE provides the capability of updating the PDC/IODC firmware from the LIF directory onto the EEPROM.

ODE is an ISL utility. To invoke ODE and bring up the update utility:

- 1 Invoke the ISL environment from the system disk.
- 2 Type **ode** after the `ISL>` prompt to invoke **ode** from the **LIF** directory on the system disk. The prompt changes to `ODE>`.
- 3 At the `ODE>` prompt, type **update** to bring up the update utility. The prompt changes to `UPDATE>`.

The following commands may be entered at the `UPDATE>` prompt:

- **help** - prints a one line description of each of the available commands in the update utility.
- **info** - prints information on how to use the update utility.
- **run** - updates the PDC of the workstation from the LIF directory.
- **image** - allows you to specify which LIF images to use.
- **expert** - enables/disables exit pausing and run confirmation for expert users.
- **exit** - resets the workstation so the new PDC can run.

To run the **update** utility, type **run** at the `UPDATE>` prompt. After **update** loads the new images into memory, it asks if you want to continue the update process,

## Boot Console Interface

### Updating System Firmware with ODE

and displays the PDC version of the currently running PDC as well as that of the images that were loaded. If you wish to continue, type **y**.

When the update process has completed, the machine reboots automatically.

If you are using a graphics monitor for the updating procedure, characters may not be printed to the screen correctly because the character set for graphics printing is stored in the machine ROM that is overwritten. We recommend that you use a terminal connected to the first serial port, serial 1, for updating your workstation.

---

# Index

---

## A

audio  
connectors, 11  
controls, 8  
conversion formula, 13  
electrical specifications, 12  
features, 11  
headset jack, 8  
inputs, 12  
mic jack, 8  
mute button, 8  
outputs, 12  
volume control, 8  
AUI connector  
pinouts, 170  
auto boot,, 203  
auto boot, changing state,, 203  
auto search,, 203  
auto search, changing state,, 203

## B

backplane  
removing, 139  
backplane to PCI connector  
pinouts, 152  
backplane/system board connector  
pinouts, 147  
battery  
removing, 135  
boot commands, 59  
boot console  
accessing,, 183  
boot failure  
dealing with, 56  
bootable media  
searching for,, 187

## C

CD-ROM drive  
removing, 119  
codes  
chassis, 61  
error, 61  
commands

all,, 209  
auto,, 203  
boot,, 185  
fastboot,, 205, 207, 208  
lanaddress,, 206  
memory,, 201  
path,, 190  
pim,, 210  
reset,, 189  
search,, 187  
configurations  
FRU, 34  
graphics, 46  
memory, 43  
storage, 35  
workstation, 33  
connectors  
audio, 11  
AUI pinouts, 170  
backplane to PCI slot pinouts, 152  
backplane to system board pinouts, 147  
enhanced video pinouts, 169  
fan pinouts, 166  
hard disk drive pinouts, 162  
HP parallel I/O, 14  
keyboard, 14  
mouse, 14  
network, 14  
parallel port pinouts, 167  
power cord, 16  
PS/2, 17  
PS/2 pinouts, 170  
rear panel, 10  
SCSI device pinouts, 168  
SCSI devices, 16  
serial I/O, 15  
serial I/O port pinouts, 170  
Console, external, 91  
controls  
audio, 8  
TOC button, 16  
CPU board  
removing, 128

## D

DDS tape drive  
removing, 119  
devices  
booting from, 56  
internal storage, 4  
pointing, 15  
removable storage, 9  
SCSI IDs, 36  
storage configurations, 36  
diagnostics  
running ODE-based, 79  
disk filler panel  
removing, 118  
disk tray  
positions, 34

## E

EISA, 5  
EISA boards, 5  
enhanced video connector  
pinouts, 169  
External Console, 91

## F

fans  
pinouts, 166  
removing, 133  
fastboot  
disabling,, 205  
displaying status,, 205, 207, 208  
enabling,, 205  
fastboot,, 205  
Fast-Wide SCSI board  
backplane connector pinouts, 148  
FDDI  
determining ID, 129  
firmware  
updating system with ODE, 215  
floorstand  
removing, 103  
floppy disk drive  
disconnecting cables, 121

---

## Index

- 
- removing, 121
  - FRUs
    - configurations, 34
    - exchange part numbers, 95
    - installing memory modules, 109
    - main tray, 96
    - nonexchange part numbers, 95
    - procedures, 102
    - removing backplane, 139
    - removing battery, 135
    - removing CD-ROM drive, 119
    - removing CPU board, 128
    - removing DDS tape drive, 119
    - removing disk filler panel, 118
    - removing fans, 133
    - removing floorstand, 103
    - removing floppy disk drive, 121
    - removing GSC option boards, 126
    - removing hard disk drive, 124
    - removing main tray assembly, 105
    - removing memory modules, 106
    - removing optional video RAM module, 131
    - removing PCI option boards, 126
    - removing power supply, 136
    - removing speakers, 133
    - removing storage tray, 114
    - removing storage tray cover, 117
    - storage tray, 97
    - tools needed, 94
  - ftp, 22
  - G**
    - graphics
      - configurations, 46
      - GSC boards
        - removing, 126
      - GSC option boards, 5
  - H**
    - hard disk drive
      - pinouts, 162
      - removing, 124
  - I**
    - IDs
      - determining LAN and FDDI, 129
    - initial system loader (ISL), 212
    - Initial System Loader. *See* ISL
    - input
      - audio, 12
    - installation
      - workstation, 29
  - ISL
    - altpath command, 213
    - conspath command, 214
    - display command, 213
    - environment, 60, 212
    - help command, 213
    - interacting with, 56
    - invoking, 212
    - invoking ODE-based diagnostics, 79
    - listautofl and lsautofl commands, 214
    - primpath command, 213
    - program, defined, 60
    - readss command, 214
    - support command, 214
    - user commands, 213
    - using to update firmware with ODE, 215
- L**
  - LAN
    - determining ID, 129
    - displaying station address, 129
    - LAN station address., 206
- LAN station address,displaying., 206
- LANIC ID, 19
- LEDs
  - error codes, 61
  - power, 7
  - system, 7
- M**
  - mail, 21
  - main tray
    - removing, 105
  - man commands
    - cstm, 77
    - ftp, 22
    - mstm, 77
    - rcp, 23
    - rlogin, 22
    - telnet, 21
    - xstm, 77
  - manuals
    - reference, 177
  - media
    - searching for bootable, 58
  - memory, 4
    - configurations, 43
    - displaying configuration., 201
    - installing modules, 109
    - removing modules, 106
  - monitor
    - displaying type., 193, 195
    - setting type at power on, 199
    - setting type., 197
  - monitors
    - types of, 17, 45
  - mouse, 17
    - connector, 14
- N**
  - network, 4
    - connector, 14
  - networking
    - ftp, 22
    - mail, 21
    - NFS, 23



---

## Index

---

- overview, 21
  - rcp, 23
  - rlogin, 22
  - telnet, 21
  - NFS, 23
  - notes
  - service, 179
- O**
- ODE-based diagnostics, 79, 215
  - offline diagnostics environment (ODE), 79, 215
  - operating system
  - overview, 18
  - option boards
  - removing, 126
  - optional video RAM module, 131
- P**
- parallel port connector
  - pinouts, 167
  - path
  - displaying., 190
  - setting., 192
  - path., 190
  - paths
  - support boot, 59
  - PCI boards
  - removing, 126
  - PCI slot to backplane connector
  - pinouts, 152
  - PIM information, displaying., 210
  - pinouts
  - AUI connector, 170
  - backplane to PCI slot connector, 152
  - enhanced video connector, 169
  - fans, 166
  - FWSCSI board backplane connector, 148
  - hard disk drive, 162
  - parallel port connector, 167
  - PS/2 connector, 170
  - SCSI device connector, 168
  - serial I/O port connector, 170
  - system board/backplane connector, 147
  - power cord connector, 16
  - power on
  - troubleshooting, 52
  - power supply
  - removing, 136
  - power switch, 7
  - preventive maintenance, 29
  - PS/2 connector
  - pinouts, 170
- R**
- rcp, 23
  - rlogin, 22
- S**
- SCSI devices
  - connector pinouts, 168
  - connectors, 16
  - IDs, 36
  - security loop, 11
  - selftests, 61
  - troubleshooting, 53
  - serial I/O
  - connectors, 15
  - serial I/O ports connector, 170
  - service notes, 179
  - speaker
  - removing, 133
  - specifications
  - environmental, 27
  - stable storage, 59, 211
  - storage
  - stable, 59, 211
  - storage devices
  - removable, 9
  - storage tray
  - removing, 114
  - storage tray cover
  - removing, 117
  - system board/backplane connector
  - pinouts, 147
  - system information, displaying., 209
  - system power, 145
  - system verification tests
  - running, 77
- T**
- telnet, 21
  - Terminal, external, 91
  - tests
  - running system verification, 77
  - self, 61
  - TOC button, 16
  - tools
  - needed for FRUs, 94
  - trackball, 17
  - troubleshooting
  - HP-UX compatible mode, 55
  - power on, 52
  - selftests, 53
- U**
- user interface, 3, 5
- V**
- video RAM
  - removing optional module, 131
- W**
- workstation
  - booting., 185
  - configuration, 33
  - features, 3
  - installation, 29
  - installation manual, 177
  - preventive maintenance, 29
  - resetting to predefined parameters, 189
  - resetting., 189
  - security loop, 11
  - service manual, 177
-

---

## Index

---